

# Operation manual

## Gravity Auto

### GRAVITY AUTO Usage

- Always push phone firmly onto product and ensure it is held well before driving
- When removing phone, hold product at vent or dash mount while gently pulling phone away starting from one side.
- Before use in the car, attach phone and determine if phone sticks sufficiently. If more adhesion is desired, remove upper half circle and re-test. For the most adhesion, remove upper and lower half circles.
- Sticky surface naturally attracts dust and typically needs refreshed weekly or sooner. Renew the surface every 2 weeks by rubbing with water on your hand and allowing to air dry.
- Never use a cloth or other material to renew sticky surface.

### **First of all, thanks sincerely for buying this product**

1) For your safety, please read this manual carefully

before using this product .

2) Please make sure that write down the selling date and s

ales shop's name on the warranty, and put it away with

operation manual, keep them properly.

1. To protect people from harm and property loss, we make a clear explanation on what you

do should obey:A. Warning! There ate concerning the possibilities of death and severe wound : People who use heart-birth-maker should consult your doctor before you use this product ; And please leave it at a distance of 50cm from the place where you install your heart-birth-maker, the electromagnetic wave have influence on heart-birth-maker's work.

B. Attention! It may led to heat, fire and electric shock:

- 1) Do not put it into water or any other liquid , Do not make it wet;
- 2) Do not pull the AC adapter out with wet hands, ensure the safety and integrity of the adapter;
- 3) Do not let the dust or other things accumulate on the product and the AC adapter;
- 4) Do not use the product outside the temperature-20 °C to 40 °C ;
- 5) Do not charge in places where the sun shine directly or with high temperature;
- 6) Do not use this product in places that are easy to fall , so as not to break;
- 7) Do not lay the magnetic card , magnetic record media and precise machine too close to the protect ;
- 8) Do not decompose and remold ;
- 9) Do not lay anything between the non-connection charging pad and the charging machine ;
- 10) Do not surpass the rated value when using the plug and other wiring layout;
- 11) Do not make any breakage on the AC adapter , please make sure you connect the AC adapter fully and take the AC adapter off the plug when it's not used .

12) Do not use travel converter .

13) Please teach your children , the let them use

## 2. Product advantages

1) the product is of high sensitivity , intelligent recognition, put a charge; After charging, automatically enter standby mode of the product;

2) charge for all Qi compliant product .

3) efficiency can reach more than 70% ,less heat;

4) in the process of charging can be free to pick up, answer the phone , freeing discharge or charge;

## **The third wireless charger's charging method**

1). Insert the USB cable into computer or power adapter.

2). Place the phone on the wireless charger in vertical or horizontal position as shown.

3).LED will turn on when charging.

4). When the charging equipment complete, can be taken away;

Products applicable: all qi wireless charging equipment accorded with Qi standard;

Charging type: one-on-one charge corresponding area;

The input voltage:DC:5V-2A;9V-1.67A

Launch distance:4 to 6 mm;

Conversion efficiency:  $\cong 70\%$ ;

Charging methods: induction model;

Working frequency:110-205 KHz;

Accessories/components name: USB cable, Wireless charging pad ,Packing box, AC adapter(Selective).

**FCC Warning**

This device complies with Part 18 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.