

# $\alpha$ 711P

**RFID UHF Reader**  
**User Guide**  
Ver. 0.1



Copyright 2020. Aplusetech Co.,Ltd. All rights reserved.

**Apulsetech** is the manufacturer of Apulsetech RFID handheld computers.

This document and related software in this device are protected by international copyright laws.

Any part of this document may not be reproduced, removed or used in any form by any means, without permission in writing from Apulsetech.

The contents in this manual is subject to change without prior notice.

Apulsetech and α711P are registered trademarks of Apulsetech Co.,Ltd., all other trademarks and copyrights are property of their respective owners.

The software is provided for user understanding how to use the device and application development. All software, including firmware, is on a licensed basis.

No right to copy a licensed program in whole or in part is granted, to other device except as permitted under copyright law.

Apulsetech

C-1211, 60, Haan-ro,  
Gwangmyeong-si,  
Gyeonggi-do,  
Republic of Korea

2 | 27

## Revision History

Change	Date	Description
Ver.0.1	2020/03/31	Draft

# Table of Contents

## Copyright

## Revision History

<b>1.</b>	<b>About this guide .....</b>	<b>8</b>
1.1	Introduction .....	8
1.2	Configuration .....	8
1.3	Related document and Software.....	8
1.4	Service information .....	8
1.5	Safety information .....	9
<b>2.</b>	<b>Brief Description of α711P .....</b>	<b>11</b>
2.1	Packing Contents .....	오류! 책갈피가 정의되어 있지 않습니다.
2.2	α711P Overview .....	11
2.2.1	Top view .....	11
2.2.2	Bottom view .....	11
2.2.3	Front view.....	12
2.2.4	Back view .....	13
2.3	α711P Accessories.....	오류! 책갈피가 정의되어 있지 않습니다.
<b>3.</b>	<b>Getting Started .....</b>	<b>14</b>
3.1	Installing and Replacing the Battery .....	14
3.2	Charging the Battery.....	15
3.3	Battery Management .....	15
3.3.1	When charging a711 and Smart at the same time with DC Adapter.....	오류! 책갈피가 정의되어 있지 않습니다.
3.3.2	When charging through Docking Cradle.....	오류! 책갈피가 정의되어 있지 않습니다.
3.3.3	Spare Battery charging .....	오류! 책갈피가 정의되어 있지 않습니다.
3.4	Switching α711P on and off.....	15
3.5	Reset.....	16

<b>4.</b>	<b>Android Connections .....</b>	<b>17</b>
4.1	Compatible Product Models .....	17
4.2	Demo Apps .....	17
4.3	BT Connection.....	오류! 책갈피가 정의되어 있지 않습니다.
4.3.1	Setup .....	오류! 책갈피가 정의되어 있지 않습니다.
4.3.2	Make a Connection .....	오류! 책갈피가 정의되어 있지 않습니다.
4.4	Bluetooth Connection.....	17
4.4.1	Setup .....	17
4.4.2	Make a Connection .....	17
4.5	Wi-Fi Connection.....	19
4.5.1	Setup .....	19
4.5.2	Make a Connection .....	19
<b>5.</b>	<b>Windows Connections .....</b>	<b>오류! 책갈피가 정의되어 있지 않습니다.</b>
5.1	Compatible Product Models.....	오류! 책갈피가 정의되어 있지 않습니다.
5.2	BT Connection.....	오류! 책갈피가 정의되어 있지 않습니다.
5.2.1	Setup .....	오류! 책갈피가 정의되어 있지 않습니다.
5.2.2	Make a Connection .....	오류! 책갈피가 정의되어 있지 않습니다.
5.3	Bluetooth Connection.....	오류! 책갈피가 정의되어 있지 않습니다.
5.3.1	Setup .....	오류! 책갈피가 정의되어 있지 않습니다.
5.3.2	Make a Connection .....	오류! 책갈피가 정의되어 있지 않습니다.
5.4	Wi-Fi Connection.....	오류! 책갈피가 정의되어 있지 않습니다.
5.4.1	Setup .....	오류! 책갈피가 정의되어 있지 않습니다.
5.4.2	Make a Connection .....	오류! 책갈피가 정의되어 있지 않습니다.
5.5	Serial Connection.....	오류! 책갈피가 정의되어 있지 않습니다.
5.5.1	Setup .....	오류! 책갈피가 정의되어 있지 않습니다.
5.5.2	Make a Connection .....	오류! 책갈피가 정의되어 있지 않습니다.
<b>6.</b>	<b>iOS Connections.....</b>	<b>21</b>
<b>7.</b>	<b>LED Indications .....</b>	<b>22</b>
7.1	α711P Booting & Battery Level status .....	22

7.2	BT Mode.....	22
7.2.1	α711P BT Ready .....	22
7.2.2	α711P BT Connection .....	22
7.2.3	α711P BT Sleep .....	22
7.2.4	α711P BT HID Ready.....	22
7.2.5	α711P BT HID Connection.....	22
7.2.6	α711P BT HID Sleep .....	23
7.3	BT Mode.....	23
7.3.1	α711P BT Ready .....	23
7.3.2	α711P BT Connection .....	23
7.3.3	α711P BT Sleep .....	23
7.4	WIFI Mode.....	오류! 책갈피가 정의되어 있지 않습니다.
7.4.1	α711P WIFI Read .....	오류! 책갈피가 정의되어 있지 않습니다.
7.4.2	α711P WIFI Connection.....	오류! 책갈피가 정의되어 있지 않습니다.
7.4.3	α711P WIFI Sleep.....	오류! 책갈피가 정의되어 있지 않습니다.
7.5	Serial Mode.....	오류! 책갈피가 정의되어 있지 않습니다.
7.5.1	α711P Serial Ready .....	오류! 책갈피가 정의되어 있지 않습니다.
7.5.2	α711P Serial Connection .....	오류! 책갈피가 정의되어 있지 않습니다.
7.5.3	α711P Serial Sleep .....	오류! 책갈피가 정의되어 있지 않습니다.
7.6	When Charging Status.....	오류! 책갈피가 정의되어 있지 않습니다.
7.6.1	α711PCharging : RED LED is on the battery status	오류! 책갈피가 정의되어 있지 않습니다.
<b>8.</b>	<b>Follow Demo APK .....</b>	<b>23</b>
8.1	UHF Reading.....	23
8.2	Barcode Scanning .....	24
<b>9.</b>	<b>OS &amp; Firmware Update .....</b>	<b>25</b>
9.1	OS Update .....	25
9.2	RFID F/W Update .....	25
<b>10.</b>	<b>Specifications .....</b>	<b>25</b>

**11. Troubleshooting ..... 27**

# 1. About this guide

## 1.1 Introduction

The α711P (RFID UHF Reader) is a high performance UHF reader connecting to almost any mobile device. WIFI, Bluetooth or BT connections can be chosen in order to link to Android or iPhone device. Optional 2D barcode scanner engine from Zebra is available to capture 1D/2D barcode data and multitask on mobile phone efficiently. Users are able to experience highest working performance with α711P

This guide is designed for helping users to operate α711P effectively. Please read the guide carefully before using α711P.

## 1.2 Configuration

- This guide provides information of the following configurations including optional features.

Model	Operating System	Radios	Memory	Data Capture Options
α711P	Google Android	860MHz – 960MHz	2GB RAM, 8GB Internal	2D Imager Barcode Scanner

## 1.3 Related document and Software

α711P Quick Guide

Android SDK User Guide

Android SDK Developer's Guide

Android SDK Release Notes

Barcode Demo app

RFID Demo app

BarcodeRfidDemo app

Remote Manager app

## 1.4 Service information

If you have problem with the device, visit our web site to analyze the problem or contact our partner in region or HQ.



Contact information is available at our website <http://www.apulsetech.com>




When requesting support, please have following information;

- Serial number of the device ( On manufacturing label )
- Firmware version

## 1.5 Safety information

### *Symbols*

This guide uses the following symbols to indicate hazards and additional information.

Symbol	Name	Description
	Warning	Implies information that could result in serious injury to yourself or others.
	Caution	Implies information that may result in minor or serious product damage.
	Note	Implies information that can help you get more important than surrounding text, such as exceptions or additional information.

Before you use the  $\alpha 711P$ , please read this chapter of information and keep your child away from the product and aware of this information. For detailed information, please refer to the safety guidelines.

- Do not use  $\alpha 711P$  during driving for safety.
- In medical sites, please follow the relevant regulations by turning off your  $\alpha 711P$  when you are in medical sites.
- Please turn off your  $\alpha 711P$  or turn on planes mode when you are boarding, to avoid wireless signals jamming aircraft control signal.
- Please turn off your  $\alpha 711P$  near the use of high precision electronic equipment, otherwise it may lead to electronic equipment disability.

- Do not take apart your α711P or accessories without authorizing. Only authorized institutions can repair this α711P.
- Please keep α711P away from magnetic equipment. The radiation of α711P will erase the information of the magnetic storage device.
- Please don't use α711P under high temperature or in flammable areas (example: gas station).
- Please keep your α711P and accessories away from children without supervising.
- Please obey the relevant laws and regulations when you use your α711P, and respect others lawful rights and privacy.
- Product not available while charging
- Modifying the device's operating system or installing software from unknown sources may cause device malfunction or data loss. Improper or unauthorized use of the device voids your one-year limited warranty.

## 2. Brief Description of $\alpha$ 711P


### 2.1 $\alpha$ 711P Overview

#### 2.1.1 Top view




No.	Item	Description
1	2D Imager	Scans barcodes by emitting a red laser when you press the related button.

#### 2.1.2 Bottom view




No.	Item	Description
1	BT connector	Allows the device to be connected to PC or other device.
2	Battery cover	Holds battery with locker

### 2.1.3 Front view



#### 1. Description of LED Status



No.	Item	Description
1	25%, 50%, 75%, 100% Battery Level	All LED is green and does not blink - "25% LED" turns Red color when the battery is charging.
2	BT	When the BT mode is selected, Green lamp blinks
3	WIFI	When the WIFI mode is selected, Blue lamp blinks
4	HID	When the HID mode is selected, Green lamp.
5	READY	In power saving mode, LED color is Green.

#### 2. Flourish LAMA

- Smartphone holder free stick


#### 3. Antenna for RFID







- Role of sending and receiving tag data


#### 4. BT Cable

- Charging

### 2.1.4 Back view



No.	Item		Description
	Power key		Press and hold to boot α711P when it's completely turn off.
	Reset Key		When α711P is stuck and no physical buttons are not working, use small objects and press RESET button shortly, then device will force to shut down. Recommend not using the RESET key while α711P is working normally. It may damage the system and data loss.
1	Mode key		Selection button for communication mode
	FNC Key		RFID Single reading mode and Multi reading mode selection button.
	WPS Key		Button to attempt to connect a711 to a WIFI AP
	UP		Volume UP or RFID power level UP button Default is volume UP


	DOWN		Volume DOWN or RFID power level DOWN button Default is volume DOWN
2	Scan Trigger		Scanning Barcode
3	Hand Strap Holder		Place for attaching Hand Strap ( optional )
4	RFID Trigger		RFID reader
5	Speaker		For sound alert

### 3. Getting Started

#### 3.1 Installing and Replacing the Battery

α711P uses Lithium-ion rechargeable battery.

그림 교체



1. Turn the battery lock latch 45 degree to the left(Unlock side)and lift the battery cover.
2. Insert the battery into the battery slot, make sure the gold contacts are aligned.
3. Place the cover and turn the lock latch 45 degree to the right ( lock side ).



Before removing the battery, turn off the power. Failure to do so it may cause damage to the device.



When removing the battery cover, press the cover firmly and slide the latch unlock side, be careful not to damage your fingernail.

### **3.2 Charging the Battery**

***When charging only a711 body with DC Adapter***

### **3.3 Battery Management**


To charge α711P uses BT cable or a docking cradle with the appropriate power supply. You can also charge the battery by connecting it to computer with BT cable.



Before using the α711P for the first time, charge the battery until the green Charging/Notification light emitting diode (LED) remains lit.

### 3.4 Reset

- Press reset button to reset the device.
- Reset button is hardware key, it works while a711 powers on.

 It will shut down device and running application, you may lose data which made on the running application, please back-up important data frequently and use the reset function carefully.



## **4. Android Connections**

### **4.1 Compatible Product Models**

It is recommended to use of the mobile device with Android OS version 5.0 or later.

### **4.2 Demo Apps**

#### **- *Installing Demo Apps.***

Install the application on the PC and Mobile device to connect to a711 and refer to Android SDK User Guide.

α711P provides Demo Apps for function test and customer application development.

Demo Apps may update or change without any notice.

For latest demo apps or support, please contact your regional partner or visit our website.

**[www.apulsetech.com](http://www.apulsetech.com).**

Or you can download and install the related apk from Google Play Store by searching Apulsetech.


### **4.3 Bluetooth Connection**

#### **4.3.1 Setup**

- Select Bluetooth mode by pressing BT button on a711 and check if the BT LED is blinking.

#### **4.3.2 Make a Connection**


- - Run “RFID/Barcode demo app” on your mobile device.



Run Demo app on the mobile device.



1. Select SPP mode from Bluetooth section.
2. Press Search button on the screen.



Select a searched device. → Control RFID or barcode scanner while BT in connected


#### 4.4 Wi-Fi Connection

##### 4.4.1 Setup

- Select WIFI mode by pressing WIFI button on a711 and check if the WIFI LED is blinking.

##### 4.4.2 Make a Connection


- Try to make a connection by pressing WPS key on the AP while pressing WPS key on a711



Wireless Lan AP




Run Demo app on the mobile device.



→ Press Search button on the screen.



Select a searched device.



→ Control RFID or barcode scanner while WIFI is connected

## 5. *iOS Connections*




Currently not available, coming soon.

iOS Connection will be available by the end of 2020. It will be updated once it is ready.

## 6. LED Indications


### 6.1 α711P Booting & Battery Level status



### 6.2 BT Mode


#### 6.2.1 α711P BT Ready

BT mode standby : GREEN LED Blinks




#### 6.2.2 α711P BT Connection

BT mode Connection : GREEN LED ON




#### 6.2.3 α711P BT Sleep

( Sleep when BT mode ) : RED LED ON




#### 6.2.4 α711P BT HID Ready

( BT mode standby ) :




#### 6.2.5 α711P BT HID Connection

( BT HID mode Connection )



### 6.2.6 α711P BT HID Sleep


( BT HID mode Sleep )



## 6.3 WIFI Mode


### 6.3.1 α711P WIFI Ready

WIFI mode standby : GREEN LED Blinks




### 6.3.2 α711P WIFI Connection

WIFI mode Connection : GREEN LED ON



### 6.3.3 α711P WIFI Sleep

( Sleep when WIFI mode ) : RED LED ON




## 7. Follow Demo APK

This chapter provides information to use α711P for the first time. For more specific information about settings of Demo apk and details, please refer to Android SDK User guide.

### 7.1 UHF Reading

- Check the voice status when UHF Single reading and Multi reading.
- Button on the handle can be assign as UHF Tag Scanning button.

- Able to save read Tag information.
- α711P will be into SLEEP mode after no Tag for a time as setting.

 Please contact with distributor or reseller you purchase if you have a problem on LED indicator.

 LED status should be checked by pressing power button if it is necessary.

## 7.2 Barcode Scanning

- Button on the handle can be assign as Barcode Scanning button.
- Able to save read Barcode information.
- A711 will be into SLEEP mode after no Barcode scan for a time as setting.

 Use UHF Reading and Barcode Scan button selectively on your needs.

 LED status should be checked by pressing power button if it is necessary.



## 8. OS & Firmware Update

α711P is provided with most recently released firmware however if it's necessary to update the OS, you can use **OS update** app tool which provided as default app.



Backup all the data and information from your device before OS update. Your data, such as ringtones, texts, and voice messages, may be erased during the update.



Check the battery fully charged or at least 90% charged before update, low battery may cause improper update or device malfunction.

### 8.1 OS Update

Please refer to OS update guide from our website.

### 8.2 RFID F/W Update

Please refer to Firmware update guide from our website.

## 9. Specifications

### Performance Characteristics

<b>Processor</b>	Octa core 2.0GHz
<b>Operating System</b>	Android 6.0.1
<b>Memory</b>	LPDDR 32GB RAM, eMMC 8GB Internal
<b>RFID Engine</b>	Custom module with embedded Impinj R2000
<b>Operating Temp.</b>	-20°C~+70°C
<b>Storage Temp.</b>	-30°C~+80°C
<b>Humidity</b>	95% non-condensing

### Physical Characteristics

<b>Audio</b>	Speaker
<b>Standard I/O Port</b>	1Port BT 2.0 Client
<b>Notification</b>	14 EA LED Indicator, Vibrator
<b>Key</b>	Power Key, Reset Key, Function Key 7 EA
<b>Weight</b>	525g
<b>Dimensions ( L x W x H )</b>	168mm x 84mm x 15mm

## Power Supply

<b>Main Battery</b>	6800 mAh (Rechargeable)
<b>Power Adapter</b>	5V 2A Micro BT Adpater

## Network Characteristics

<b>WLAN</b>	IEEE 802.11 ac/a/b/g/n
<b>Bluetooth</b>	Bluetooth V4.1+EDR

## Data Capture Device

<b>Barcode Engine</b>	SE-4710 2D Imager Barcode Scanner from Zebra (Optional)
-----------------------	---

## UHF Reader/Writer

<b>Frequency</b>	860MHz – 960MHz
<b>Reading Range</b>	0M ~ 40M ( Depending on Tag & Environment )
<b>Writing Range</b>	0M ~ 10M ( Depending on Tag & Environment )
<b>RF output</b>	1W ~ 4W EIRP
<b>Protocol</b>	Gen2, ISO/IEC 18000-6C
<b>Special function</b>	Anti-Collision

## Accessories

<b>Cradle</b>	BT Host, Ethernet, UART ( RS-232 with 3.3V & 5V Power Supply)
<b>Leather case</b>	Yes ( optional )

## **10.        *Troubleshooting***

Trouble shooting guide is available on separated document, you can refer to FAQ or download document from our website, [www.apulsetech.com](http://www.apulsetech.com)

## **11.        *FCC Warning Statement***

FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21

Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement: This equipment complies with FCC RF Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body

\* Cell phone couldn't be physical attached on the device.