


User manual

Dot matrix digital pen



TD-801

Press the Dot matrix pen power button or press the induction pen tip, the pointer end indicator lights up, and the Dot matrix pen enters the power-on state. If the indicator light does not go on or the yellow light flashes, please charge the Dot matrix pen first. After the battery is fully charged (about 2 hours), it will be turned on for use.

Specification :

Weight	24.5g	Dimension	154.2*11.2*11.2 (mm)
Input	3.7V / 250mAH by battery	Standby Time	50days
Charging Time	<2Hours	Working Time	>6 Hours
Wireless	BT 4.2	Transmission	15meters

		distance	
Dimension of Pen Refill	67.2mm*2.3mm	System	Windows7 and above

Indicator state:

Display	State
constantly light	Waiting for BT connecting or finishing charging
constantly blue	Connecting
flash yellow	Low power warning
constantly yellow	Charging
constantly red	abnormal state
constantly red	Memory full

FCC NOTICE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.