

Using the Controls on Beat

--To activate the toy push the  button, on the underside of the toy, nearest the shaft for 1 second.

For perineum vibration continue to push  to scroll through the 6 functions available.

For shaft thumper modes, push the  button, on the underside of the toy, to scroll through the 6 functions available. Once is activated, scroll through the functions to find your combination of choice.

To turn off, simply hold the  down for 3 seconds.

Using the remote control

To use the remote control you will first need to turn Beat ON by pushing the vibration button  on the underside of the toy. Once ON you can control the toy with the remote control up to 8 metres away. To change the shaft thumper modes simply press the thumper button on the remote control .

To change the perineum stimulator vibration simply press vibration button on the remote control .

One remote control can be programmed to use with more than one Beat. To do this simply hold down the vibration buttons on the toys for 3 seconds until the light flickers red. The lights will turn green on all toys when the remote control ON/OFF buttons are pressed.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.