



Model name:

## Ajax GlassProtect (9NA)



ajax.systems/  
support/devices/  
glassprotect

EN

### Quick Start Guide

Before using the device, we strongly recommend reviewing the User Manual on the website.

### Product name: Wireless glass break detector

**GlassProtect** is an indoor glass break detector featuring a socket for connecting a third-party device with an NC contact type. GlassProtect can recognize glass breaking at a distance of up to 9 meters and operate up to 7 years from a pre-installed battery.

Frequency range	905-926,5 MHz FHSS (complies with part 15 of the FCC rules)
Maximum RF output power	3.99 mW
Radio signal range	3,200 ft (line-of-sight)
Sensitive element	Electret microphone
Wired input contact type	NC
Power supply	CR123A battery
Operation from battery	Up to 7 years
Operating temperature range	From 14° to 104°F
Operating humidity	Up to 75%
Dimensions	Ø 0.79 x 3.54 "
Weight	1.06 oz

**Complete Set:** 1. GlassProtect; 2. SmartBracket mounting panel; 3. CR123A battery (pre-installed) 4. Quick Start Guide

### FCC Regulatory Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### ISED Regulatory Compliance

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

To maintain compliance with ISED's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

**CAUTION:** RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

**Warranty:** Warranty for Ajax devices is valid for two years after the purchase date and does not apply to the supplied battery. If the device does not work correctly, you should first contact the support service—in half of the cases, technical issues can be solved remotely!

The full text of the warranty is available on the website:  
[ajax.systems/warranty](#)

User Agreement: [ajax.systems/end-user-agreement](#)

Technical support: [support@ajax.systems](mailto:support@ajax.systems)

**Manufacturer:** "AJAX SYSTEMS MANUFACTURING" LIMITED  
LIABILITY COMPANY  
**Address:** Sklyarenka, 5, Kyiv, 04073, Ukraine  
[www.ajax.systems](#)