


SmartPace R1 Pro

User Guide

Your SmartPace R1 Pro



Steps for Use

You can follow these steps to use SmartPace R1 Pro: ① Wear → ② Power On → ③ Set up → ④ Start Using

The following steps will take approximately 5 to 10 minutes, please schedule a suitable time.


① Wear Your Watch

For optimal data accuracy, please observe the following guidelines while wearing the watch:

1. Wear the watch at a position approximately two finger-widths from your wrist bone.
2. For comfort, adjust the band to allow a finger's width between it and your wrist. This ensures both contact and fit.

② Power On


Press the Digital Crown until the startup screen appears.



Note: If the watch can't power on, it may be because the battery has drained due to long periods of inactivity. Please charge it for approximately 10 minutes and wait for it to power on automatically.

③ Wear Your Watch

Step 1: Download the Fitbeing app.



Go to the app store on your phone, search for **Fitbeing**, and install it.

- For Android phones, go to the Google Play.
- For iPhone, go to the App Store.




You can also scan the QR code on the left to quickly go to the **Fitbeing** app in the app store, and install it.

Step 2: Pair with the App

Open the Fitbeing app and select "Set Up a Device" on the home page. Follow the instructions to pair your "SmartPace R1 Pro" via Bluetooth. Then you can start using the watch.

④ Get Started

Support full-screen touch (swipe, tap, touch and hold)




Crown and Button

Press

1. Press the digital crown to wake up the screen.
2. Press the digital crown to enter the app center from the watch face screen.
3. Exit an app.

Rotate

1. Toggle between screens or navigate through menus.
2. Adjust the volume of prompt tones and phone calls.



Common Functions




Change the Watch Face

To change the watch face, press and hold the screen for 1 second to access the watch face gallery.




Install New Watch Faces

In the Fitbeing app, navigate to the Face Gallery page to pick up your preferred watch face.



Charge the Watch

To charge the watch, connect the charging cable to a USB power source. Attach the other end to the charging contact on the back of the watch. The watch will display a charging icon while it is being charged.



Wear and Care


It is advised to remove the watch for approximately one hour daily. If you experience discomfort or irritation like redness, tingling, or a burning sensation, take off the watch and rest your wrist.

- To maintain hygiene, regularly clean your watch and wrist, particularly after workouts and sweating. Avoid using hand soap, shower gel, dishwashing liquid, or cleaning wipes as they can cause skin irritation. Instead, use mild soap and fresh water to clean the band.



Design for Comfortable Wearing

The inner sweat grooves of the band are specifically designed to minimize skin irritation resulting from sweat, moisture, and prolonged wear.



Precautions

Do not replace the built-in battery yourself as it may pose a safety risk.

- Avoid forcibly opening the watch case, as it may cause short circuits and overheating.
- Keep the watch away from environments exceeding 60°C to prevent battery leakage or explosion.
- While the product complies with 3ATM waterproof standards, it is not recommended for activities such as bathing, diving, or water skiing that involve high temperatures, steam, or rapid water flow. Note that the waterproof performance may be compromised if the product structure is damaged.
- Be aware that firmware upgrades can lead to interface and usage changes. For detailed information, please refer to the product's upgrade instructions.



Key Specifications

Product Name: SmartPace R1 Pro

Display: 1.43" HD AMOLED

Resolution: 466 x 466

Battery Capacity: 400 mAh

Wireless Connection: Bluetooth 5.3

Water resistance grade: 3ATM

Satellite positioning: Support GPS/IBDS/GAL/GLO/QZS/SBAS

Geomagnetic sensor: Support compass

Air pressure senso: Supports elevation

Body Dimension: 46.5mm x 46.5mm x 11.6mm

Working Temperature: 0°C ~ 50°C

Compatible Operating Systems: iOS 13.0 and above, Android 9.0 and above

Help and Guide

Frequently Asked Questions

If you encounter any problems while using the product, you can access the "Profile → Help & Support" section in the Fitbeing app for assistance.



Product Manual

You can find the complete product manual in Fitbeing app at "Profile → User Guide".

Scan the QR code on the right to access it, or visit help.fitbeing.com to browse.



FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

ISED

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RoHS COMPLIANT

FC

CE

WEEE