

User manual

Model:BY17-77



Foshan Yunai Technology Co.,Ltd

Material: Medical silicone and ABS
Vibration: 10 frequency waterproof: IPX5
Maximum noise: <50dB
Usage time: about 60 minutes
Charging time: about 40 minutes
Product size: 32*8.5*210mm
Weight: 61g grams
Label:

Product name: Vibrating egg
Model: BY17-77
FCC ID: 2BK2Y-BY17-77
Input: DC 5V300mA
Battery: DC 3.7V, 160mAh

Made in China

This device complies with part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received,
including interference that may cause undesired
operation.

1. key operation

Hold down the vibrating/power button for 1.5 seconds to start/turn off the vibrating function. At this time, the vibrator will vibrate and enter the standby state, the light will be on as shown in the figure, and then short press the vibrating/power button to switch between 9 different modes.


2. Use remote control operation

When the vibrator is in standby state, press the power button of the remote control, the vibrator starts to vibrate, and press the vibrating/power button of the remote control to enter the next frequency.

3. APP operation



APP download QR code



Device identification code

Download and install the APP

ios system

1. Search for "Twilight" in the App Store and download it.

Android system

1. Scan the QR code in the lower right corner with your mobile phone and download and install the APP as prompted

2: Register and log in the APP

1. Click the APP icon to enter the APP. Please register for the first time
2. Click "New User Registration" to register with your mobile phone number or email address

3. After registration, enter the account and password to log in to the APP

3: Bind the device

1. The customer needs to bind the device after the first login
2. Tap +. The device binding scan box is displayed
3. Scan the device identification code on the product packaging box or manual, and can be used after scanning successfully, or enter the binding code 8798.
4. If the customer has purchased several products, please repeat the above steps 2-3 to complete the binding of other products

4. Device connection and control weight:

Classical mode

Click any icon on the APP, and the device will start the corresponding vibration frequency. At the same time, the icon on the APP will flash, click this icon again, the device will stop vibrating and enter the standby state, and the APP icon will also stop flashing.

Use a 5V output charger to charge, and use the complimentary DC charging cable to connect the charger to the product. When charging, the indicator blinks, and when it is full, the indicator goes off. If the product is fully charged, please disconnect the charging cable in time.

Product use precautions:

1. Fully charge when first used.
2. Do not use while charging.
3. It's better to use a lubricant.
4. Don't soak in water for a long time.
5. If you feel uncomfortable, stop using it.
6. For the sake of your health, don't share with others.

Cleaning and storage

Clean the vibrator before and after each use

A quality water-based solution is the most reliable option, if not available, wash with warm water and antibacterial soap.

Rinse with water and dry with a lint-free cloth or towel.

Do not place the product in boiling water.

Store the product in a dry and ventilated place, away from sun exposure.

Keep products out of reach of children.

Quality guarantee

The quality of the product is guaranteed for 6 months, except for defects caused by human damage and improper operation. If you have any questions about our products, please contact the SEXBAY Support team directly at support@gd-sexbay.com.

Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed

to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.