



W2

SMART WATCH

Quick Start Guide

Styled Minimalism & Discover Smart Life

Functions:



Timekeeping



Call reminder



Remote camera



Pedometer



Sleeping monitor



Sedentary reminder



Alarm clock

Bluetooth :



Android 4.3 or above



IOS 7.0 or above

Parameters:

NO	Item	Parameters
1	Specifications	Case Diameter : 41.0mm
		Thickness: 10.3mm
		Material: 316L fine steel
3	Functions	BLE Bluetooth 4.0
		Analog Timekeeping
		Exercise & Sleeping monitor
		Remote camera
4	Battery life	Call, Sedentary & Alarm reminder
		Timekeeping: 3 years
		Electronic features: 3 months
5	Waterproof	30m under water

Operation :



Bluetooth connection

Based on Bluetooth 4.0 or above mobile devices, It can be connected easily.



APP Views and settings

Viewing and setting functions & data through ELE APP, and the date will be preserved for 7 days only.

Accessories:


What's Included:
1 x Smart watch
2 x Standard button cell.
1 x Special screwdriver

APP installation:

"ELE" APP is the mobile terminal management software for ELE Watch. After installing it, you can manage the watch on your phone, check health data report and sleeping analysis. Please choose appropriate QR code to download it..



Scan the QR code to download APP



- ① ON/OFF
- ② Settings
- ③ View and Mode switch
- ④ Light for Mode checking
- ⑤ Light for Sedentary reminder
- ⑥ Light for Call reminder
- ⑦ Light for Exercise checking

Button & LED light

Power on --- Press the button ① for 3 seconds.

When press power button, the lights for exercise will light one by one for 1 second, then all will extinguish.

Power off --- Press the button ① for 3 seconds.

When long press the power button, the lights for exercise will flash for 3 second, then you need to release the power button and press it again. Next, the 10 lights for exercise will extinguish one by one.

Bluetooth Connection: --- single press the button ①.

The first time to connect the watch to your phone through the Bluetooth, you need to: single press the button ①, then the watch will enter the Bluetooth mode. Then enter the ELE APP on your phone and click the "Device-bound" button in the Device page. And if you don't unbind the device, the watch will connect to it once they are at effective connection distance.

Mode checking --- single press the button ①.

When single press the power button, the light for Mode checking will light. It might have 3 colors.

Blue Sleeping mode.

Green Exercise mode or updating mode.

Red Low battery.

Exercise mode switch --- single press the button ①.

Exercise mode --- Sleeping mode: Press Button ③ for 3 seconds.
Sleeping mode --- Exercise mode: Press Button ③ for 3 seconds.

View the amount of exercise --- single press the button ①.

One light stands for 10%. When you finish the exercise task, all ten lights will light and flash for 3 seconds.

Remote camera --- Signal press any button.

With the phone camera on, you can take pictures by signal pressing any button.


OTA.

You will receive the OTA reminder in the ELE APP

Low battery reminder.

Signal press any button, the light for Mode checking is red and flashes for 2 seconds.

How to replace battery



1. Reverse your watch on a flat surface and unscrew the 4 screws on the back cover with special screwdriver.
2. Take apart the back cover and remove the old button cell.
3. Insert the new button cell into the watch with the negative cathode side down.
4. Seal the cover and tighten the screws.
5. Open ELE APP and connect it to your watch to finish the battery change.

(Note: ★Waterproof rubber ring must be installed in the slot while replacing battery.)

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

ELE W2 Smart Watch

ELEPHONE COMMUNICATION TECHNOLOGY CO.,LTD
OFFICIAL WEBSITE: WWW.ELEPHONE.HK
Scan the QR code on the right for more ELEPHONE information.

