


Charging

Connect the USB cable to the SmartShaker 3 and plug the other end of the USB cable to any USB wall adapter. The LED light should blink white. After charging full (all LED off or solid on), you can detach the USB cable.



Set Up

1. Open the Android App.
 - Directly click "Get Started" and then click "Next", "Next" till you will see below screens.



- Just wait for around 10 seconds. Then, you will see the below screen. Just click Next to go ahead.

11:12




You're all set!


SmartShaker 3 is **successfully**
connected.

NEXT


2. Then you will see below screen. Click the button at the right bottom corner. If there is any prompt asking you to accept location or Bluetooth access, just click okay. If the app close, open it again and you will see the below screen again. Click the button at the right bottom corner again.




3. At this moment, make sure the slide switch is at on position. Press and hold snooze button for 10s on the device. Then you see should see LED light blink blue and then you can release the snooze button.



- Click the button at the right bottom corner again. Then, you should see “SmartShaker 3” as below, click connect. Then, the device should vibrate once. If you have too many devices nearby, you will see multiple “SmartShaker 3”. In this case, try to take away those SmartShaker 3 device that you will not want to test.




- Then, you will see below screens. Click the button in the red dotted rectangle as below.




6. Then, you will see below screens. Click the red dotted button as below.



7. Then, you will see below screen.




8. Just scroll down the screen. You will see below.




9. Click "Msg in". Then, the device will vibrate once.

10. Click “Incoming Call”, the device will vibrate continuously. You can click “Call End” or the snooze button on the device to stop the vibration.



Note: if the device is disconnected during testing,click “Msg in” and “Incoming Call” will not have vibration effect. please click the “Connect” button at the top right corner to connect again. Then, please repeat steps 5 -10.



If you close the app and want to test it next time, just start from step 4 again.








If you encounter continuous connection problem, please go to Bluetooth setting menu to remove the pairing record and start again from step 2.

On



Make sure the device you want to connect to is in pairing mode. Your phone (Galaxy A7) is currently visible to nearby devices.

Paired devices

- SmartShaker3 
- iLuv BBGUMTWS AIR 
- iLuv BBGUMTWS AIR 
- TOZO-T10 
- SmartShaker2 
- iPhone 
- George Chung's iPhone 

Available devices

- 客厅的小米盒子

Rename
SmartShaker3

Unpair



FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.