



# KinectIQ-Pro Tx and KinectIQ-Pro BT Dongle

## User manual

### Product Appearance




### Features



- ① HDMI connector : Connect to HDMI OUT port of laptop or PC
- ② Micro-USB port : Charge transmitter using USB cable
- ③ Power switch : Power ON/OFF
- ④ Transmit button : Start transmission (and click to end transmission)  
Switch to this transmission (when using multiple transmitter).
- ⑤ Status LED (device connected)
  - Purple : System booting
  - Blue : Ready to stream
  - Blue (blinking) : Video streaming
  - Red : HDMI pairing error
- ⑥ Low Battery LED
  - Orange : Low battery
- ⑦ Charging LED
  - Red : Currently charging
- ⑧ KinectIQ-Pro BT Dongle: Connect to USB port of laptop or PC where Transmitter is connected

## Installation




- ① Remove the Touch USB Dongle from the Transmitter.
- ② Insert the Dongle into the USB In port of your laptop or PC.
- ③ Connect the Transmitter to the HDMI out port of laptop or PC.  
Use the HDMI extension cable provided if needed.
- ④ Slide the power switch to the left to turn power ON and the Status LED will be lit in blue.
- ⑤ Press the Transmit button and an image will appear on the display device of which the Receiver is installed.

- If multiple Transmitters are connected, the corresponding screen of the Transmitter that has just been clicked will appear, as part of the product's integrated switching function.

**For first use : please find the instructions to pair transmitter with receiver in the User Manual of the Receiver.**

## Recharging



- Please charge Transmitter when you see orange light on status LED or when power does not turn on.

- Use provided USB cable and connects it to USB port of laptop or PC. Or you can use additional adapter (5V/2A) for charging. Transmitter must be turned off while charging.
- ① Red light will show on Status LED when Transmitter is being charged, and the light will be gone after charging is finished.

- Charging time may vary depending on the current. If you are charging with an adapter of 5V/2A, it takes about 2 hours 30 minutes for full charge when the battery is empty.

## Notice

The distance available for wireless application may vary depending on the user environment. The wireless device in use may be subjected to radio interference during operation. The screen in part may not show if the aspect ratio of image being replayed does not match with that of the monitor.

Turn power OFF of the product and of the Transmitter when not in use.

### Specification

**KinetIQ-Pro TX**  
Frequency range: 5180~5220, 5745~5825MHz

HW Version: 0.1

Software Version: 17.1.24

Operating Temperature: 0~40°C

**KinetIQ-Pro BT Dongle**

Frequency range: 2402~2480MHz

HW Version: 0.3

Software Version: 16.6.9

Operating Temperature: 0~40°C

# Notice

---

## **This device comply with part15 of FCC rules.(FCC Part 15.19(a))**

Operation is subject to the following two conditions:

This device may not cause harmful interference.

This device & its accessories must accept any interference received, including interference that may cause undesired operation.

### Class B digital device or peripheral (FCC Part 15.105)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. --
- Consult the dealer or an experienced radio/TV technician for help.

Caution (FCC Part 15.21) : Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### RF EXPOSURE

This device complies with RF exposure requirement.

Cet appareil est conforme à l'exigence d'exposition RF.

## Caution

Product: KinetIQ-Pro TX

This device is restricted to indoor use only within the 5.15 ~ 5.25GHz Band.

Cet appareil est restreint à l'utilisation à l'intérieur seulement dans la bande 5.15 ~ 5.25GHz.

# Notice

---

This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radio électrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.