

EXHIBIT C

[Ref: RSP-100 2.4(a)]


" User Manual "

DENON

REMOTE CONTROL UNIT

RC-8000

OPERATING INSTRUCTIONS
MODE D'EMPLOI



FOR ENGLISH READERS PAGE 2 - PAGE 33
POUR LES LECTEURS FRANCAIS PAGE 34 - PAGE 65

"SERIAL NO. _____
PLEASE RECORD UNIT SERIAL NUMBER ATTACHED TO THE REAR OF THE CABINET FOR
FUTURE REFERENCE"

"NO. DE SERIE _____
PRIERE DE NOTER LE NUMERO DE SERIE DE L'APPAREIL INSCRIT A L'ARRIERE DU
COFFRET DE FAÇON A POUVOIR LE CONSULTER EN CAS DE PROBLEME."

Changes or modifications not expressly approved by the manufacturer for compliance could void the user's authority to operate the equipment.

- We greatly appreciate your purchase of this unit.
- To be sure you take maximum advantage of all the features this unit has to offer, read these instructions carefully and use the set properly. Be sure to keep this manual for future reference should any questions or problems arise.

This device complies with Part 15 of the FCC Rules and Industry CANADA RSS210. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

TABLE OF CONTENTS

1 Features.....3	5 Other Registerable Devices25
2 Before Using3	6 Customizing
3 Names of Parts4	(setting the operating environment).....26-31
4 Operation4-24	Editing the icon display section26-28
Introduction4, 5	[1] Adding devices26
[1] Turning on the liquid crystal display.....4	[2] Deleting devices26
[2] Adjusting the brightness of the	[3] Changing the positions of devices
liquid crystal display4	in the icon display section27
[3] Adjusting the touch panel.....5	[4] Registering device names28
[4] Basic operation of the	Customizing the Buttons.....29, 30
liquid crystal display5, 6	[1] Adding buttons29
Operating preset devices6-10	[2] Deleting buttons29
Preset Memory10-17	[3] Moving buttons29, 30
[1] Changing the preset memory	[4] Changing button names30
of preset devices12	User Menu31
[2] Adding new devices13	7 One-button Search Function31, 32
[3] Operating devices for which the	[1] Using the one-button search function ...31, 32
preset memory is set.....14-17	8 RF Transmission Function32
Learning Function18-19	9 Factory Default Settings.....32
[1] Using the learning function18, 19	10 Specifications32
[2] Inputting button names19	11 Cautions on Use33
System Call Function20-22	12 Troubleshooting33
[1] System call buttons20	
[2] Storing system call signals20, 21	
[3] Editing registered system call settings ..21, 22	
[4] Deleting registered system call settings22	
[5] Sending system call signals.....22	
[6] Changing the names of	
system call settings22	
Making the Various Settings23, 24	
[1] Backing up the current settings23	
[2] Making the sound settings23	
[3] Setting the liquid crystal display's	
auto off time23	
[4] Setting the back light's auto off time24	
Resetting24	

1 FEATURES

The RC-8000 can be used for integrated control of remote controllable devices connected to an AV amplifier (for example TV sets and DVD players) as well as remote control compatible peripheral devices (for example lighting equipment and power screens).

Icons are registered for 20 types of devices, and presettings are available for 14 of these device types. (Of the device types for which presettings are registered, six are for Denon products only).

Devices for which no presettings are registered can be operated using the learning function.


In addition, system call settings can be made to operate multiple devices at once in a "macro" sequence.

- 1. Large liquid crystal touch display**
320 x 240 dot liquid crystal display with EL back light.
- 2. Preset memory function**
Easy memory presetting thanks to a preset memory search function (1-button search).
- 3. System call function**
Up to 20 system call settings (10 codes per setting) can be registered.
Delay times can be set between the transmission codes.
- 4. Customizing function**
Up to 23 extra devices to be used can be registered additionally, and buttons can be moved and their names changed for easier use.
- 5. User menu function**
The user menu settings can be used to register frequently used buttons on a single page and this page can always be displayed first.
- 6. User backup function**
Customized settings can be backed up so that set data is not lost.
- 7. Learning function**
The remote control signals of your devices can be stored ("learned") in the RC-8000, so all your equipment can be operated using the RC-8000.
Approximately 200 codes can be learned.
- 8. RF transmission function (only when the RC-8000 and RC-8001ST are used in combination)**
RF transmission is possible when the RC-8000 is used in combination with the RC-8001ST.
- 9. Charging function (only when the RC-8000 and RC-8001ST are used in combination)**
When using the nickel cadmium battery included with the RC-8001ST, the RC-8000 can be charged on the RC-8001ST.
- 10. USB update function**
In the future the RC-8000 will allow customizing and updating of remote control signals on a personal computer through connection to the computer using the USB connector.
(A separately available PC application program is required.)


2 BEFORE USING

Loading the LR6 (AA size) alkaline batteries


- ① Slide the battery cover on the rear of the RC-8000 to remove it.



- ② Insert the included alkaline batteries, being careful to do so in the proper direction.



- ③ Close the battery cover.



Notes on Batteries

- Use LR6 (AA size) alkaline batteries in the remote control unit.
- The batteries should be replaced with new ones approximately once a year, though this depends on the frequency of usage.
- Even if less than a year has passed, replace the batteries with new ones if the set does not operate even when the remote control unit is operated nearby the set. (The included battery is only for verifying operation. Replace it with a new battery as soon as possible.)
- When inserting the batteries, be sure to do so in the proper direction, following the "⊕" and "⊖" marks in the battery compartment.
- To prevent damage or leakage of battery fluid:
 - Do not use a new battery together with an old one.
 - Do not use two different types of batteries.
 - Do not short-circuit, disassemble, heat or dispose of batteries in flames.
- Remove the batteries from the remote control unit when you do not plan to use it for an extended period of time.
- If the battery fluid should leak, carefully wipe the fluid off the inside of the battery compartment and insert new batteries.
- When replacing the batteries, have the new batteries ready and insert them as quickly as possible.
- The learned remote control signals may be cleared if no batteries are in the remote control unit for about 5 seconds.
The factory-installed codes are in permanent memory, however.