### 8. OPERATIONAL DESCRIPTION - MODEL Axcera-LU5000AT

### 8.1 General Description

The LU5000AT is a complete 5000-watt UHF solid-state, internally diplexed television transmitter. It operates at a nominal visual output power of 5000 watts peak sync and an average aural output power of 500 watts, at an A/V ratio of 10 dB, 10% sound.

## 8.2 Technical Specifications

	Type of Emissions:  Visual
	Frequency Range470 MHz to 860 MHz (any 6-MHz channel)
	Output Power Visual
	Maximum Power Rating Visual
	Power Consumption
8.3 Perfo	rmance Specifications
	<u>Visual Performance</u>
	Operating Frequency Range
	RF output - Nominal:  Power
	Visual Sideband Response: -1.25 MHz and below20B -0.75 to -0.5 MHz+0.5, -2.0dB -0.5 MHz to +3.58 MHz±0.5 dB 3.58 MHz to 4.18 MHz+0.5, -1.0 dB
	Variation of Frequency Response with Brightness



Signal-to-Noise Ratio       55 dB         2t K-Factor       2%         Harmonic Radiation       -60 dB         Spurious (>3 MHz from channel edge)       -50 dB         Carrier Frequency Stability       ±1000 Hz
<u>Aural Performance</u>
Frequency Deviation Capability (Transmitters)       ±75 kHz         Distortion       0.5%         FM Noise       -60 dB         AM Noise       -55 dB         Visual to Aural Separation       4.5 MHz, ±100 Hz
Composite Audio Input (Multi-channel sound - Transmitters) Input Level
Frequency Range: $\pm 0.1$ dB Response
Monaural Audio Input (Transmitters):  Input Level
Subcarrier Audio Input (Transmitters):  Input Level
Electrical Requirements
Power Line Voltage
<u>Environmental</u>
Maximum Altitude
<u>Mechanical</u>
Dimensions:  Width



1305715

### 8.4. System Overview

The LU5000AT (1304276) is made up of the trays listed in Table 8-1.

MAJOR ASSEMBLY TRAY/ASSEMBLY NAME **DRAWING NUMBER DESIGNATOR UHF Exciter Assembly** 1302065 Α1 Α2 **External Amplifier Assembly** 1304276 1304276 External Amplifier Assembly А3 External Amplifier Assembly 1304276 Α4 Α5 External Amplifier Assembly 1304276 Α6 External Amplifier Assembly 1304276

Optional Exciter Switcher

Table 8-1. LU5000AT Major Trays and Assemblies

### 8.4.1 Exciter Tray/External Amplifier Tray

The output of the Exciter Tray (driver) drives the input to the External Amplifier Tray.

### 8.4.1.1 Modulator Module (Exciter)

Α7

The (A2) Modulator Assembly contains the Modulator Board (1301797). The modulator is broadcast quality and provides front panel access to control and monitoring points. The video level is controlled through a sync tip clamp and sync and white clipping circuitry. The IF oscillator is oven controlled and locked to a 10 MHz reference for stability. The IF signal is fed through a SAW filter for precise sideband shaping. The Modulator operates using either the baseband audio and video inputs or the 4.5-MHz composite input to produce a diplexed, modulated, and on-channel frequency visual + aural RF output that is cabled to the IF Processing Module.

#### 8.4.1.2 IF Processor Module (Exciter)

The (A3) IF Processor Assembly contains the IF Processor Board (1301977). The IF Processor provides pre-correction to ensure broadcast quality output signal. The pre-correction consists of amplitude linearity correction, Incidental Carrier Phase Modulation (ICPM) correction and frequency response correction.

The IF Processor module is configured either for an analog or digital system. Pin 13C of the IF Processor module is grounded in analog systems and left not connected in digital systems. An IF Processor Interlock signal is used to report the presence of the IF Processor module to the Control Monitoring board. If the IF Processor interlock signal is not present, the Pioneer 100 Watt Transmitter/Exciter Driver RF output is Muted (turned off). If an analog IF Processor module is installed and the Modulation Present signal is not true, the Pioneer 100 Watt Transmitter / Exciter Driver output is Muted (turned off).

The Control & Monitoring/Power Supply module uses the IF Processor module for System output power control. Through the front panel display or a remote interface, an operator can set the transmitter's RF output power. The range of RF power adjustment is between 0% (full off) and 105% (full power plus). A front panel IF Processor module potentiometer sets the upper limit of RF power at 120%. The system's Control Monitoring board compares the RF Power Monitoring module RF power level with the desired level and uses the IF Power Control PWM line to correct for errors.



In digital systems, a digital level control (DLC) voltage is generated on the IF Processor module and sent to an external digital modulator (DT1C or DT2B). RF power control is implemented by changing the DLC voltage provided to the external digital modulator. The 'RF High' potentiometer sets the upper adjusted range of RF control circuit output to 120%.

The IF Processor module provides a reference ALC voltage to the system's Upconverter. When the ALC voltage decreases, the Upconverter automatically lowers the system output power through the AGC circuits.

The IF Processor module has a front panel switch to select Auto or Manual ALC. When Manual ALC is selected, the reference ALC voltage is set by a front panel potentiometer. In this condition, the RF power level control circuit is removed from use. When the ALC select switch is changed to Auto, the RF power level control circuit will start at low power and increase the RF output until the desired output power is attained.

The IF Processor module Modulation Present signal is monitored. If the modulation level is too low or non-existent, a Modulation Present fault is reported to the Control Monitoring board. When the controller detects this fault, it can be set to Automatically Mute the transmitter or in Manual mode the transmitter will continue to operate at 25% output.

The IF Processor module Input Signal level is monitored. If the signal level is too low or non-existent, an Input fault is reported on the Control Monitoring board. When the IF Processor board detects an Input Signal fault it automatically Mutes the transmitter. The system controller does not Mute on an IF Processor Input fault.

### 8.4.1.3 UHF/VHF Upconverter Module (Exciter)

The VHF/UHF Upconverter Module Assembly contains (A1) a Downconverter Board Assembly (1303834), (A3) a First Conversion Board, LX Series (1303838), (A2) a L-Band PLL Board, LX Series (1303846) and (A4) an Upconverter Control Board (1304760).

A 0 dBm 44 MHz IF input to the upconverter through the backplane board is applied to a mixer mounted on the first conversion board. Also applied to the mixer is a nominal 1 GHz LO1. The mixer converts it to a nominal frequency centered at 1044 MHz. A filter selects the appropriate conversion product, which is then amplified to a level of approximately -4 dBm. The frequency of the first conversion LO1 can be shifted by  $\pm$  10 kHz to generate channel offsets of 10kHz. For +offsets the frequency is 999.99 MHz and for -offsets the frequency is 1000.01 MHz.

This signal is applied to a second mixer mounted on the downconverter board that converts it back to a broadcast channel (2-69) by an LO2 that operates in 100kHz steps between 1.1-1.9 GHz depending on the channel selected. The LO2 frequency equals the Channel center frequency plus the LO1 frequency plus 44 MHz. (As an example CH14+: Center Frequency is 473.01 MHz and LO1 is 999.99 MHz therefore LO2 is 473.01 + 999.99 + 44, which equals 1517.00 MHz.)

The output of the mixer is applied to a 900 MHz Low pass filter to remove unwanted conversion products. The resulting signal is amplified and applied to a Pin diode attenuator before it is connected to the output of the upconverter. This pin diode attenuator adjusts the gain of the module and is controlled by an Automatic Gain Control



circuit, which maintains a constant power out of the upconverter, and also the transmitter, that connects to the power amplifier module.

# 8.4.1.4 Control & Monitoring / Power Supply Module (Exciter)

The (A4) Control & Monitoring/Power Supply Assembly is made up of a Control Board (1302021), a Power Protection Board (1302837) and a Switch Board (1527-1406). The Assembly also contains a switching power supply that provides  $\pm 12$  VDC to the rest of the modules in the chassis and  $\pm 32$  VDC to the Power Amplifier module.

The Assembly provides all transmitter control and monitoring functions. The Front panel LCD allows monitoring of system parameters, including forward and reflected power, transistor currents, module temperatures and power supply voltages.

### 8.4.1.5 Power Amplifier Module (Exciter)

The (A6) Power Amplifier Module Assembly is made up of a Coupler Board Assembly (1301949), an Amplifier Control Board (1301962), a 1-Watt Module Assembly (1302891), a TFS 40W UHF Module (1206693) and a RF Module Pallet, Philips (1300116).

The Power Amplifier Module contains Broadband LDMOS amplifiers that cover the entire UHF band with no tuning required. They amplify the RF to the 10W to 50W output power level of the transmitter.

The Power Amplifier of the Transmitter/Exciter Driver is used to amplify the RF output of the Upconverter module. A cable, located on the rear chassis, connects the RF output from the LO/Upconverter at J23 to J24 the RF input to the PA Assembly. This module contains RF monitoring circuitry for both an analog and a digital system. Control and monitoring lines to the Power Amplifier module are routed through the floating blindmate connector of the Control & Monitoring/Power Supply module.

The 50-Watt Transmitter/Exciter Driver Power Amplifier module and any External Amplifier modules contain the same control and monitoring board. This board monitors RF output power, RF reflected power, the current draw of amplifier sections, the supply voltage, and the temperature of the PA heat sink.

The RF power detector circuit outputs vary with operating frequency. These circuits must be calibrated at their intended operating frequency. Front panel adjustment potentiometers are used to calibrate the following:

Table 1: Power Amplifier Calibration Adjustments in Analog Systems

- R201 Reflected Power Cal
- R202 Visual / Forward Power Cal
- R203 Aural Power Cal
- R204 Visual Offset Zero
- R205 Aural Null

In analog systems, the Aural power of an Exciter Driver Power Amplifier and the Aural power of any external amplifier will not be reported by the system Control Monitoring module. Additionally the Visual power of these amplifiers, is reported as Forward Power just like in digital systems. In analog systems, aural and visual power will only be reported for the final system RF output.



In digital systems, the Forward power of an Exciter Driver Power Amplifier and the Forward power of any external amplifier, is reported by the system Control Monitoring module.

If the Control Monitoring module is monitoring a 5-50 Watt Transmitter, system power is measured in the Power Amplifier module. The wired connections are transferred through the power supply connector to the backplane board on a five position header.

All four positions of control board switch SW1 must be set on to route these lines as the system's RF power signals. In systems of output power greater than 50 Watts, system power is monitored by an external module that is connected to TB31 and control board SW1 switches must be set off.

The Forward Power of the Transmitter/Exciter Driver Power Amplifier module is routed to the Upconverter module as AGC #1. A system over-drive condition is detected when this value rises above 0.9 VDC. When an over-drive condition is detected, the Upconverter module reduces its RF output level. For values less than 0.9 VDC, the Upconverter uses this voltage for automatic gain.

## 8.4.1.6 Power Amplifier Module (External Power Amplifier Assembly)

The Power Amplifier Module Assembly is made up of (A6) an Amplifier Control Board (1301962), (A1) a UHF Phase/Gain Board (1303213), (A2) a 150 Watt Driver Pallet Assembly (1303293), (A3 & A4) two RF Module Pallets, Philips (1300116), and (A5) a 2-Way Combiner Board (1303208).

The Power Amplifier Module contains Broadband LDMOS amplifiers that cover the entire UHF band with no tuning required. Each module amplifies the RF to a nominal 300W output power.

The Power Amplifier assembly is used to amplify the RF output of the Transmitter/Exciter Driver. A cable, located on the rear chassis, connects the RF output from the Exciter/Driver at J25 to J200 the RF input to the PA Assembly. This module contains RF monitoring circuitry for both an analog and a digital system. Control and monitoring lines to the Power Amplifier module are routed through the floating blindmate connector of the Control & Monitoring/Power Supply module.

The 100-Watt Transmitter/Exciter Driver Power Amplifier module and any External Amplifier modules contain the same control and monitoring board. This board monitors RF output power, RF reflected power, the current draw of amplifier sections, the supply voltage, and the temperature of the PA heat sink.

The RF power detector circuit outputs vary with operating frequency. These circuits must be calibrated at their intended operating frequency. Front panel adjustment potentiometers are used to calibrate the following:

Table 2: Power Amplifier Calibration Adjustments in Analog Systems

- R201 Reflected Power Cal
- R202 Forward Power Cal
- R204 Meter Offset Zero



In analog systems, the Aural power of an Exciter Driver Power Amplifier and the Aural power of any external amplifier will not be reported by the system Control Monitoring module. Additionally the Visual power of these amplifiers, is reported as Forward Power just like in digital systems. In analog systems, aural and visual power will only be reported for the final system RF output.

In digital systems, the Forward power of an Exciter Driver Power Amplifier and the Forward power of any external amplifier, is reported by the system Control Monitoring module.

If the Control Monitoring module is monitoring a 5-50 Watt Digital or 10-100 Watt Analog Transmitter, system power is measured in the Power Amplifier module. The wired connections are transferred through the power supply connector to the backplane board on a five position header. All four positions of control board switch SW1 must be set on to route these lines as the system's RF power signals. In systems of output power greater than 50 Watts digital or 100 Watts aural, system power is monitored by an external module that is connected to TB31 and control board SW1 switches must be set off.

The Forward Power of the Transmitter/Exciter Driver Power Amplifier module is routed to the Upconverter module as AGC #1. A system over-drive condition is detected when this value rises above 0.9 VDC. When an over-drive condition is detected, the Upconverter module reduces its RF output level. For values less than 0.9 VDC, the Upconverter uses this voltage for automatic gain.

## 8.4.1.7 Power Supply Module (External Power Amplifier Assembly)

The Power Supply Module Assembly is made up of (A1) a +32V/2000W Switching Power Supply and (A2) a  $\pm 12V/40W$  Switching Power Supply.

The power supply module provides the +32 VDC and the +12 VDC and -12 VDC to the power amplifier module assembly.

### 8.4.1.8 Optional Exciter Switcher

The Single Channel Auto Switcher consists of (A1) a Single Channel Exciter Switcher Tray (1305715) with a separate (A2) coaxial transfer relay, mounted on a bracket that faces toward the rear of the cabinet, behind the Switcher Tray. The Exciter Switcher Tray is designed to monitor the selected On Air Exciter and automatically switch to the back up Exciter if the On Air Exciter should malfunction. The coaxial relay has the RF outputs from both Exciters connected to its inputs and, depending on if the energizing voltage is applied or not, the selected Exciter RF Output is connected to the external amplifiers and the RF output from the other exciter is connected to a load.

Functionally the Single Channel Exciter Switcher Tray contains an Exciter Switcher Control Board (1305704), which provides the monitoring of the operation of both Exciters and the control of the automatic switching of the Exciters in case of malfunction in the On Air Exciter. ICs on the board monitor the operating parameters of the Exciters and determine if the Exciters are functioning properly. The front panel of the Exciter Switcher has an LCD display, which provides set up screens for the operation of the switching process.



The coaxial relay has four "N" connectors that provide input and output connections to the relay. The RF Output from Exciter "A" connects to J21. The RF Output from Exciter "B" connects to J23. The Selected Exciter RF Output to the external amplifiers connects to J24. The Exciter "A/B" Load connects to J22, to which the RF output of the Off Air Exciter is connected. A wire harness connects to the relay from J14 on the Exciter Switcher Control Board. These connections provide the control voltages to the relay from the control board and status indication connections back to the control board.

### 8.5 Control and Status

### 8.5.1 Exciter Tray

Table 8-2. Modulator Front Panel Switch

SWITCH	FUNCTION
MAN/AUTO CLAMP	When Manual Clamp is selected, the video level is set by the Manual Bias Pot R67 located on the board. ( <b>NOTE</b> : The pot is factory set and needs no adjustment by the customer).
SW1	When Auto Clamp is selected, the video level control circuit will automatically increase or decrease the video to maintain the desired video level.

Table 8-3. Modulator Front Panel Status Indicators

LED	FUNCTION
AUR UNLOCK	When lit it indicates that the 4.5 MHz VCO and the 10 MHz reference
DS5 (Red)	are not PLL locked.
VIS UNLOCK	When lit it indicates that the 45.75 MHz VCXO and the 10 MHz
DS6 (Red)	reference signal are not PLL locked.
AUD OV DEV	When lit it indicates the deviation level is more than ±80kHz
DS4 (Red)	when he is maleates the deviation level is more than ±80km2
VIDEO LOSS	When lit it indicates the Video Input to the transmitter is lost.
DS1 (Red)	when he it indicates the video input to the transmitter is lost.
OVER MOD	When lit it indicates the Video input level is too high.
DS3 (Red)	when he is the video input level is too night.
ALT IF	When lit it indicates that external or alternate 4.5MHZ is present.
DS7 (Green)	when he is mulcates that external or alternate 4.5MHZ is present.
10 MHz PRES	When lit it indicates that a 10MHz reference is present to the
DS2 (Green)	transmitter.

Table 8-4. Modulator Front Panel Control Adjustments

POTENTIOMETERS	DESCRIPTION
POTENTIOMETERS	DESCRIPTION
Video Gain (R42)	Adjusts the level of the output video.
Visual Level (R214)	Adjusts the Visual IF level that combines with the Aural IF.
Aural Level (R243)	Adjusts the Aural IF level that combines with the Visual IF.
MONO (R110)	Adjusts the deviation level of the balanced audio input.
STEREO (R132)	Adjusts the deviation level of the composite audio input.
SAP/PRO (R150)	Adjusts the deviation level of the subcarrier audio input.



Table 8-5. Modulator Front Panel Sample

SMA CONNECTOR	DESCRIPTION
MOD IF SAMPLE (J10)	Sample of the combined Aural IF and Visual IF signals.

Table 8-6. IF Processor Front Panel Switch

SWITCH	FUNCTION
	When Manual ALC is selected, the reference ALC voltage is set by the ALC Gain front panel potentiometer.
MAN/AUTO ALC	When Auto ALC is selected, the IF level control circuit will automatically increase the IF output until the desired output power is attained.

Table 8-7. IF Processor Front Panel Status Indicators

LED	FUNCTION
INPUT FAULT (Red)	When lit it indicates that there is a loss of the IF Input signal to the
	IF Processor. Transmitter can be set to Mute on an IF Input Fault.
	When lit it indicates that the required gain to produce the desired
ALC Fault (Red)	output power level has exceeded the operational range of the ALC
	circuit. The LED will also be lit when ALC is in Manual.
MUTE (Red)	When lit it indicates that the IF input signal is cut back but the
	enable to the Power Supply is present and the +32 VDC remains on.

Table 8-8. IF Processor Front Panel Control Adjustments

POTENTIOMETERS	DESCRIPTION
FREQUENCY RESPONSE EQUALIZER	These three variable resistors, R103, R106 & R274, adjust the depth of gain for the three stages of frequency response correction.
ALC GAIN	Adjusts the gain of the transmitter when the transmitter is in the Auto ALC position.
MAN GAIN	Adjusts the gain of the transmitter when the transmitter is in the Manual ALC position.
LINEARITY CORRECTION	These three variable resistors adjust the threshold cut in for the three stages of linearity pre-correction. R211 and R216, the top two pots, are adjusted to correct for in phase amplitude distortions. R 231, the bottom pot, is adjusted to correct for quadrature phase distortions.

Table 8-9. IF Processor Front Panel Sample

SMA CONNECTOR	DESCRIPTION
IF SAMPLE	Sample of the pre-corrected IF output of the IF Processor



Table 8-10. VHF/UHF Upconverter Front Panel Switch

SWITCH	FUNCTION
	When Manual AGC is selected, the reference AGC voltage is set by the AGC Manual Gain front panel potentiometer.
MAN/AUTO AGC (Left Manual, Right AGC)	When Auto AGC is selected, the RF power level control circuit will automatically increase the RF output until the desired output power is attained.

Table 8-11. VHF/UHF Upconverter Front Panel Status Indicator

LED	FUNCTION
PLL 1 Fault (Red)	When lit it indicates that the 1 GHz PLL is unlocked
PLL 2 Fault (Red)	When lit it indicates that the 1.1 –1.9 GHz PLL is unlocked
AGC Fault (Red)	When lit it indicates that the AGC is out of range.
AGC Override (Red)	When lit it indicates that the AGC is cutting back due to too much drive to the driver module.
Man Gain (Amber)	When lit it indicates that the AGC is bypassed in Manual.

Table 8-12. VHF/UHF Upconverter Front Panel Control Adjustments

POTENTIOMETERS	DESCRIPTION
MAN GAIN ADJ	Adjusts the gain of the upconverter and transmitter when in the
MAN GAIN ADJ	Manual AGC position.
AGC ADJ	Adjusts the gain of the upconverter and transmitter when in the
	Auto AGC position.
AGC CUTBACK ADJ	Adjusts the point at which the transmitter will cut back in power,
(AGC OVERRIDE)	due to too much drive, when the Transmitter is in Auto AGC.

Table 8-13. VHF/UHF Upconverter Front Panel Samples

SMA CONNECTOR	DESCRIPTION		
LO1 SAMPLE	Sample of the 1 GHz nominal LO1 signal in the Upconverter as		
	generated on the L-Band PLL Board.		
LO2 SAMPLE	Sample of the 1.1-1.9 GHz LO2 signal in the Upconverter as		
	generated on the First Conversion Board.		
RF SAMPLE	Sample of the On Channel RF Output of the Upconverter		

Table 8-14. Controller/Power Supply Display

DISPLAY	FUNCTION		
	A 4 x 20 display providing a four-line readout of the internal		
LCD	functions, external inputs, and status. See Chapter 3,		
	Controller/Power Supply Display Screens, for a listing of displays.		



Table 8-15. Controller/Power Supply Status Indicators

LED	FUNCTION		
OPERATE ( green )	When lit it indicates that the transmitter is in the Operate Mode. If transmitter is Muted the Operate LED will stay lit, the transmitter will remain in Operate, until the input signal is returned.		
FAULT ( red or green )	Red indicates that a problem has occurred in the transmitter. The transmitter will be Muted or placed in Standby until the problem is corrected.		
DC OK ( red or green )	Green indicates that the switchable fuse protected DC outputs that connect to the modules in the transmitter are OK.		

Table 8-16. Controller/Power Supply Control Adjustments

<b>POTENTIOMETERS</b>	DESCRIPTION	
DISPLAY CONTRAST	Adjusts the contrast of the display for desired viewing of screen.	

Table 8-17. Power Amplifier Status Indicators

LED	FUNCTION		
ENABLED (Green)	When lit Green, it indicates that the PA is in the Operate Mode. If a Mute occurs, the PA will remain Enabled, until the input signal is returned.		
DC OK	When lit Green, it indicates that the fuse protected DC inputs to the		
(Green)	PA module are OK.		
TEMP	When lit Green, it indicates that the temperature of the heatsink		
(GREEN)	assembly in the module is below 78°C.		
MOD OK	When lit Green, it indicates that the PA Module is operating and has		
(Green)	no faults.		

Table 8-18. Power Amplifier Control Adjustments

POTENTIOMETERS	DESCRIPTION		
RFL CAL	Adjusts the gain of the Reflected Power monitoring circuit		
VISUAL CAL	Adjusts the gain of the Visual / Forward Power monitoring circuit		
AURAL CAL	Adjusts the gain of the Aural Power monitoring circuit		
VISUAL ZERO	Adjusts the offset of the Forward Power monitoring circuit		
AURAL NULL Adjusts the offset of the Forward Power monitoring circuit base the Aural signal level			

Table 8-19. Power Amplifier Sample

DISPLAY	FUNCTION	
FWD SAMPLE	RF sample of the amplified signal being sent out the module on J25.	



# 8.5.2 External Power Amplifier Tray

Table 8-20. Power Amplifier Status Indicators (External Power Amplifier Assembly)

LED	FUNCTION		
ENABLED (Green)	When lit Green, it indicates that the PA is in the Operate Mode. If a Mute occurs, the PA will remain Enabled, until the input signal is returned.		
DC OK	When lit Green, it indicates that the fuse protected DC inputs to the		
(Green)	PA module are OK.		
TEMP	When lit Green, it indicates that the temperature of the heatsink		
(Green)	assembly in the module is below 78°C.		
MOD OK	When lit Green, it indicates that the PA Module is operating and has		
(Green)	no faults.		

Table 8-21. Power Amplifier Control Adjustments (External Power Amplifier Assembly)

POTENTIOMETERS	DESCRIPTION	
RFL CAL	Adjusts the gain of the Reflected Power monitoring circuit	
VISUAL CAL	Adjusts the gain of the Visual / Forward Power monitoring circuit	
METER ZERO	Adjusts the offset of the Forward Power monitoring circuit	

Table 8-22. Power Amplifier Sample (External Power Amplifier Assembly)

DISPLAY	FUNCTION	
FWD SAMPLE	RF sample of the amplified signal being sent out the module on J25.	

# 8.5.3 Optional Exciter Switcher Assembly

The Exciter Switcher Assembly contains an integrated LCD display and switch assembly (soft keys) that is used to display and set all exciter switcher parameters.



# 8.6 Remote Interface Connections

# **8.6.1 Remote Interface Connections (Exciter)**

Port	Туре	Function	Ohm
J1	IEC	AC Input	N/A
TB02	Term	Base Band Audio Input	600
J3	BNC	Composite Audio Input	75
J4	BNC	SAP / PRO Audio Input	50
J5	BNC	CW IF Input	50
J6	BNC	Modulated IF Input	50
J7	BNC	Video Input (Isolated)	75
J8	BNC	Visual IF Loop-Thru Output	50
J9	BNC	Aural IF Loop-Thru Output	50
J10	BNC	10 MHz Reference Input	50
J11	BNC	10 MHz Reference Output	50
J17	BNC	Video Loop-Thru (Isolated)	75
J18	BNC	Visual IF Loop-Thru Input	50
J19	BNC	Aural IF Loop-Thru Input	50
J23	BNC	Upconverter RF Output	50
J24	BNC	Power Amplifier RF Input	50
J25	N	Power Amplifier RF Output	50
TB30	Term	Remote Control & Monitoring	
TB31	Term	Remote Control & Monitoring	
J32	RJ-45	SCADA (Input / Loop-Thru)	CAT5
J33	RJ-45	SCADA (Input / Loop-Thru)	CAT5
J34	RJ-45	System RS-485 Serial	CAT5

# **8.6.2 Remote Interface Connections (External Power Amplifier Assembly)**

Port	Type	Function	Ohm
J220	Circular-3	AC Input #1	N/A
J221	Circular-3	AC Input #2	N/A
J200	N	Power Amplifier RF Input	50
J205	7-16	Power Amplifier RF Output	50
J232	RJ-45	System RS-485 Serial Input	CAT5
J233	RJ-45	System RS-485 Serial Output	CAT5



## **8.6.3 Optional Exciter Switcher Assembly**

Port	Туре	Function	Ohm
J1	IEC	AC Input	N/A
J21	N	Exciter A - RF Input (Channel 1)	50
J22	N	Exciter A/B - Load (Channel 1)	50
J23	N	Exciter B - RF Input (Channel 1)	50
J24	N	RF Output (Channel 1)	50
J31	N	Exciter A – RF Input (Channel2)	50
J32	N	Exciter A/B - RF Input (Channel 2)	50
J33	N	Exciter B – RF Input (Channel 2)	50
J34	N	RF Output (Channel 2)	50
Ј8	RJ-45	Exciter A – SCADA Serial I/O Port	CAT5
J9	RJ-45	Exciter A – System Serial I/O Port	CAT5
J10	RJ-45	Exciter B - SCADA Serial I/O Port	CAT5
J11	RJ-45	Exciter B - System Serial I/O Port	CAT5

## 8.7 AC Input

### 8.7.1 Exciter Tray

The AC input to the Exciter Tray is 117 VAC or 230 VAC (factory selectable). The AC input is applied to the tray through Jack J1. MOV's are provided to protect the Tray from transients or surges, which may occur on the AC Input Lines.

#### 8.7.2 External Power Amplifier Tray

The AC input to the Power Amplifier Tray is 230 VAC. The AC input is applied to the tray through Jacks J220 and J221. MOV's are provided to protect the Tray from transients or surges, which may occur on the AC Input Lines.

### 8.7.3 Optional Exciter Switcher Assembly

The AC input to the Optional Exciter Switcher Assembly is 117 VAC or 230 VAC (factory selectable). The AC input is applied to the tray through Jack J1.

#### 8.8 System Operation

When the transmitter is in operate, as set by the menu screen located on the Control & Monitoring Module in the exciter/driver assembly. The IF Processor will be enabled, the mute indicator on the front panel will be extinguished. The +32 VDC stage of the Power Supply in the Control & Monitoring Module is enabled, the operate indicator on the front panel is lit and the DC OK on the front panel should also be green. The enable and DC OK indicators on the PA Module will also be green.

When the transmitter is in standby. The IF Processor will be disabled, the mute indicator on the front panel will be red. The +32 VDC stage of the Power Supply in the Control & Monitoring Module is disabled, the operate indicator on the front panel will be extinguished and the DC OK on the front panel should remain green. The enable indicator on the PA Module is also extinguished.



If the transmitter does not switch to Operate when the operate menu is switched to Operate, check that all faults are cleared and that the remote control terminal block stand-by signal is not active.

The transmitter can be controlled by the presence of a modulated input signal. If the input signal to the transmitter is lost, the transmitter will automatically cutback and the input fault indicator on the IF Processor module will light. When the video input signal returns, the transmitter will automatically return to full power and the input fault indicator will be extinguished.

## 8.8.1 Principles of Operation

### **Operating Modes**

This transmitter is either operating or in standby mode. The sections below discuss the characteristics of each of these modes.

### **Operate Mode**

Operate mode is the normal mode for the transmitter when it is providing RF power output. To provide RF power to the output, the transmitter will not be in mute. Mute is a special case of the operate mode where the +32 VDC section of the power supply is enabled but there is no RF output power from the transmitter. This condition is the result of a fault condition that causes the firmware to hold the IF Processor module in a mute state.

#### **Operate Mode with Mute Condition**

The transmitter will remain in the operate mode but will be placed in mute when the following fault conditions exists in the transmitter.

- Upconverter is unlocked
- Upconverter module is not present
- IF Processor module is not present
- Modulator (if present) is in Aural/Visual Mute

### **Entering Operate Mode**

Entering the operate mode can be initiated a few different ways by the transmitter control board. A list of the actions that cause the operate mode to be entered is given below:

- A low on the Remote Transmitter Operate line.
- User selects "OPR" using switches and menus of the front panel.
- Receipt of an "Operate CMD" over the serial interface.

There are several fault or interlock conditions that may exist in the transmitter that will prevent the transmitter from entering the operate mode. These conditions are:

• Power Amplifier heat sink temperature greater than 78°C.



- Transmitter is Muted due to conditions listed above.
- Power Amplifier Interlock is high indicating that the amplifier is not installed.

### Standby Mode

The standby mode in the transmitter indicates that the output amplifier of the transmitter is disabled.

## **Entering Standby Mode**

Similar to the operate mode, the standby mode is entered using various means. These are:

• A low on the Remote Transmitter Stand-By line.

Depressing the "STB" key on selected front panel menus.

• Receipt of a "Standby CMD" over the serial interface.

## **Operating Frequency**

The LX Series transmitter controller is designed to operate on UHF frequencies. The exact output frequency of the transmitter can be set to one of the standard UHF frequencies, or it can be set to a custom frequency using software set-up menus. Since RF performance of the transmitter requires different hardware for different frequency bands, not all frequency configurations are valid for a specific transmitter. The Power detectors in the transmitter have frequency dependency, therefore detectors of power amplifiers are calibrated at their frequency of use. The detectors for System RF monitoring are also calibrated at the desired frequency of use.

