

## INSTALLATION

1. Mount the receiver on wall near grounded electrical outlet. Nail or screw head must extend at least 3/16" out from wall. Hang the receiver from slot on back of unit onto nail or screw. Plug the power supply cord of the receiver into outlet. Then plug device cord into the receptacle at bottom of the receiver.
2. Install battery into the transmitter.

## OPERATION

1. Press ON button on the transmitter to turn the receiver ON.
2. Press OFF button on the transmitter to turn the receiver OFF.

### 1.1. Connection Diagram of Test System

