

Aroma 40 Wireless handsfree manual

Instructions:

1. For first time use, please charge the both two units for 8hours.
2. Please switch your mobile phone to Auto-Receipt function.
3. Insert the plug of the Transmitter into the Adapter and connect the Transmitter with your mobile phone.
4. You can decide to use the Ear hook onto your right/ left ear according to your preference.
5. when receiving a call, pleased push the Switch and push again to turn off if you finish talking in order to economize power.
6. The Transmitter has Auto-Searching function. **LED** light will be turned off automatically in 60 seconds when you finish talking for economizing power.
7. **LED** light will turn green when talking and turn red when charging
8. When there's interference happening and becoming louder and louder, it means you will run out of power very soon and you can prepare for charging
9. Please do not use this product when charging .

Notice: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Model: AROMA 40

FCC ID:QJG AROMA 40H/40B

THIS DEVICE COMPLIES WITH PART 15 OF THE
FCC RULES. OPERATIONS IS SUBJECT TO THE
FOLLOWING TWO CONDITIONS :(1) HIS DEVICE
MAY NOT CAUSE HARMFUL INTERFERENCE AND
(2) HIS DEVICE MUST ACCEPT ANY INTERFERENCE
RECEIVED. INCLUDING INTERFEERENCE THAY MAY