

User Instructions

- (1) Place the booster in a suitable location and plug the 12V DC adaptor power cord into the power jack or cigarette socket.
- (2) Plug in the antenna and make sure to tighten it.
- (3) Connect one end of the cell phone adaptor cable to the booster where it is marked "Phone" and the other end to the cell phone antenna port.
- (4) Make sure all the connections are tight and secure, turn on the power switch. A green light will indicate the booster is ready to use.
- (5) Press any cell phone key to refresh its communication with the base station. Seconds later you should notice that the strength of the signal gets improved. Now you are ready to make and receive phone calls.

Note: It is normal for the booster box to be warm during operation.

Safety Warning: human body should always be separated at least 25 cm away from the antenna of the booster.

Warning: Changes or modifications not approved by CM technical specialist could void the warranty and cause health issues.

Troubleshooting:

During operation, if the booster interferes with your radio or other electronic reception, move the box away from the radio and other electronic equipments.

Consult a Cellphone-Mate technical specialist by sending email to help@Cellphone-Mate.com

www.Cellphone-Mate.com

1-888-365-MATE