

## **. User Manual**

Please follow the steps as below:

1. Plug the receiver into PC USB port before using, the red indicator shines means the connection between PC and receiver is OK.
2. Load the batteries to the mouse and click on the power switch then the optical LED will be lightened.
3. Click the mouse ID setting button, its optical LED will be darkened and the low power indicator (red color) will shine for once.
4. Click the receiver ID setting button, it will shine red slowly.
5. After ID setting of the mouse and receiver is finished, the red indicator of receiver will be quickly shining and then stop shining which shows that the connection between mouse and receiver is OK.
6. The red indicator of the receiver will shine while moving the mouse, and stop shining if mouse not moving.
7. When the batteries carry low power (2.0V~2.3V), the red low power indicator of the mouse will shine to remind users to change batteries.
8. After 8 minutes of not moving the mouse, its optical LED will be darkened (in sleep mode).
9. Users should click the mouse buttons or scroll if tend to wake it up from the sleep mode.

### **Warning:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by

turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications not authorized by the manufacturer may void users authority to operate this device.