

Wellmike

Two Way Baby Alert

Includes:

Transmitter (Half Moon Shape-TX) x 1PC

Receiver (Teddy Bear Shape-RX) x 1PC

Features:

- A compact, lovely Teddy Bear Shaped Two Way Baby Alert.
- Combines functions of Baby Locator and Baby Proximeter into one set of devices. It ' s a friendly-use alert for baby guard, especially in crowded spots, such as: stores, supermarkets, etc.

How to Use It

Battery Installation (Both TX and RX):

- Screw out the battery covers, follow the polarity to insert CR2032*2PCS and Screw back the covers.

TX & RX Get Activated

- First, switch ON the Half Moon Transmitter(TX). The Green LED flashes twice rapidly.
- Then slide the ON/OFF switch on the Teddy Bear Receiver (RX). You'll see a Red LED flash once a second following the Green LED 's two quick flashes. Press on the TX for 3 seconds, the Red LED stays on. When TX and RX get connected, the Green LED on RX flashes rapidly, followed by 3 BE.BE.BE. After the RX has been activated, the Green LED flashes once a second. The Alert has entered ARMED status.
- Attach the RX to your child's shoe loop or any other attachable places and carry the TX with yourself.

Functions of Proximeter

- When in ARMED status, the LEDs on both RX and TX will flash at intervals if they can find each other's signal. Otherwise, the RX will emit "BE..BE..BE.." every four seconds accompanied by 3 rapid flashes by Green LED, which means "YOUR BABY IS STEPPING OUT YOUR VIEW". The Beeps stop when your baby comes back within the distance that you allowed.

Functions of Baby Locator

- When the RX goes out of visible range, press the locator button on TX for more than one second. The Red LED illuminates and the RX attached to the child will response with 'BE-BE. BE.BE accompanied by Green LED flashing for 5 seconds. You can get trace of your baby by following the sounds, which will continue for 5 seconds.

Low Battery Indicator:

- On connected conditions, when either TX or RX's battery voltage drops to as low as 2.6V or even lower, there will be a short Bi at interval of 20 seconds, which remind you to change batteries.

Cautions:

- Due to the characteristics of RF technology, the Alert's working distance will be varied with different environments.
- Please turn off the RX&TX when not in use for a period of time.
- To avoid the TX& RX from being adjacent to metal objects, which might shorten the Alert 's working distance; When in use, the device is possible to be intervened by wireless signals neighborhood.
- When use the baby locator functions, make sure to press Locator button on RX for more than one second.
- Only Teddy Bear Receiver is Water Resistant. Keep the Half Moon Transmitter away from humidity.

Tips:

- To prevent signals from missing, keep the RX at distance from Human body.

FCC statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.