


QSWMCRC/QSWMC User's Manual


(VER:2.0)

OPERATION

1. Install the antenna of receiver.
2. Connect the power adaptor (5V/500mA) to the receiver (DC IN), indicator light turns on, refer to Fig ①、④.
3. Connect one end of the A/V cable to the receiver and the other to the monitor (yellow for video, white for audio). Set the monitor as A/V mode, refer to Fig①.



4. Connect the power transformer (7V/500mA) to the camera (Battery of the same voltage is acceptable).
5. Press the “CH” button of the receiver, image appears when choose the same channel as the wireless camera for the receiver. If the image is blurry, adjust the focus of the camera to make sure the received image is clear enough.



6. In case two or more channel need to be displayed synchronously, set the relative channel on, press “AUTO” button, the relative channels will enter recycling work state and the period is 6 seconds.
7. Recycling display setting: Press “Auto” button, indicator light flashes for 2 seconds, press the button “CH”, choose the channel to recycle, and finally press the “Auto” to save settings; Press “CH” again, choose the next channel till settings completed. Finally press “Auto” again to save settings, indicator lights flashes twice and recycling display starts.
8. Remote controller for receiver available. Buttons as follows:
Auto: recycle, CH1: channel 1, CH2: channel 2, CH3: channel 3, CH4: channel 4, SET: setting, ENTER: save settings.
Same functions as buttons on the receiver, refer to Fig②、⑤.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.