


# THE SLINGSHOT-LI-ION

**BF4081**



**User's Manual**

## Important Safety Instructions

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

### 1. Ventilation

The unit should be situated so that its location or position does not interfere with its proper ventilation. For example, it should not be situated on a bed, sofa, rug or similar surface that may block the ventilation openings. The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc. Also, it should not be placed in a built-in installation, such as a bookcase or cabinet, which may impede the flow of air through the ventilation openings, a minimum distance 20 cm around the apparatus for sufficient ventilations.

### 2. Heat & Flame

The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.

No naked flame sources, such as lighted candles, should be placed on the apparatus.

### 3. Cleaning

The unit should be cleaned only as recommended. See the section "Care and Maintenance" of this manual for cleaning instructions.

### 4. Attachments

Do not use attachments not recommended by the product manufacturer.

### 5. Damage Requiring Service

This unit should be serviced by qualified service personnel when:

- A. The unit has been dropped or the enclosure damaged.
- B. The unit exhibits a marked change in performance or does not operate normally.

### 6. Periods of Nonuse

If the unit is to be left unused for an extended period of time, such as a month or longer, take out the battery from the unit to prevent damage or corrosion.

### 7. Servicing

The user should not attempt to service the unit beyond those methods described in the user's operating instructions.

Service methods not covered in the operating instructions should be referred to qualified service personnel.

## Features

Thank you for purchasing the SLINGSHOT-LI-ION, a Bluetooth Shower Speaker.

The model incorporates following features:

- Playback mobile device, like iPad /iPhone/iPod Touch and smart phone music through Bluetooth technology
- Hands-free function for the incoming phone call
- Water resistant shower speaker
- Built-in rechargeable battery

iPad, iPhone and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.

Smart phone, iPad, iPhone and iPod models are not included.

## Installation

### Low Battery Status

While the battery voltage drops to a low voltage level, the unit may operate abnormally and “beep” tone will be sounded. In this case, the built-in battery is needed to recharge.

### Charging Battery (see Figure A)

The unit has built-in rechargeable battery.




Figure A

To recharge the battery, ① an USB cable with USB micro B type connector, plug the **Micro-USB** connector to the **Micro-USB port** located at rear of the unit. Connect the other end of the USB cable to a DC power supply source.

- Status LED indicator lights RED when the unit is charging.
- Status LED indicator will turn off (no red light) when the battery is fully charged.

### Mounting (see Figure B)

- ① - Snap the main unit into the rubber sling.
- ② - Hang the rubber sling with the unit in bath room





Figure B


## Description of Parts

### Main Unit

Front View



Rear View



1. Status LED Indicator



2. button

With the unit power off : Press and hold to turn on the unit.  
With the unit power on: Press to Play / Pause smart phone music.  
With the unit power on: Press and hold to turn the unit off.



3. button

In Bluetooth mode: Press to answer smart phone incoming call, the hands free function.



4. button

Adjust volume level up and down.



5. button

In Bluetooth mode: Skip tracks Forward / Backward

6. Microphone

Voice pick up in the hands free phone mode.

7. Speaker

8. Rear Cap

9. Micro-USB connector

10. RESET button

For resetting the unit


## Bluetooth Operation

The unit playback mobile device (for example: smart phone, tablet, iPad, iPhone and iPod Touch) music through Bluetooth operation.





### **Before you did the Bluetooth pairing / connection, following information will help:**

- (A) Whilst the unit is searching for Bluetooth device, the Blue LED indicator lights steadily.  
Whilst the unit paired/connected with a Bluetooth device, the Blue LED indicator blinks slowly.
- (B) The Bluetooth device name of this model: **Slingshot**


### **Pair / Connect a mobile device**

1. With the unit at power off mode, press and hold the Power  button for **around 3 seconds**.
2. (a) After the first 3 seconds, the unit will search for the last connected mobile device for around 5 seconds and connect it. **Note** : If you would like to connect other mobile device, turn off the Bluetooth function of the last mobile device and implement following step (b).  
(b) If the last connected mobile device is not available within the 5 seconds mentioned in (a) above, it will start searching other nearby Bluetooth device.
3. The Blue LED indicator lights steadily.
4. From the mobile device with its Bluetooth function turned on and it will also search for the nearby Bluetooth device.
5. From the Bluetooth device list of your mobile device, tap on Bluetooth device name "**Slingshot**" of this model for the connection.
6. Once the mobile device is connected with the unit, the Blue LED indicator blinks slowly.

### **Playback mobile device music**

7. Playback your mobile device music.
8. You may adjust both the volume control of your mobile device and the volume control  button of this unit to find the most desirable volume setting.
9. (a) You may tap the ► / || button from the mobile device (or the Play-Pause  button from the unit) to Play / Pause the mobile device music.  
(b) Press the   button to skip tracks backward / forward.


### **Hands-free phone call**

10. During Bluetooth music playback and an incoming call comes, press the Phone  button to answer the call.

To disconnect the call after the conversation, press the Phone  button again.

To redial the last outgoing telephone number (from telephone off mode), press the Phone  button twice.

### **Power off the unit**

11. In operation mode after listening the Bluetooth music, press and hold the Power  button for around 3 seconds to turn off the unit. Three tones (Do-Do-Do) will be generated and the Blue LED indicator will turn off.

### **Energy Saving Note**

In the case the Bluetooth communication link disconnected for around 5 minutes, the unit will power off automatically.

## Care and Maintenance


- Do not subject the unit to excessive force, shock, dust or extreme temperature.
- Do not tamper the internal components of the unit.
- Avoid leaving your unit in direct sunlight or in hot, humid or dusty places.
- Keep your unit away from heating appliances and sources of electrical noise such as fluorescent lamps or motors.

### Resetting the Unit

If the unit experiences a power surge or electric shock, it is possible that the internal micro-controller may lock up and the unit will not respond to any commands from the panel controls.

In this event, use a straightened paper clip, toothpick or similar objects to press the RESET button located at rear of the unit (see the below figure). The reset operation clears the system memory and all of your previous settings will be erased.

**CAUTION: DO NOT USE SHARP, POINTED OBJECT TO PRESS THE RESET BUTTON.  
IT MAY DAMAGE THE RESET SWITCH INSIDE THE UNIT.**



## Technical Data

<b>Built-in rechargeable battery:</b>	DC3.7V 1000mA Lithium battery
<b>Power supply for charging the internal battery:</b>	DC5V 500mA (through the USB connector)

## Compliance with FCC Regulations

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE :** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This Class [B] digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [\*] est conforme à la norme NMB-003 du Canada.



If at any time in the future you should need to dispose of this product please note that: Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice. (Waste Electrical and Electronic Equipment Directive).

**THE SPECIFICATION AND EXTERNAL APPEARANCE OF THE SET ARE SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.**