

## Thank you for choosing our electric baby carriage

Please read the manual before using this product, it will tell you the correct operation method and installation steps. To avoid incorrect operation of the product and damage or injury to your baby. This manual shall be properly kept and kept in an accessible place,

## Specifications


Storage battery	12V7AH
Motor	12V550*2
Applicable Age	For children aged 37–95 months
Maximum load	30kg
Dimensions	133x90x82.5CM
Speed	3–8km/h
Charger	Input: 100V–240V Output: 12V1000mA
Usage time	Charge for 10–12 hours. Use for 1–2 hours

## Charging points

1. When using an electric car for the first time, the battery must be fully charged for 16 hours! Otherwise the battery will be permanently damaged and beyond repair. The charging timeshould not exceed 18 hours.
2. When charging, first plug the charger DC into the charging socket, and then plug the charger into the power socket.
3. Each continuous use of 1 hour, you must be timely charging, normal charging time for 10–12 hours.
4. Charging process charger or battery heating phenomenon (below 600C) is normal.
5. When the electric baby carriage is not in use for a long time, it must be recharged at least once a month.

## Battery instruction for Remote Control


1. When installing the battery, first open the battery cover, then install the battery according to the polarity, lock the battery cover. In the same way, take out the battery.
2. The remote control uses 2 # 7 batteries.
3. The non-rechargeable battery can not be charged.
4. rechargeable batteries can only be charged under adult supervision.
5. The rechargeable battery should be removed from the toy before recharging.
6. Different types of batteries or old and new batteries should not be mixed.
7. Batteries should be placed at the correct polarity.
8. The depleted battery should be removed from the toy.
9. The power terminal must not be short-circuited.



## Trouble shooting

Fault type		
The Motor won't run	<ol style="list-style-type: none"> <li>1. Is the foot switch in good contact?</li> <li>2. Is the welding wire on the motor terminal in good condition?</li> <li>3. Is the connector of the motor lead plugged in well?</li> <li>4. Will the motor plug-in disconnect, directly, connected to the battery rotation?</li> </ol>	No, fix the foot switch; yes, next. No, weld the terminals to the wire; yes, next. No, plug the connector in; yes, next. Do not turn, change the motor; turn, Drive Circuit Board failure, send professional repair point repair.

## Circuit Diagram



# Instructions



## 1. Install the front axle

The corresponding position of the front axle, in turn into the Shim, fixed with nuts can be




## 2. Shock absorber after installation

Fix the rear shock absorber in place with a screw/nut




## 3. Install the rear axle

Install the rear axle in the appropriate position under the car



## 4. Install rear pedals

The rear pedal is clamped into the body bracket and fixed with the gasket and the screw



## 5. Install the motor/wheel

The Gasket, the front wheel and the gasket are fixed in turn, and then fixed with the nut. In order to fix the plum shaft, rear wheel, gasket, and then fixed with nuts. And mount the front and rear wheels on the other side in the same way.

The rear wheel needs to be filled with a plum shaft



## 6. Install the steering wheel

Connect the power connection, the steering wheel into the direction of the shaft can be




## 7. Install the front gear

The corresponding position of the front gear card can be

## 8. Connect the motor wire/install the guard/install the seat

1. Connect the left and right motor wires
2. Install the support plate and screw it in place
3. Install the seat by pressing the bottom button



## 9. Install rear bumpers

Connect the power cord and insert the bracket into the body




## 10. Connect the power cord

Open the front hood and connect the main power connection

## Instructions for use




- ① One button start
- ② media player
- ③ Light switch
- ④ High speed, low speed
- ⑤ Shift Gears



## Remote control functions and instructions

- Do not switch the forward and backward buttons during vehicle movement to avoid damaging the gearbox and motor.
- The remote control needs a battery to work properly.
- The remote control requires the use of a guardian.
- Remote control is preferred.



★ Code method:  
always press the code key (m) do not let go waiting for the signal lights flashing, flashing lights after the start of the car successfully release the Code Key


## Precautions for use

1. Not in the streets, roads, slopes and other hazardous areas.
2. Please be on a well-level ground, please do not use on the smooth surface (such as marble, floor tiles) and other surfaces.
3. This product limited by one person, can not be overloaded, the maximum load 30KG.
4. Children must ride under adult guidance and caretakers must not leave during cycling.
5. Do not modify the vehicle wiring or additional charging device.
6. Do not use in water, do not pour water and other liquids in the car.
7. The car should not be blocked in the process of moving the car, so as to avoid damage to the device, such as blocked phenomenon, please immediately release Foot switch, remove the obstacles before riding,
8. The car should be timely charging slow cycling speed, cycling for too long will cause shortened battery life.
9. Do not use, please turn off the power switch, unplug the battery connector when not in use for a long time.
10. Do not ride in rainy weather.
11. The main use of PP car material, non-toxic, non-radiation, safe to use for a period of three years.

## Packing Instruction

- |                         |   |                      |   |
|-------------------------|---|----------------------|---|
| ● Product specification | 1 | ● The front wheel    | 2 |
| ● Car body              | 1 | ● The rear wheel     | 2 |
| ● The saddle            | 1 | ● The steering wheel | 1 |
| ● The remote control    | 1 | ● Wheel cover        | 4 |
| ● The charger           | 1 |                      |   |
| ● Accessories package   | 1 |                      |   |

## Schematic



# **Warning**

1. The toy may have potentially sharp edges or sharp points or small parts prior to assembly, so it must be assembled by an adult.
2. Use The car properly under adult supervision or risk injury to yourself or a third party.
3. Do not drive or play in dangerous places such as public streets, roads, slopes, swimming pools, etc. Otherwise, it may cause traffic accident and drowning.
4. This toy car may have small parts falling off during use, so it is not suitable for children up to 36 months of age.
5. This product is only suitable for children aged 37–95 months. Please put on protective equipment before use, such as helmet, hand protective cover, kneepad, etc.
6. The car can not be overloaded with a maximum load of 30KG.
7. chargers and batteries, wires, plugs and other components must be checked regularly for damage and should be stopped from being used until they are repaired.
8. Stay away from fire.
9. It is important to read the product instructions carefully before doing so and keep them for future reference.
10. The remote control uses two cells of No. 7 battery, which must be placed in the correct polarity position.

Certificate of conformity

model: \_\_\_\_\_

Inspector: \_\_\_\_\_

Production date: \_\_\_\_\_

## Electric four-wheeler for children

### **Installation and operation manual**

Applicable Age: 37–95 Months Child Use

- remote control priority control
- remote control for forward, backward, steering operation
- manual shift for forward and backward operation
- steering wheel with music function
- equipped with volume adjustment and MP3 amplifier research
- equipped with battery power display



Please take good care of the important information in it

WARNING: The remote control is not a toy. It is for the adult use only and should not be used by a child.

A close adult supervision is always required. Reception range may change significantly with weather, battery, and other environmental conditions.

## Instructions for use

\* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

The device must not be co-located or operating in conjunction with any other antenna or transmitter.

## Remote control functions and instructions

- Do not switch the forward and backward buttons during vehicle movement to avoid damaging the gearbox and motor.
- The remote control needs a battery to work properly.
- The remote control requires the use of a guardian.
- Remote control is preferred.

★ Code method:

always press the code key (m) do not let go waiting for the signal lights flashing, flashing lights after the start of the car successfully release the Code Key

