

User manual

Product name: Duet Bluetooth Dual Karaoke Micrphone

Model number:MI-S112B

Bluetooth distance:10M

Charging time:2.5H

Playing time: 2-3H

Speaker power:2*8W

Main functions:Bluetooth,TF card,AUX,U disk)

Microphone battery specification:7.4V/1500mAh



SpeakerX1



MicrophoneX2



Stereo Audio cablex1



USB-Micro USB cableX1



ON/OFF

1. "OFF" means Power off, "ON" means Power on, speaker will enter into the play mode which same as last time.

2. Charging: Insert out power to "DC5.0V", then the built-in battery can be charged.

Play Mode


1. Insert the audio equipment to the "AUX" ,and the speaker can play music from mobile phone,MP3,computer and other audios.

2. MP3 function

TF card/U disk: Insert TF card to TF, it will play music from TF card. Insert U Disk ,it will play music from U disk.

Button Function



1. 

MODE button is the mode conversion(Bluetooth, TF card, U disk, AUX).

2. 

Short press it will be PREVIOUS song ,Long press to volume down.



Short press to pause and play music, Long press to turn on the colorful neon lights, allowing you to sing at home and enjoy the KTV atmosphere.



Short press it will be NEXT song, Long press to volume down.



Short press the Music Original button is to cancel the original singer's voice.



When you singing adjust the reverb effect



7.

When you singing adjust the voice volume



8.

Switch "ON/OFF" and you can sing in any mode of the speaker.

Instructions for use

As you power on, Bluetooth mode is the default. You could search for the bluetooth device named **MI-S112B** on your phone for connection. It will be converted to TF card mode when you insert the TF card. It will be converted to USB mode when you insert the U disk. It will be converted to AUX mode when you insert the 3.5MM audio cable. When insert the TF card and USB at the same time, press the MODE button to convert the mode.

Singing instruction

When the speaker is turned on, the wireless microphone is connected to the speaker by default after turning it on. Just turn on the wireless microphone power **switch**"ON/OFF" and you can sing in any mode of the speaker. When you sing, you can adjust the reverb effect through the "ECH" button of the wireless microphone and adjust the voice volume through the "VOL" button. The volume is adjusted according to your personal preference to achieve the desired singing effect.

When the blue light of the wireless microphone is flashing, it means the microphone battery is too low and needs to be charged.

Wireless microphone charging method

Use the USB charging cable to plug into the charging port at the bottom of the microphone to charge.



FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.