

User Manual

RGB Backlit Wireless Keyboard



Note: Please read the manual carefully before using.

Package Contents.....	01
Product Overview.....	01
How to connect.....	02
Indicator Light.....	02
Function Keys.....	03
Backlight Switching.....	03
Mouse.....	04
Power Saving Mode.....	05
Charge.....	05
Electrical Specifications.....	06
Troubleshooting.....	07
End.....	09


Package Contents

- 1 x 2.4GHz Wireless Keyboard with Receiver
- 1 x 2.4GHz Wireless Mouse
- 1 x USB-C Charging Cable
- 1 x USB-C to B Adapter
- 1 x Silicone Keyboard Cover
- 1 x User Manual

Notice: 1. When not used for a long time, it's recommended to turn off the power to prolong the battery life of the keyboard.

2. Do not use liquid to clean the keyboard directly. Clean the keyboard with alcohol or similar volatile disinfectant.

Product Overview



How to connect


Step 1. Please make sure that the keyboard and mouse are fully charged.

Step 2. Slide the power switches separately to turn on the keyboard and mouse.

Step 3. Take out the 2.4GHz USB receiver and plug it into an USB port of the computer.(The Type-C device interface requires a USB C-B adapter.)

Step 4. Then it will automatically connect.

Indicator Light



① Num Lock

The Num Lock indicator will turn green when Num Lock is activated.

② Caps Lock


The Caps Lock indicator will turn green when Caps Lock is activated.

③ Charging indicator

Red light is on when charging, red light is off when full.

Low battery warning: the light flashes slowly for 5 seconds (one flash per second).








Function Keys



Tips: Please press  + "F1-F13" together to activate the function keys.

Backlit Switching

How to switch:

1. Press the  to turn on the backlit of the keyboard.
2. Press  +  or  to adjust the brightness.
3. Press    to select the mode of the backlit.

Modes:

- M1 is the flow mode, the backlit flows like an illuminated rainbow.
- M2 is the monochrome mode, you can switch one of 7 colors by tapping M2.
- M3 is the ripple mode, tap any key and the light will flash once.

| Power Saving Mode

1. When the keyboard is inactive within 60 seconds, it will automatically enter the sleep mode.

To wake up the keyboard, press any key and wait for 2-3 s, it will automatically connect to the device.

2. When the mouse is not operated within 5 minutes, it will automatically enter the sleep mode.

To wake up the mouse, press any key and wait for 2-3 s, it will automatically connect to the device.

| Charge

Charging Tips:

When the keyboard is charging, the power indicator is on in red, and it goes off when fully charged.

When the mouse is charging, the red indicator on the scroll wheel is on and it will automatically go off when fully charged.

Low battery warning:

When in use, the keyboard light will flash slowly for 5 seconds (flash once per second).

When moving the mouse or pressing a button, the green light on the scroll wheel blinks twice about 1 second intervals. If not used in mouse, it doesn't give any indication.

Electrical Specifications

2.4GHz Wireless Keyboard Parameters


Number of Keys	112 Keys
Battery Capacity	1600mAh
Standby Time	200 Days
Continuous Working Time	≈380h without backlit; ≈6h with backlit
Key life	10 Millions Strokes
Working Distance	Within 10 meters
Compatibility	95/98/2000ME XP Vista Win7 Win 8 Win 10 above Mac OS
Charging Current/Time	1000mAh/2.5h
Wake up Button	Any button
Dimensions	16.19 x 4.80 x 0.47 inches
Weight	1.27 pounds
Material	ABS

Troubleshooting

Unable to connect the device

First, please fully charge the keyboard and mouse, unplug the receiver, restart the computer, and re-plug the receiver. If it can't be connected, please perform the following actions to fix it.

1. Keyboard can not be connected

Switch on the keyboard, press  + , the light flashes quickly. Plug the 2.4GHz USB receiver into the computer.

Within 10 seconds, put the keyboard at 10 cm from the receiver for pairing. When the light is off, the keyboard pairing succeeds.

Keyboard typing delayed/not working

1. Make sure there is no 2.4GHz device (e.g. router) nearby to interfere with the connection.
2. Make sure the keyboard fully charged.
3. Make sure there is no full metal case that may block the signal.
4. The computer is running too many tasks and the CPU memory is full to handle the signal from the receiving end.

Shortcut keys not working

Unplug the USB receiver and plug it back in.

Keyboard and mouse not charging

1. Please confirm the charging status of the keyboard, charge it for 60 minutes and turn it on to see if the indicator light can blink normally:

Stable red light - charging

Light off - fully charged

Flashing light - keyboard battery power low

2. Please try another charging cable to check if it can be charged normally.

Under Mac OS, if Alt is not correctly mapped, the system thinks that pressing Win. At this time, Unplug the USB receiver and then re-plug, the system re-identification to Mac OS.

| End

Thank you very much for your purchase.

Hope it can bring a comfortable experience.

Any questions about the product, please contact our customer support directly and we will try our best to help you.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.