



User Manual
Model: SB1327HZ


1. Quick start guide

Overview



1. Screen
2. Touch key
3. Charging POGO PIN
4. Heart rate

- Make sure the POGO-pins on the charging cable fit correctly onto the charging terminals on the back of smart watch.
- Plug the big end of the USB cable to a power source and after successful charging, a charging icon will appear on the screen.



Install “Orunning” app on the phone

Search and install the “Orunning” app from Google Play or App Store. Or scan the following QR code to directly install the app.



Android



IOS

Connect the smart watch with the phone

1. Enable Bluetooth on your smart phone.
2. Open the “Orunning” app on your smart phone, and then fill in all the requested information in the “Settings” menu.
3. Tap “Connect device” in the “Settings” menu.
4. Select the smart watch icon to connect.
5. Choose your device name to connect it with your phone.

Unbind smart watch with mobile phone

1. Open the “Orunning” app on your smart phone.
2. Tap “Disconnect device” in the “Settings” menu and confirm “OK”.
3. To disconnect your smart watch with an iPhone, click “Disconnect device” in the “Settings” menu of the “Orunning” app, and go to the Bluetooth settings on your iPhone, then access and select the “Forget This

Device” option.

Operation Introduction

- You can raise your hand or press the touch key to light the screen.
- To switch on the watch, press and hold the touch key until the display is on.
- To switch off the watch, press the touch key repeatedly until “more” icon shows on the display and then long press to enter in, press the touch key repeated until Power off” icon shown and long press the touch key twice.


2. Functions

Watch face




There are 3 watch faces. In the current watch face, press and hold the touch key to choose the one you like.

Pedometer




The watch will record your daily activity automatically. Press the touch key to enter in pedometer and you can check the more detailed data by long press the touch key.

Heart rate



Press the touch key to enter in heart rate and you can monitor your current heart rate by long press the touch key. Press the touch key to exit.

Sport




Press the touch key repeatedly and long press the touch key to enter the multi-sport mode.

The smart watch has 4 sports modes: Walking, Running,

Hiking, and Cycling. Choose one of them and then do sports. The smart watch will record your sports data. When you finish your sports, you can long press the touch key twice to stop your sport and save the sports data. If you've connected your smart watch with the "Orunning" app via Bluetooth, you can also check your sports data in the app.


Note: If the exercise time is less than 5 minutes, the data cannot be saved.

Sleep status



Wear the watch to fall asleep during 9:00 p.m. to 9:00 a.m.; the watch can show your sleep data of last night on the next day. Long press the touch key to check the sleep data.

Message




Unread messages will be displayed in "Message" interface. Long press to enter and check these messages on the watch.

Weather



After connecting with app, you can select city in advanced settings of the app. And the weather of this city will be displayed on the watch.

More



In “More” interface, long press the touch key to see more functions, including Find Phone, Stopwatch, Sedentary reminder, Remote capture, BT music, About, Reset, Restart, and Power off.


Reminders



In this interface, long press the touch key and you can

see the reminders you've set in the app. When the reminder time is up, your watch will vibrate.

Stopwatch




Enter “More” interface and you could find stopwatch by press the touch key. Long press the touch key to enter the timing page, short press the touch key to start and pause. You can exit by long press the touch key.

Find Phone




After connecting the app, you can look for your phone by long press the touch key of the watch.

Sedentary reminder




Long press the touch key to turn on or turn off the sedentary reminder you've set in the app.

Remote capture




After successfully connecting with the app, long press the touch key to open camera of your phone, short press the touch key to take photos, and long press the touch key to exit.

BT music



Open your music app on your phone, and then enter BT music in your watch. You can control the music by long press the touch key. Long press the touch key to exit.

About



Long press the touch key in “About” to view watch name, marc address and firmware version.

Reset



Long press the touch key in “Reset”, your watch will be reset and restart.

Dial switching



Long press the touch key in “Dial switching”, you can change the watch face directly.

Restart



Long press the touch key in “Restart”, the watch will be restarted.

Power off



Long press the touch key in “Power off”, the watch will be turned off.

3. FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.