

# QUICK INSTALLATION GUIDE

#### RRT-200-LTE

The RRT-200 is an SD-WAN Router for Small Office Home Office (SOHO) communications:

- 5xGbe (2xWAN, 3xLAN)
- 802.11a/b/g/n/ac
- 500 Mbps Internet
- Optional 4G LTE Built-in Modem:
  - Max 150 Mbps Downloads & 50 Mbps Uploads
  - North American Coverage

**Note:** We recommend providing at least 3 inches clearance on each side and the top of the device.




### **RRT-200 Other Package Contents**



## **Dual Link 4GLTE (WAN1 + 4GLTE SIM)**

Connect ISP1 Modem to WAN1 Port and Insert SIM:



**Note:** Insert and removal may require the provided tool. Use the rounded edge to gently push the SIM in until the mechanism clicks.

- Insert SIM (Some devices may be shipped with prepaid SIM)
- Gently insert SIM until the SIM slot latch clicks (tool provided)
- Connect your ISP Modem to WAN1 (LAN side of Modem to WAN1 port)
- Connect the AC Power Adaptor
- Device requires portal activation. (consult your reseller)

#### **FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

The use of the 5180-5240 MHz band is restricted to indoor use only.