

名称： 外单瀚可SK100说明书-白色 128G双铜+风琴折 展开尺寸560*100mm 折好尺寸： 140*100mm Y.047.1048

NYLAVEE

Computer Soundbar
SK100
User Manual

Package Included

1 x Computer Soundbar (SK100)

1 x 3.5mm Audio Cable

1 x User Manual

Specification

Device Model	SK100
Two Connection Options	Bluetooth 5.0 & 3.5mm audio plug
Power Supply	USB plug (no built-in battery)
Power Input	DC 5V \pm 2A Max

Product Diagram

Back

1 Volume Knob

2 Power Indicator

3 Bluetooth Indicator

4 AUX OUT Jack

5 AUX IN Jack

Button Control

Function	Operation	Voice Prompt	LED Indicator
Power On	Insert the USB plug into any USB charging adapter or active computer USB port	Beep	Power Indicator stays solid blue
Power Off	Unplug the USB power cord	/	/
Bluetooth Mode On / Off	Press the Volume Knob twice quickly	Beep	/
Bluetooth Pairing	/	Beep	Bluetooth Indicator flashes blue and white alternately
Bluetooth Connected	/	Beep	Bluetooth Indicator (blue) flashes every 5 seconds
Bluetooth Out of Range	/	/	Bluetooth Indicator flashes blue and white alternately
Volume +	Turn the Volume Knob clockwise	Beep when highest volume is reached	/
Volume -	Turn the Volume Knob counter clockwise	/	/
Play / Pause	Press the Volume Knob once	/	/
Answer / Hang Up Phone Call	Press the Volume Knob once	Beep when answering	/
Decline an Incoming Call	Press and hole the Volume Knob for 1 second	/	/

Use Your Soundbar

The soundbar does not have a built-in battery, please insert the USB plug into the USB port on the desktop, laptop, tablet, power bank, etc.

Wired Connection via 3.5mm Plug

1 Wired mode: the soundbar defaults to this mode when it is turned on.

2 When the Bluetooth Indicator light is off, it means the wired mode is on.

3 Insert the 3.5mm Audio Cable into the "AUX IN" jack at the back of the soundbar and plug the other end into your device.

Note:

When want to use wired mode, please make sure the soundbar is not in Bluetooth mode.

Quickly press the volume knob twice to switch from Bluetooth mode to wired mode.

Wireless connection via Bluetooth

1. Switch to Bluetooth mode

1 Press the Volume Knob twice quickly to turn on Bluetooth mode.

2 When the Bluetooth Indicator flashes blue/white, it means the Bluetooth pairing mode is on.

2. Pair with your device

1 Turn on the Bluetooth of your device and search for nearby devices.

2 Find "SK100" in the search results and tap to connect.

Once connected, a beep will be heard and the Bluetooth indicator (blue) will flash every 5 seconds.

Note:

Make sure the soundbar isn't connected to other devices, otherwise please disconnect this device.

If you can't find other connected devices, please press and hold the knob for 3 seconds to return to the Bluetooth pairing mode (Bluetooth Indicator flashes blue/white).

Keep the soundbar and your device within 16ft/5m.

Attention

Troubleshooting of Sound

If there is no sound comes out from the soundbar, please try the following operations:

Rotate the volume knob clockwise to raise the volume of the soundbar.

Adjust the volume on your device.

Press the volume knob to resume in case the soundbar paused.

Re-insert the USB plug

Troubleshooting of Bluetooth Connection

Make sure that the soundbar Bluetooth pairing mode is on(Bluetooth Indicator flashes blue/white).

Make sure the Bluetooth of the soundbar is not connected by other devices.

Unplug the 3.5mm Audio Cable from your device.

Delete "SK100" memorized on your device, then search for "SK100" and connect again.

Worry-free Service Guarantee

30 days free return and exchange.

18 months warranty.

Lifetime friendly customer service.

Please contact us for more details and further instructions via

support@nylavee.net

Extend 2-years warranty:

www.nylavee.net

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must withstand any interference received, including interference that may cause undesired operation.

FC CE RoHS

4

5

6

7

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.