


Receiver User Manual



1. Receiver connected to computer:

Insert the receiver into the USB port of the computer, and when the receiver is powered on, it will automatically search for a paired mouse and start working.

2. Pairing the receiver with the mouse


a. Connect the receiver to your computer. Make sure the mouse is not connected to your computer

b. Please put your mouse in pairing mode

To do this, press and hold the right-click, left-click, and scroll-wheel button simultaneously for 5 seconds. The LED on your mouse will blink, indicating that the pairing mode is activated.

c. Press the PAIR button.

You can use the space key or the enter key on your keyboard to run the program.



3. Working frequency and applicable models

The frequency range of the receiver is 2402-2480MHz, and this receiver is suitable for Pulsar Xlite/X2H/X2/X2A wireless models or Pulsar OLED eS Xlite/X2H/X2/X2A wireless models.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.