

正面

The front cover of the quick start guide is divided into eight numbered sections. Sections 1-4 show the camera and its components, while sections 5-8 provide step-by-step instructions for mounting the camera on a ceiling.

- Getting Started**: Shows the camera, USB adapter, and USB-C cable.
- PRODUCT OVERVIEW**: Shows the camera from two angles with numbered callouts for its parts: Status LED (1), Lens (2), Microphone (3), SD card slot (4), Speaker (5), SYNC button (6), and Power input (7). Below is a list of included items: aoso IndoorCam P1 x1, USB Adapter x1, USB-C Cable x1, Mounting Plate x1, Mounting Screw Pack x1, and User Manual x1.
- SETTING UP THE SYSTEM**:
 - Download the App and Set up the System**:
 - Download the aoso App from the App Store (iOS devices) or Google Play (Android devices).
 - Scan the QR code below or search "aoso" in the App Store or Google Play.**
 - Register or log into the App.** Add IndoorCam P1 and scan the QR code for later installation process.
- Status LED**: A table mapping four LED colors to their meanings:

Status LED	Description
Solid Green	Camera powered on
Blinking Green	Ready for setup
Solid Blue	Camera working properly
Blinking Blue	Disconnected from the internet
- MOUNTING THE INDOOR CAM**:
 - Select a Location for Mounting:** The camera can be placed on a table, shelf, or mounted on a ceiling. To avoid infrared reflection, it should be at least 0.7 ft/20 cm away from walls or obstacles.
 - Explanation:** To mount the Indoor Cam on the ceiling, follow the steps below:
 - Place the Mounting Plate against the ceiling and mark the points where anchors are needed.
 - Drill holes with a 5/16" (8mm) drill bit.
 - Align the grooves with the mounting plate and the Indoor Cam, then pull forward until it clicks into place.
- To mount the Indoor Cam on the ceiling, follow the steps below:**
 - Place the Mounting Plate against the ceiling and mark the points where anchors are needed.
 - Drill holes with a 5/16" (8mm) drill bit.
 - Align the grooves with the mounting plate and the Indoor Cam, then pull forward until it clicks into place.
- Mounting the Indoor Cam on the ceiling:**
 - Step 1: Place the mounting plate on the ceiling and mark the anchor locations.
 - Step 2: Drill holes for the anchors.
 - Step 3: Align the mounting plate with the holes and push it into place.
 - Step 4: Mount the camera onto the plate.

背面

The back cover of the quick start guide is divided into six numbered sections. Sections 9-11 provide technical details, while sections 12-14 offer customer support information.

- To mount the Indoor Cam on a wall:** We recommend using the mounting bracket (not provided, users need to purchase by themselves) as the illustration below.
- Notice**:
 - FCC Statement:** This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference resulting from such interference.
 - IC Caution:** User manuals for licence-exempt radio apparatus shall contain the following or equivalent notice in a conspicuous location in the user manual or alternatively on the device or both:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) this device may not cause interference, and
(2) this device must accept any interference, including interference that may cause undesired operation of the device.
 - IC SAR Warning:** This equipment generates heat and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/ TV technician for help.
 - FCC Radio Frequency Exposure Statement:** The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed/mobile exposure condition. The min separation distance is 20cm.
- CE**: This product complies with the radio interference requirements of the European Community.
- Customer Service**:
 - Warranty:** 12-month limited warranty.
 - Email Us:** Customer Support: support@aosalife.com
 - Call Us:**
 - United States: +1 866 905 9950 Mon-Fri 9:00-17:00
 - United Kingdom: +44 20 3885 0830 Mon-Fri 9:00-17:00
 - Germany: +49 32 221094692 Mon-Fri 9:00-17:00
 - Japan: +81 (50) 58402601 Mon-Fri 9:00-17:00
 - Facebook:** @aosalife
 - Twitter:** @aosalife
 - YouTube:** @aosalife
- AOSU**:

IndoorCam P1
Quick Start Guide

说明书制作要求

材质: 105g哑粉

成品尺寸: 73x73mm, 共16P

印刷: 70%k

装订方式: 风琴折, 按照顺序折叠

备注: 请使用ai文档印刷