

EN Customer Information

Keep all this information for safe and proper use. Also keep the product packaging, as it contains operating instructions and information about the product, batteries and recharging. For more information, scan the QR code on the packaging.

General Safety Instructions

- Keep out of the reach of children as small parts can be swallowed.
- Only use the product if you are in good physical condition.
- Do not use the product with other people against their will. Only use with the consent of the people involved.
- Use the product safely to avoid injury. Use at your own risk.
- A doctor should be consulted before using the product if a person has any health issues or concerns.
- Do not use the product on diseased or irritated skin.
- Discontinue use immediately if unpleasant skin irritation or physical discomfort occurs. Consult a doctor if the symptoms persist.
- To avoid illness and infection, do not pass the product on to third parties.
- Read the information on the product packaging carefully to avoid allergic reactions (e.g. latex).
- Do not use the product if it is obviously non-functional, overheats or has visible defects.
- Do not freeze or heat the product.
- The product is not suitable for commercial use.
- Do not inflate inflatable products beyond the diameter indicated on the packaging.
- The product is not suitable for medical use.
- Only charge the product with a suitable charger at a power socket. Observe the instructions of the respective mains adapter.
- No liability can be accepted for damage or accidents caused by improper use, the use of force, modifications and non-compliance with these safety instructions.

Before First Use

- Clean the product with warm water and mild soap before using it for the first time. To prevent damage to the device, make sure that no water gets into the battery compartment. Do not submerge the device in water.
- Charge the product or insert the batteries (if supplied). For safety reasons, lithium batteries are generally only charged to 40-50% for transport.
- Switch the product on first. Then insert it into the vagina or place it on the desired area in the genital area.

Use of Vibrators

The product is only suitable for vaginal use.

1. Apply sufficient lubricant to the surface of the product.

Important: The use of water-based lubricant is recommended.

2. To start the vibration, use the control unit to switch the product on.
 3. Insert the product into the vagina or place it on the desired area in the genital area.
 4. To change the vibration setting, carefully press, turn, or slide the control unit.
 5. Slowly remove the product from inside or off your body.
 6. To switch off the vibration after use, press, turn, or slide the control unit into the initial position.
- Important: If the product switches off automatically when the battery is low, do not switch it on again, but charge it at a power socket.***

Optional (when relevant):

- Some vibrators have a G-spot tip. To stimulate the G-spot, follow the steps above and hold the curved tip in the direction of the abdominal wall.
- Some vibrators have one or two stimulation arms that can be used to stimulate the clitoris and/or anus simultaneously.
- Some vibrators have a special function (e.g. rotation, thrust function, pump function). Press the control unit to switch these functions on and off.
- Some vibrators have a pump ball. To increase the diameter of the vibrator, press the pump ball repeatedly if necessary. The vibrator is inflated. To let the air escape, open the valve.
- Some vibrators have a suction cup that allows you to attach the product to a smooth, clean and dry surface. Detach the suction cup carefully from the surface.
- Some vibrators are made out of glass. They can be warmed up on the heater or cooled down in the fridge for temperature play.

Care Instructions

- Allow the product to cool down after every use before putting it away.
- Clean the product after every use with warm water and a mild soap and disinfect it with a disinfectant solution suitable for the product. To prevent damage to the product, please make sure that no water enters the battery compartment. Do not submerge the device under water.
- Keep the product in a clean, cool and dry place. Moisture can damage the batteries and motor. Avoid direct sunlight.
- To prevent chemical reactions, store the product separately and not together with other products made from different materials.
- To extend the life of the batteries and rechargeable batteries and to prevent damage to the product, remove the batteries from the product after each use or remove the product from the socket as soon as the rechargeable battery is fully charged.

Disposal Information / Your Contribution to Environmental Protection

Please do not discard the packaging material or old devices. Recycle items where possible. Separate packaging according to material and dispose of it with household waste. Do your bit for the environment and take old devices to your local collection points in accordance with your national legislation and the applicable guidelines. Separate non-enclosed batteries and rechargeable batteries from old devices before you hand them in at a collection point. Make sure that you delete all personal data from your old devices before disposing of them.



The symbol of the crossed-out garbage can on wheels means that this product must be handed in free of charge to a collection point for electronic waste so that it can be recycled for the best possible reuse of raw materials.



Batteries do not belong in household waste. As a consumer, you are under a legal obligation to turn in used batteries. You can do this at public collection points or places where batteries are sold. You can also return rechargeable batteries and batteries that we carry or have carried as new batteries to our dispatch warehouse (Schäferweg 14, 24941 Flensburg, Germany) free of charge after use. Batteries containing hazardous substances are labelled with the sign and one of the chemical symbols:

- Cd: Battery contains cadmium
- Hg: Battery contains mercury
- Pb: Battery contains lead

Lithium batteries and battery packs for all systems can only be turned in at collection points if they have been discharged. To prevent short-circuits in the event of incomplete discharging, the poles on these types of batteries should be insulated using a substance such as adhesive tape before the batteries are returned.

FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.