Instruction Manual

Model: FDBT-OR2-BULL

Specification:

Bluetooth 5.0

Frequency range: 20Hz-20kHz


Charging time: 150 min

Music playing time: 60-90 min

Material: ABS

Device description

- 1. On/off Switch
- 2. LED indicators
- 3. Charging port



Power on and connect

Press and hold the on/off button on the device to turn the speaker on or off. Enable Bluetooth® function on mobile device, and search for Bluetooth® devices. The device name is "FDBT-OR2-BULL". When the pairing is successful, a beep will sound. If you want to switch pairing to other mobile devices, then you need to cut off the connection of existing equipment and repeat the steps with the new device.

WARNING:

- You must select a qualified charger from a reliable source.
- You must charge the Bluetooth® speaker if it has not been used for more than 12 months.

Please fully charge the device for 3-4 hours before first use. Connect the cable to the computer's USB port, use an AC adapter (not included) or other DC power supply not exceeding 5V, 1A. The LED indicator will light up and the LED indicator will turn off when the speaker is fully charged.

Cleaning and storage

- 1. Turn off the device before cleaning.
- 2. Use a soft damp cloth for cleaning.
- 3. Do not use corrosive cleaners or abrasives (such as steel wool or brushes) for cleaning.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- --Increase the separation between the device and receiver.
- --Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- --Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Distributed by:



