














<p>Wi-Fi Water Leak Sensor With Sound User Manual</p>  <p>* Please read this manual carefully before use and keep it for future reference.</p>	<p>Product Introduction</p>  <p>Function Key Introduction</p>  <p>1</p>	<p>Specifications:</p> <p>Battery type: Alkaline battery (2* 1.5V AAA battery) Standby current: ≤18uA Alarm current: ≤100mA Sound level: 80dB(within 1m) With Low Battery remind function Working temperature: -10℃~55℃ Working humidity: 10%~90%RH Wi-Fi: IEEE 802.11 b/g/n 2.4GHz</p> <p>2</p>	<p>How to use:</p> <p>1. Push the mounting bracket upward and take out the bracket, then insert the battery.</p>  <p>2. Put the battery into the battery bin and place it according to the graphics in the battery bin. After two batteries are loaded, the indicator lights are always on and then off.</p>  <p>3</p>	<p>3. Download Smart Life APP in app store or google play store, or scan the following QR code</p>  <p>iOS / Android</p> <p>4</p>	<p>4. First turn on the bluetooth in mobile phone → open smart life app and choose "+" → press and hold on the set key for more than 5s to let the indicator flashes.</p>  <p>5</p>
<p>5. Then will see "Discovering devices" on the app. Press "add", enter the correct password, then press "Next". Finally, it will connect the Wi-Fi network automatically.</p>  <p>6</p>	<p>6. Network connection successfully.</p> <p>Picture 1: Water leak detector "Normal" status, press "Smart" to set the automatic linkage with other devices, press "Set" to do some setting.</p> <p>Picture 2: Water leak detector "Alarm" status, press "Mute" to stop the alarm sounds.</p>   <p>① ②</p> <p>7</p>	<p>7. Function Introduction.</p>  <p>8</p>	<p>8. Share devices You can share your added devices with your family members, so they can also monitor the ambient environment.</p> <p>9. Intelligent Linkage When trigger water sensor, can link to turn on the Tuya smart light.</p> <p>10. Battery Life The more triggered water sensor, the shorter life of battery(The battery life will be related to the triggered times of sensor.)</p> <p>9</p>	<p>FCC Statement This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver.</p> <p>10</p>	<p>-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.</p> <p>To assure continued compliance, any changes or modifications not expressly approved by the party. Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).</p> <p>This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.</p> <p>FCC Radiation Exposure Statement: The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.</p> <p>11</p>