



2.9-inch
SyncSign® Display
User Manual

1. Get to Know SyncSign Display



Pin-hole E-ink Screen




USB Port
(DC 5V, 500mA)


2 x AA Battery
(Replaceable)

- The battery equipped is non-rechargeable.
- When USB port was plugged in, the display will be powered up by a power adapter instead of the battery.
- No need to take out the battery when having the USB port plugged in.

Wall Mount Bracket (Optional accessories are to be purchased separately.)



Screw Hole Anti Theft Screws



Back Cover Serial Number LED

2. What's in the box



2.9-inch SyncSign Display x 1



Pin x 1



Double-sided tape x 2

3. Setup



↑ Insert the pin into the pin-hole

- Pairing: Please launch the SyncSign App and follow the instructions on the App to pair the display with the hub.
- Reboot: Insert the pin into the pin-hole, press and hold for 4 seconds, then release.
- Reset: Insert the pin into the pin-hole, press and hold for 12 seconds, then release.

4. Support Center

<https://help.sync-sign.com>
help@sync-sign.com

5. For more:



Search "SyncSign" on social networks

Please checkout this web page for the latest version of user manual:

<https://dev.sync-sign.com/usermanual>

CE FC Recycle (v1.2)

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter