



QUICK START GUIDE

Product Name:Scout

Model:SC3100

Brand:Moorebot

Manufacture:Dong Guan City Hang Seng Digital Product Co., Ltd.

1. Safety Instructions

READ AND SAVE THESE INSTRUCTIONS. This product is fully compliant with all relevant electromagnetic field standards, and is when handled as described in this Guide, safe to use. Therefore, always read the instructions in this Guide carefully before using the device, and save it for later use.

- Scout is not a toy. Do not allow children to play with it without parental care.
- Keep this Guide for future reference.
- Use of other 2.4GHz and 5GHz products, such as other wireless networks, or microwave ovens may cause interference with this product. Keep Scout away from these types of products, or turn them off if they appear to be causing interference.
- Always ensure that you have a good Wi-Fi connection available.

2. What's in the box?

- ✓ Scout Robot
- ✓ Charging Station (recommend to tape to ground)
- ✓ Type-C USB cable
- ✓ Quick Start Guide
- ✓ Lubricant for Mecanum wheels

Important note:

- ◆ **Scout doesn't provide power adaptor in the package. It is recommended to use USB adaptor with 5V and >2A output.**
- ◆ **Not recommended to stick the charging station to wood floor with paint.**


3. What can Scout do?

- **Monitoring.** Scout is a smart robot with an FHD camera on wheels. Once connected, the App can control Scout move around. Night vision is supported. Scout by default recognizes many objects including human bodies and pets. Scout is IP65 waterproof. It works in the outdoor environment.
- **Record videos and take pictures on demand.** Use the "Moorebot Scout" App or send commands

from Amazon Alexa or Google Home, videos and pictures can be recorded. Cloud service is also available.

- **Patrol.** Scout is capable of patrolling the house on its own. Set up the patrol path in the App as well as the triggers such as the timer, sound, sensors from the smart home system, etc. During the autonomous patrols, Scout can avoid obstacles on the way, calculate its path and go back to its Charging Station once done. Scout may have difficulties navigating in a narrow and/or crowded environment with many obstacles.
- **Programming and add-on tools.** Scratch language is supported in the App. Learning programming becomes easy. Users can also design new extension tools for Scout and add on to the extension port. Explore the endless possibilities. For more details, please refer to information

4. Product Overview



5. Place the Charging Station

Scout is charged by its own Charging Station. Place the Charging Station against the wall using the adhesive tape. To support autonomous patrol, it is important to make sure that the charging station does NOT move around. Provide power via USB port. Scout is capable of identifying its Charging Station and backing into it. The Battery Indicator will reflect the charging status.

Several tasks can only be performed when Scout is in

the charging station, including software OTA (over-the-air) update, monitoring with motion detect, and reboot.

Avoid heat sources or other battery-unfriendly conditions to place the Charging Station.

6. Powering Scout On & Off

Press the “On & OFF” button for 2 seconds. The system will power up and the Power LED will turn on. Press and hold the button for 3 seconds to turn it off.

7. Reset to Factory Condition

To reset the robot, long press the “RESET” hole at the rear of the robot. It will restore the factory condition and unbind the robot from previous user account.

8. Connecting Scout

What you need:

- Smartphone or tablet with Android OS 6.0 and later or iOS 11.0 and later
- Wireless network (for Wi-Fi Router mode)

8.1 Download Scout App

For Android devices

Go to Google Play Store, search for “Moorebot Scout”, then download and install the App on your Android device.

For iOS devices

Go to App Store, search for “Moorebot Scout”, then download and install the App on your iOS device.

8.2 Connect to Scout

There are two ways that a mobile phone can connect to Scout, Wi-Fi Direct Mode (or AP mode) and Wi-Fi Router Mode. Out of factory, the Wi-Fi on Scout is set to the Wi-Fi Direct Mode. The LED indicator shall reflect that status. When the LED indicator blinks, it indicates that the robot is not connected. When the LED indicator stays on, it indicates that the robot is connected.

In the Wi-Fi Direct Mode, mobile phones can link to Scout directly. Users can see in the mobile phone a Wi-Fi named "**robot_scout_XXXXXX**". Follow the App and use the default password (e.g. "**r0123456**") to connect. Once connected to Scout, users shall control the robot and view the video. The second mode is Wi-Fi Router mode. In this mode, the robot connects to the home Wi-Fi router as an Internet-of-Things (IoT) device and can be accessed from the internet via a secured Peer-to-Peer connection. Simply press the "Wi-Fi mode select button" to change to this mode. The home Wi-Fi SSID and Password need to be provided to Scout in Wi-Fi Direct Mode. Then Switch to Wi-Fi Router mode to go online. Just follow the App.

9. Get started with Scout

9.1 Overview of Scout App

Moorebot Scout App allows users to connect the robot to mobile phones either directly or through the internet. Users can control the robot's movement and view its video with different resolutions (e.g. 720P/1080P). Scout, when it is in its charging station,


can become an IP camera or monitor. It supports motion detect, and many other standard IP cameras features.

Patrol path can be set up for Scout to autonomously conduct patrol with different triggers, such as the timer, voice control through Alexa or Google Home, even sensors in your smart home system. Scout can generate a report and send a notice after each patrol. If human bodies or pets are detected, a 13-second video clip can be uploaded to the cloud server. The cloud server can be disabled on the setup page.

Moorebot Scout App also supports Scratch Programming. Users can program and control the robot with this graphical programming interface.

9.1.1 Register and Set up Wi-Fi


Users need to register an account with correct email. Depending on your email security setting, sometimes the confirmation email may go to your spam folder.



Once registered, the next step is to set up Wi-Fi.

Turn on the robot. After it powers up, the Wi-Fi shall stay in the “Wi-Fi Direct” Mode, which is the out-of-factory condition. Use this App to scan Wi-Fi. There should be Wi-Fi with the SSID name “robot_scout_XXXXXX”. This is Scout. Connect to it with default password “r0123456789”. You can play with the robot already. If you want to set up the robot as an IoT device, follow the App, select or type in your home Wi-Fi SSID and provide the password. This must be done in the “WiFi Direct” mode when the mobile phone connects to Scout. If successful,

the robot can switch to the “Wi-Fi Router” mode automatically and connects to the internet. You can control the robot and view the video from worldwide in “Wi-Fi Router” mode.





9.1.2 Live video with movement control

The main control panel is shown below. The controller is overlaid with the camera view from Scout.



The following table illustrates the icons in the App.

Icon	Functions or Status
	Status showing Scout is Wi-Fi direct mode, where Scout connects to the mobile phone directly. Green indicates that the mobile phone is connected with Scout. Red indicates unconnected.
	Status showing Scout is Wi-Fi router mode, where Scout connects to home Wi-Fi router and goes online. Green indicates that the mobile phone is connected with Scout. Red indicates unconnected.



Indicate that the robot is in the charging station. Press to get out of the charging station. Only when the robot is outside the charging station, it can be controlled to move around. **User must press this button to release the robot first.**



Indicate that the robot is outside the charging station. Press to return to the charging station autonomously.



Set up patrol path. Users control Scout to navigate. A path is drawn. When Scout returns to its charging station, it saves the path and follows path for future patrol.



Setup motion detect. Motion detect only works when Scout is in the charging station.



Take a photo and store in local memory.



Record video clip and store in local memory.




Enable and Disable speaker.

9.1.3 Set up patrol


Multiple patrol paths can be set up with different names. To set up the patrol path, users must tap the “path” symbol in the App and manually control the robot to create the desired path. The patrol path setup must start with Scout in its charging station. The charging station is coordinates (0,0). When Scout goes back to its charging station whether autonomously or guided by users, the patrol path will be saved. Scout will remember it, follow the path to patrol whenever needed and go back to its charging station once the job is complete. The video of each patrol can be stored locally onto the flash memory inside Scout. When enabled in the setup and human bodies and/or pets are detected, Scout would upload 13-second video clips to the cloud server.

Once the patrol path is set, users can trigger patrol using timer, triggering events in smart home system (e.g. door sensor), and Alexa/Google Home/Siri voice.



9.1.4 Scratch Programming

The following is the UI for Scratch Programming. Try it out. It is quite fun.



9.1.5 Work with Alexa and Google

Scout is a “work with Alexa and Google Home” device.

Users can pair the robot with Alexa and/or Google Home account. Video can be streamed to Echo Show or other screen devices. Voice commands can control the movement of the robot.



Alexa Voice Commands

The following table contains the voice commands to control the robot.

	Skills	Launch Phrase	Description
1	Video skill	"Alexa, show my camera."	Stream video to Echo Show and Spot. Camera name can be

			customized.
2	Start patrol	"Alexa, ask robot Scout to start patrol."	Voice command to start autonomous patrol. Only default patrol path can be activated by voice.
3	Stop patrol	"Alexa, ask robot Scout to stop patrol."	Voice command to stop autonomous patrol. Scout is expected to go back to its charging station autonomously.
4	Leave the charging station	"Alexa, ask robot Scout to leave the charging station."	Scout will come out of its charging station.
5	Return to the charging station	"Alexa, ask robot Scout to return to the charging station."	Scout will go back to its charging station, if it can identify a right path.
6	Start	"Alexa, ask	Start video recording

	recording	robot Scout to start recording."	and store in local on-board flash.
7	Stop recording	"Alexa, ask robot Scout to stop recording."	Stop video recording.
8	Take photo	"Alexa, ask robot Scout to take a photo."	Take a photo and store in local on-board flash.
9	Turn left	"Alexa, ask robot Scout to turn left."	Make Scout turn left.
10	Turn right	"Alexa, ask robot Scout to turn right."	Make Scout turn right.
11	Move to the left	"Alexa, ask robot Scout to move to the left by	Move to the left. XYZ is a number. The default is 1inch.

		XYZ inch(es)."	
12	Move to the right	"Alexa, ask robot Scout to move to the right by XYZ inch(es)."	Move to the right. XYZ is a number. The default is 1inch.
13	Move forward	"Alexa, ask robot Scout to move forward by XYZ inch(es)."	Make Scout move forward. XYZ is a number. The default is 1 inch.
14	Move backward	"Alexa, ask robot Scout to move backward by XYZ inch(es)."	Make Scout move backward. XYZ is a number. The default is 1 inch.
15	Clockwise rotate	"Alexa, ask robot Scout	Make Scout rotate clockwise. XYZ is a

		to rotate clockwise by XYZ degree(s)."	number. The default is 45 degrees.
16	Counter-clockwise rotate	"Alexa, ask robot Scout to rotate counter clockwise by XYZ degree(s)."	Make Scout rotate counter clockwise. XYZ is a number. The default is 45 degrees.

Google Home Voice Commands

Google Home voice commands are the same as above, only with the wake word "Hey Google" or "OK Google". For example, "Hey Google, ask robot Scout to start patrol."

10. Add-on tools

Scout is also a robotic development platform. A UART

port is available on the top of the robot. Remove the metal panel, the UART port is accessible. One can use 3D printing to design new tools for Scout. From LED torch, to toy gun, to robotic arm. Only the imagination is the limit. Complex tools may require C/C++ programming. Scout's robotic control layer is open source. For serious developer, please contact us for more information.

11. Contact us

If you need help, please don't hesitate to contact us

12. Disposal of the Device (Environment)

At the end of the product life cycle, you should not dispose of this product with normal household waste. Take this product to a collection point for

the recycling of electrical and electronic equipment.

Please contact your local authorities in case you need more information on the collection points in your area.

13. FCC regulations

FCC Part 15

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the Federal Communication Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful interference in the residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TA technician for help.

Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept an interference received, including interference that may cause undesired operation.

Caution: To maintain compliance with the FCC's RF exposure guideline, place the unit at least 20cm away from nearby persons. To ensure safety of users, the FCC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with the FCC criteria.

Warning

Changes or modifications, to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The Socket-outlet shall be installed near the equipment and shall be easily accessible.

14. Technical Specifications

Communication

Dual-band 2.4G/5G Wi-Fi 802.11 a/b/g/n

Power Supply

USB 5V, >2A

Battery

Battery Type: 18650 Rechargeable Li-ion

Battery

Battery Capacity: 2000mAh (expected to operate for >2 hours, without Night Vision)

Camera

Sensor: 2M Pixel CMOS (1080P)

Angle: Wide Angle 120 degree

Night Vision: IR Infrared (mechanical IR cut)

Audio

1W Speaker

1x Microphone

CPU

Quad-Core ARM A7 @1.2GHz

512MB LPDDR III

4GB eMMC Storage

OS

Linux + ROS

Motors & Wheels

4x high-speed DC motors

4x novel Mecanum wheels

Sensors

6DoF IMU

Light sensor

ToF (Time to Flight)

Waterproof

IP65 (Splatter-proof)

Maximum Speed

~2km/h or ~1.2miles/h

Operating Temperature -10C to 45C