
User Manual

1. Summary

This retro arcade game has an exquisite appearance, unique design, and sensitive directional control.

2. Functional characteristics

2.1 Configure an 8-inch TFT screen.

2.2 Built in multiple games (provided by the customer, game combinations are subject to the latest customer requirements).

2.3 Buttons: joystick (up, down, left, right), START button, SELECT button, MENU button, power switch, volume switch, A, B, X, Y, L1, R1.

2.4 Interface: Type-C female head powered by 5V.

2.5 Supports two USB-A interfaces and can be plugged into a wired controller.

2.6 Built in 8 Ω 3W large speaker.

2.7 Volume Adjustment.

3. Product diagram



4. Instructions for use

- 4.1 Press down the power switch to turn on the device.
- 4.2 Enter the game directory and select games up and down using the joystick.
- 4.3 Press the "A" key to enter the game.
- 4.4 Pressing the "A" key in the game is to fire bullets.
- 4.5 The joystick is directional control.

5. Game switching

- 5.1 To switch games in the game, press the "MENU" key and select "Exit" from the menu to exit.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning:

The device has been evaluated to meet general RF exposure requirement.