



# Neckband Headphones



USER MANUAL

PACKING LIST



XS

XS

S


S

M


M

L

L




DIAGRAM



HOW TO PAIR

< Settings Bluetooth

Bluetooth



1

1-2s


< Settings Bluetooth

Bluetooth

DEVICES

Flexus NE1


Connected



2

5-7s

< 1m



1 First use

1. Turn on the Bluetooth function on your phone.

2. Power it on, then it will enter the pairing mode automatically. Red and blue lights will start flashing alternately with the voice "Pairing"

3. Search for the Bluetooth devices and select "Flexus NE1"(Enter the code "0000" if needed).

4. When pairing is successful, you will hear the voice "Connected".

2 Pair to another device

1. In the state of shut-down, press and hold on the MFB button for 5-7 seconds or so. Do not release it until the red and blue lights start flashing alternately with the voice "Pairing".


2. The rest goes the same as above.

POWER ON / OFF

LED


Power on


1-2s




Power off

5-7s





PLAY / PAUSE / ANSWER / HANG UP / ACTIVATE SIRI / REJECT / REDIAL




Double Click

Redial

Click Once

x1




Triple Click


x3

Siri

Hold on (1-2s)




VOLUME CONTROL / MUSIC CONTROL




Click Once

x1




Hold on (1-2s)




Click Once


x1




Hold on (1-2s)




CHARGE BATTERY




Output : 5V




LED




1H







MUTE




(Call mode)




Mute / Unmute



Hold on 1s



CORRECT DISPOSAL OF THIS PRODUCT

 ( Waste Electrical& Electronic Equipment )

This Marking shown on the product or its literature, indicate that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contact. This product should not be mixed with other commercial wastes for disposal.

NOTIFICATION

1. Please fully charge it if it was going to lay idle for a long time and place it in a cool and dry place. Please recharge it each 2 months for storage.

2. Please fully charge it for the first use.

FCC STATEMENT

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.