



Model Number:Leisure 3

**CONTENTS**

- PACKING LIST ..... 1
- NOTICE ..... 1
- FUNCTION OVERVIEW ..... 2
- QUICK START ..... 3
- PROJECTOR CONNECTION ..... 4
- PROJECTION DISTANCE&SIZE ..... 4
- WIFI CONNECTION ..... 5
- MULTIMEDIA CONNECTION ..... 5
- Projecting from a USB Disk/Memory Card ..... 5
- Projecting from HDMI Input Connection ..... 6
- Projecting from VGA Input Connection ..... 7
- Projecting from AV Input Connection ..... 7
- SCREEN MIRRORING ..... 7
- For iOS System ..... 7
- For Android system ..... 8
- SCREEN CASTING (For iOS System Only) ..... 8
- SETTINGS ..... 10
- UPDATING THE PROJECTOR TO THE LATEST VERSION ..... 11
- SPECIFICATION ..... 14
- TROUBLESHOOTING GUIDE ..... 15

**PACKING LIST**

LEISURE 3  
Remote (Batteries Not Included)  
User Manual  
AV Cable  
Power Cable

**NOTICE**

**Recommended**

**NOT Recommended**

support@vankyo.com

**FUNCTION OVERVIEW**

**QUICK START**

**PROJECTOR CONNECTION**

**PROJECTION DISTANCE&SIZE**

\* The recommended projection distance varies with different projection contents. Please adjust the distance between the wall/screen and the projector properly as needed.  
\* Ambient darkness will improve the clarity of the projected image.

**WIFI CONNECTION**

- Go to **Homepage** → **Setup** → **Network** → **WiFi**, then select **Scan** to display the WiFi list.
- Press the **Up** button to select your WiFi, then press the **OK** button to continue.
- Enter the correct password, then select **Confirm** to get internet connection.

**MULTIMEDIA CONNECTION**

**Projecting from a USB Disk/memory card**

- Turn on the projector and insert your USB disk/memory card into the USB port/memory card slot.
- Go to **Homepage** to select **Media**, it will display an interface for projecting from a USB disk/memory card.

**Projecting from HDMI Input Connection**

- Turn on the projector, then connect the projector to your device with the provided HD cable.
- Go to **Homepage**, then select **Source** → **HDMI** to project the contents from your device to the screen/wall.

**Different File Formats Supported**

Text Format Supported	TXT
Photo Format Supported	BMP/JPG/PNG/GIF/PEG
Audio Format Supported	ACC/MP2/MP3/PCM/FLAC/WMA
Video Format Supported	AVI/MP4/MKV/FLV/MOV/WMV/SOP/MPEG1/MPEG2/H.264/VID

**Projecting from AV Input Connection**

- Turn on the projector, then connect the projector to your device with the provided AV cable.
- Go to **Homepage**, then select **Source** → **AV** to project the contents from your device to the screen/wall.

**Projecting from VGA Input Connection**

- Turn on the projector, then connect the projector to your device with the provided VGA cable.
- Go to **Homepage**, then select **Source** → **VGA** to project the contents from your device to the screen/wall.

**Projecting from AV Input Connection**

- Turn on the projector, then connect the projector to your device with the provided AV cable.
- Go to **Homepage**, then select **Source** → **AV** to project the contents from your device to the screen/wall.

**SCREEN MIRRORING**

**For iOS System**

- Connect your iOS device and the projector to the same WiFi network.
- Go to **Homepage** → **iOS Cast** to display the following interface.

**For Android system**

To activate this function, please make sure your android device supports **Multi-Screen/Wireless display**. Names may differ from different Android devices.

- Turn the **WiFi** to **ON** status in the settings of your Android device. To make a smoother streaming, please do not connect to any WiFi on your projector.
- Go to **Homepage** → **Miracast** to enter the following interface.

- Activate **Multi Screen** function in your Android device and search for the projector.
- Select **ZiCast** (xxxxxx) from the searching list.
- Your Android device display will be projected on the wall/screen.

**Note:** An extra HDMI adapter is needed when mirroring your device through wired connection.

**SCREEN CASTING (For iOS System Only)**

- Connect your iOS device and the projector to the same WiFi network.
- Select **Setup** on the homepage, enter **Advanced** → **iOS Play Mode**, then press the right button on the remote to select **screen casting** HD/SD.
- Go to **Homepage** → **iOS Cast** on the projector.
- Launch a video player on your iOS device and select a video to play.
- Tap **+** → **AppleTV** (xxxxxx) → **ZiCast** (xxxxxx) to cast the video on your iOS device to the wall/screen via the projector.

**Tip:**

- Once the video is casted to the wall/screen, you can close the app and do other things without interrupting the video as long as your iOS device is still connected.
- Always connect your projector to power.

**SETTINGS**

Go to **Homepage** → **Setup** to adjust the settings of your projector.

**Network**

Connect the projector to your WiFi.

**Projection**

Set up projection mode.

**Advanced**

Change language, select boot source, set up sleep timer, update firmware, make a factory restore, etc...

**Information**

Check the model number, memory, software version, etc...

**UPDATING THE PROJECTOR TO THE LATEST VERSION**

**Step 1:**

Go to **Setup** → **Network**, then select your WiFi and input the correct password.

**Step 2:**

Go to **Advanced** → **Online Update**, then press **OK** on the remote to continue.

**Step 3:**

Select **Confirm** and press **OK** to start downloading the latest software.

**Step 4:**

You will see a percentage on the top left corner of the screen which shows the upgrade process.

**Step 5:**

The projector will be dim for a few seconds, then it will display the progress bar that shows the upgrading process.

When the progress bar reaches 100%, the projector will restart automatically, which means the software has been updated successfully.

**Tip:**

If the updating failed due to unstable network connection, please reboot the projector and repeat the steps mentioned above.

**SPECIFICATION**

<b>Display Technology</b>	LCD	<b>Light Source</b>	LED
<b>Resolution</b>	Native 1280 x 720	<b>Input Signal</b>	576i/576P/720i/720P/1080i/1080P
<b>Installation Type</b>	Front/Rear/Ceiling	<b>Aspect Ratio</b>	4:3/16:9/Auto
<b>Focus</b>	Manual	<b>Keystone</b>	±15°
<b>Speakers</b>	2W/8ohm x 2	<b>Power Supply</b>	AC 100-240V, 50/60Hz
<b>Unit Dimension</b>	198 x 148.6 x 68mm (7.8 x 5.9 x 2.7 inches)	<b>Unit Net Weight</b>	0.9kg(1.98lb)
<b>Photo Format Supported</b>	BMP/JPG/PNG/GIF/PEG	<b>Audio Format Supported</b>	ACC/MP2/MP3/PCM/FLAC/WMA
<b>Video Format Supported</b>	AVI/MP4/MKV/FLV/MOV/WMV/SOP/MPEG1/MPEG2/H.264/VID	<b>Ports</b>	HD In x 1/USB Port x 1/ VGA Port x 1/AV In x 1/ Audio Out x 1/ Memory Card Slot x 1
<b>Mounting Screw</b>	M4 Metric	<b>Number of Screw</b>	1

**TROUBLESHOOTING GUIDE**

- The content from Hulu, Netflix, and similar services can not be mirrored or cast?  
\* Due to the copyright restriction from Hulu, Netflix, and similar services, the contents MAY NOT be mirrored or cast.
- What should I do if I want to watch the content from Hulu, Netflix, and similar services via the projector?  
\* Please prepare a Fire TV stick, Roku stick or Chromecast (not included), then connect it to the projector to watch the content.
- Blurry Image  
\* Adjust focus ring/keystone.  
\* Projector and screen/wall must be in effective distance.
- Remote Unresponsive  
\* Make sure remote points at IR receiver directly.  
\* Don't cover IR receiver.  
\* Try a new pair of batteries.
- Upside Down Images  
\* Go to **Home** → **Setup** → **Projection** → **Projection Mode** to flip the projection image.

**FCC Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
—Reorient or relocate the receiving antenna.  
—Increase the separation between the equipment and receiver.  
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
—Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

**ISED/C Warning**

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:  
(1) This device may not cause interference.  
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.  
L'opération est autorisée aux deux conditions suivantes:  
1) L'appareil ne doit pas produire de brouillage.  
2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment complies with radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Le présent appareil est conforme  
Après examen de ce matériel au conformé ou aux limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité et compliance d'acquies les informations correspondantes. La distance minimale du corps à utiliser le dispositif est de 20cm.

**CAUTION**

To avoid replacement of a battery with an incorrect type.  
Don't dispose of batteries into fire or hot water, or mechanically crush or cut a battery.  
Don't leave a battery in an extremely high temperature surrounding environment.  
To avoid battery subjected to extremely low air pressure.  
The main plug is used as the disconnect device, the disconnect device shall remain readily operable.

The symbol indicates for indoor use only.  
 Class II equipment.  
 The symbol indicates DC voltage.  
 The symbol indicates AC voltage.

**RECYCLING**

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EC in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give this product to a competent recycling organization or the retailer when he buys a new electrical or electronic equipment.  
This product can be used across EU member states.  
The device is low power device, it can meet the requirement of the RF exposure.