


USER MANUAL

V800P Projector



- Email: contact@projectorcs.com -
Please read this manual thoroughly before using and keep it for future reference.

V.I.D.

Thanks for choosing our product.
If you have any concerns or need any help,
please contact us at
contact@projectorcs.com

CONTENTS

TROUBLESHOOTING GUIDE	01
IN THE BOX	02
PRODUCT OVERVIEW	03
QUICK START	04
1. Projector Installation	04
2. Power On/Off	04
3. Setup Wizard	05
4. Image Adjustment	06
5. Play Contents from Officially Licensed Apps like Netflix, Prime Video and YouTube	09
PROJECTOR CONNECTION AND INPUT SOURCE	10
1. USB Connection	10
2. Wired Speaker and Headphones Connection	11
WIFI CONNECTION	12
SCREEN MIRRORING	12
For Android System	12
For iOS System	13
Home Share	16
BT CONNECTION	17
1. Use as a BT Speaker	17
2. Connect to an External BT Speaker	18
SETTINGS	20
PROJECTION DISTANCE AND SIZE	22
EXPLANATION OF APPS	22
SPECIFICATION	24

TROUBLESHOOTING GUIDE


1. Can't directly use Netflix on the projector?
*Yes, you can. The projector comes with preinstalled and officially licensed Netflix/YouTube/prime video apps. You have the convenience of watching your favorite videos directly on the projector without any hassle.
*Due to the copyright restriction from Hulu, Disney+, and similar services, the content MAY NOT be mirrored or cast. To play copyrighted content, please prepare a laptop, Fire TV Stick, Roku stick, or Chromecast™ and connect to the projector.
2. The copyrighted contents from Hulu, Disney+ and similar services can not be mirrored or cast.
*Due to the copyright restriction from Hulu, Disney+, and similar services, the content MAY NOT be mirrored or cast. To play copyrighted content, please prepare a laptop, Fire TV Stick, Roku stick, or Chromecast™ and connect to the projector.
3. Blurry image
*Adjust the focus/keystone.
*The projector and screen/wall must be in the effective distance.
4. Why doesn't the remote control work?
*Make sure the remote points at the IR receiver directly.
*Please make sure you have installed two AAA batteries in the remote control.
*Avoid mixing new batteries with old ones in the remote control as this can result in insufficient power supply and operational issues.
5. Uppside-down image
*Go to Homepage - Settings (⚙️) -> Projection to flip the projection image.
6. Factory reset
*Go to Homepage - Settings (⚙️) -> Setup -> Reset Default to restore the projector to default settings.
7. Can't sideload Android Apps onto the projector?
*Sorry, you cannot sideload Android apps onto the projector.

contact@projectorcs.com

8. How to solve the black spot in the picture?


8. How to solve the black spot in the picture?
*It can be easily removed. Please scan the QR code on the back of the remote to get the video or content us for a video to solve it.
9. Auto Focus/Keystone is not working.
*Please restore the projector to factory settings and try again. If the issue still persists, please send a video to our service team by email for assistance.
10. The picture is not bright enough.
*To enjoy the best viewing experience, we suggest using it in a dark environment. The darker the room, the better the image.

IN THE BOX



contact@projectorcs.com

PRODUCT OVERVIEW




Notes:
* 2 AA batteries (not provided) are required.
* Make sure the remote is directly pointed at the IR receiver.


contact@projectorcs.com

QUICK START

1. Projector Installation



2. Power On/Off



contact@projectorcs.com

contact@projectorcs.com

3. Setup Wizard

Follow the setup wizard to choose your preferred language, select the correct region, establish a WiFi connection, and access the homepage.




Tip:
To ensure successful Wi-Fi search, please select the correct region.

contact@projectorcs.com

4. Image Adjustment

FOCUS

1. Auto Focus
When the projector detects shaking/rapid movement, it will automatically adjust the image quality.



Tip:
You can go to Homepage - Settings (⚙️) -> Focus to enable Auto Focus After Boot, allowing the projector to automatically adjust the focus after it is powered on.

2. Electric/Manual Focus
You can also press the Focus buttons on the remote or go to Homepage - Settings (⚙️) -> Focus -> Manual Focus to sharpen the image focus until the blurry image becomes clear.

contact@projectorcs.com


contact@projectorcs.com

Image Scaling

Tip:
You can enable more automatic features by going to Homepage - Settings (⚙️) -> Keystone. Auto Correction After Boot: Automatically corrects vertical distortion after the projector is powered on. Auto Screen: Automatically adjusts the projected image to match your screen. Auto Avoid: Automatically detects and avoids obstacles in specific areas. In case the Auto Avoid/Keystone is not performing optimally, you can achieve the desired effect by adjusting the keystone focus.

2. Manual Keystone Correction

Go to Homepage - Settings (⚙️) -> Keystone -> Four Points Correction to manually correct the image shape by four points.





contact@projectorcs.com

contact@projectorcs.com

5. Play Contents from Officially Licensed Apps like Netflix, Prime Video and YouTube

Go to Homepage - Settings (⚙️) -> Zoom to reduce or enlarge the image size between 50% and 100%.



Go to the Homepage and select your preferred platform via the shortcuts on the remote, then log in to your account to play the corresponding content.

contact@projectorcs.com

PROJECTOR CONNECTION AND INPUT SOURCE

Connect your device to the projector correctly, then select the right input source.

1. USB Connection

To play files stored on a USB disk, insert the disk into the projector. Then go to Homepage -> Inputs (⌂) and select USB to play the desired file directly.




Photo Format Supported	JPG/PNG/IMG/JFIF/PSD
Audio Format Supported	OGG/AAC/MP3/FLAC/WAV
Video Format Supported	MKV/MP4/FLV/MOV/MPG/3GP/MPEG1

2. HD Connection


To connect a device with an HD output port to the projector, use the provided HD cable to connect it to the projector's HD input port. Then go to Homepage -> Inputs (⌂) and select HDMI/HDMI2.

contact@projectorcs.com

contact@projectorcs.com

WIFI CONNECTION

You can connect your projector to your router's WiFi by going to Homepage - Settings (⚙️) -> Network.



SCREEN MIRRORING

Important Note:
Copyrighted content from Hulu, Disney+, or other similar streaming services CANNOT be wirelessly mirrored or cast due to copyright restrictions.

For Android System


To activate this function, please make sure your Android device supports Multi-screen/Smart View/ Wireless Display. Names vary on different Android devices.

Step 1:
Go to the WiFi setting of your Android device to switch on the option of WiFi.

contact@projectorcs.com

Image Scaling

Go to Homepage - Settings (⚙️) -> Zoom to reduce or enlarge the image size between 50% and 100%.



Go to the Homepage and select your preferred platform via the shortcuts on the remote, then log in to your account to play the corresponding content.


Step 1:
Connect the projector and your mobile device to the same router's WiFi.

contact@projectorcs.com

Screen Mirroring

Note:
Copyrighted content from Hulu, Disney+, or other similar streaming services CANNOT be wirelessly mirrored or cast due to copyright restrictions.

Step 2:
Go to Homepage -> My Apps (📱) -> ScreenCast to enter the interface below.




Tip:
You will need to download the ScreenShare app for the initial setup. Afterward, you can skip this step. After downloading the ScreenShare app, please reboot the projector to ensure the proper functioning of the app.

contact@projectorcs.com


contact@projectorcs.com

Screen Mirroring

Step 3:
Go back to the My Apps page, and then launch the ScreenShare app to enter the following page.



Step 4:
Go to the Control Center of your iOS device, then tap Screen Mirroring/Air Playing to search for the projector.




Step 5:
Choose Projector from the list, and once the connection is successful, the content on your iOS device will be mirrored onto the projector screen or wall.

contact@projectorcs.com

Home Share

Step 1:
Connect the projector and your mobile device to the same router's WiFi.



Step 3:
Launch a video player App on your mobile device and select a video to play.

Step 4:
Tap ⌂ to search for the projector and select Projector to connect. The contents on your device will be cast to the wall/screen.

Tip:
When you cast a video from your mobile device, the video will only be displayed on the projected screen and you can still use your mobile device without interrupting the video or showing any of your other content.

contact@projectorcs.com


contact@projectorcs.com

BT CONNECTION

1. Use as a BT Speaker

It is possible to use this projector as a BT speaker by connecting your mobile device to it through a BT connection.

Tip:
Ensure the projector's BT is enabled by going to Homepage - Settings (⚙️) -> BT.



Step 1:
Go to Homepage -> My Apps (📱) -> BT Speaker to make the projector ready for a BT connection.




Step 2:
Access your mobile device's BT settings and activate BT. Search for Projector in the available devices list to pair your mobile device with the projector.

contact@projectorcs.com

BT Connection

Step 1:
Turn on your BT device and make it ready for a BT connection.

Step 2:
Go to Homepage - Settings (⚙️) -> BT to scan available BT devices, then select your BT device and pair it with the projector.



contact@projectorcs.com

contact@projectorcs.com

Important:
Compared with the wired connection to a speaker, BT wireless connection spends more time processing digital audio data, converting said data to an audio signal, and streaming the signal. There may be a delay or slight lag on audio due to signal interference. As a result, the sound on the speaker may not be in sync with the image on the projector, especially when you are using wireless screen mirroring with WiFi and BT wireless connection at the same time. If you are experiencing this situation, please check the following options to improve audio quality:
* Instead of using wireless screen mirroring with WiFi and BT wireless connection at the same time, we recommend using wired screen mirroring and BT connection using HD connection via the provided HD cable and BT connection simultaneously. If you still want to use wireless screen mirroring, it is recommended to output the audio to a wired speaker.
* Move your BT device closer to the projector.
* Keep the projector and your BT device away from other BT devices to avoid interference.
* You may be able to adjust the latency (lip sync) on your device which is playing the video. The way to adjust the latency varies with different devices; please consult it from the device manufacturer.
* Due to the compatibility issue between BT speakers/headphones and the projector, few BT devices may not be paired with the projector via BT wireless connection. Please contact us at support@vankyo.com for further assistance.

contact@projectorcs.com

SETTINGS



Setup (⚙️)
1. Set the projector's language.
2. Adjust the date and time settings.
3. Set the screen to automatically activate screensaver after a specific period of inactivity.
4. Set the screen turn-off timer.
5. Set the screen to automatically turn off after a specific period of inactivity.
6. Update the software as needed.
7. Restore the projector to the factory settings.

Picture Mode (🖼️)
Select the picture mode and adjust the image preferences such as color temperature, contrast, etc.

Audio (🔊)
1. Set your preferred sound style such as wild, movie, etc.
2. Choose the correct digital output mode.
And more.

contact@projectorcs.com

contact@projectorcs.com

BT Connection

Connect the projector to an external BT speaker.

Network (🌐)
Connect the projector to a working WiFi network.

Projection (📐)
Select the appropriate projection mode to ensure accurate image projection.

Keystone (📐)
1. Enable the projector to automatically correct the keystone after it is powered on.
2. Enable the projector to automatically correct the keystone after it is moved.
3. Enable the projected image to automatically match the screen.
4. Enable the projector to automatically avoid obstacles.
5. Correct the keystone manually.

Zoom (📐)
Modify the image size between 50% and 100%.

Focus (📐)
1. Enable the projector to automatically adjust the focus after it is powered on.
2. Enable the projector to automatically adjust the focus after it is moved.
3. Adjust the focus manually.

About (ℹ️)
1. Check version info, license info, and device temperature.
2. Rename the projector.

contact@projectorcs.com


PROJECTION DISTANCE AND SIZE



* The recommended projection distance varies with different projection contents. Please adjust the distance between the wall/screen and the projector as needed.
* Ambient darkness will improve the clarity of the projected images.
* It is recommended to maintain a distance of 6.5-8.2 feet with an image size ranging from 70 to 90 inches.

EXPLANATION OF APPS


1. You can't download the apps on the APP STORE platform, but you can log into your account to watch the content directly.




contact@projectorcs.com

contact@projectorcs.com

2. You can download the apps in the APP ASSISTANT and log into your account to watch the content directly.



3. After downloading the apps, return to the homepage, pull down to find the corresponding app, and open to view its content.



contact@projectorcs.com

SPECIFICATION

Display Technology	LED	Light Source	LED
Resolution	Native 1920 x 1080P	Input Signal	576i/576P/720i/720P/1080i/1080P
Installation Type	Front/Rear/Ceiling	Aspect Ratio	16:9
Focus	Auto and Electric/Manual	Keystone	Auto and Electric/Manual
Unit	8W x 2	Power Supply	AC 100-240V~50/60Hz, 150W
Speaker	11.9 x 9.3 x 4.9 inches (302 x 237 x 125 mm)	Gross Weight	7.97lbs (3.613kg)
Photo Format Supported	JPG/PNG/BMP/GIF/JPEG	Audio Format Supported	OGG/AAC/MP3/FLAC/WAV
Video Format Supported	MKV/MP4/FLV/MOV/MPG/3GP/MPEG1	Ports	HD in x 2 / USB x 1 / Audio Out x 1
Mounting Screws	M5	Screw Number	4(not included)

contact@projectorcs.com

contact@projectorcs.com

FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISDEC Warning

This device complies with industry Canada licence exempt RSS standard(s). Operation is subject to the following two conditions:
(1) this device may not cause interference, and
(2) this device must accept any interference, including interference that may cause undesired operation of the device.
Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
The device is compliance with RF exposure guidelines, users can obtain Canadian information on RF exposure and compliance. The minimum distance from body to use the device is 20cm.
L'appareil est conforme aux directives d'exposition aux RF. Les utilisateurs peuvent obtenir des informations canadiennes sur l'exposition aux RF et la conformité. La distance minimale du corps pour l'appareil est de 20cm.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Cet émetteur ne doit pas être co-localisé ou fonctionner en conjonction avec une autre antenne ou un autre émetteur.
Operation of this device in the band 5150-5250 MHz is restricted to indoor use only for non-commercial use. L'opération de cet appareil dans la bande 5150-5250 MHz est limitée à une utilisation en intérieur uniquement.
R1C16E 02471-02015



contact@projectorcs.com

contact@projectorcs.com