


Tiny Remote Control User Guide

Key Introduction



Compatibility

1. This Remote Control is designed for OBSBOT Tiny **only**.
2. Support controlling up to 4 OBSBOT Tins at the same time.
3. Compatible with Windows and Mac OS computer.
4. Compatible with OBSBOT TinyCam App V0.1.27.1 and above.

Required

TinyCam x1

AAA battery x2

Tiny remote control x1

Download TinyCam here : <https://www.remo-ai.com/download>

Before you use

1. Put two batteries into the remote control.
 2. Plug the USB receiver to your PC.
 3. Connect Tiny to your PC.
 4. Open TinyCam, enable remote control in the [System Setting].
- *NOTE 1: Turning on the Remote Control **will** cause some keys on the PC's keyboard to not work properly. It is normal. Turning it off, the keyboard **will** work.
- *NOTE 2: Ensure TinyCam is at the top of other applications on the computer desktop.

Package Include

Tiny Remote Control

USB Receiver

User Guide

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.