


# Thank You For Choosing Bluetooth Earphone

## User Manual

### Product Display



### Earphones Specification

Bluetooth Version: V5.0	Working Frequency: 2.402GHz-2.480GHz
Bluetooth Distance: >=10M	Waterproof Rating: IPX5
Battery: Polymer Battery 3.7V, 50mAh	Charging Box: 3.7V, 500mAh
Charging Time: 1H for Earphones, 1H for Charging Case	
Playing Music/Call Time: 5 Hours (depends on music style and volume)	
Supporting Protocol: A2DP 1.3/AVRCP 1.6/AVDTP 1.3/AVCTP 1.4/GAVDP 1.3/HFP 1.7 HSP 1.2/SPP 1.2/GATT 1.0	

### Basic Operation

1. Power on: Open Lid and earbuds boost up automatically, or long press MFB for 3s, there is a "power on" prompt tone.
2. Power off: Put back to case and close lid, earbuds are automatically off, or long press MFB for 5s, there is a "power off" prompt tone.
3. Single Click: Left earbuds (L) Volume Down, Right earbuds (R) Volume Up. There is a beep at maximum or minimum volume.
4. Double Click: Play/Pause; Answer Call/Hang up Call; Reject call when on calling mode.
5. Triple Click: Left earbuds (L) Skip Back, Right earbuds(R) Skip forward.
6. Voice Assistance: Long press Left(L) for 2s to wake up Siri with a beep, Long press for 2s to exit Siri with a beep
7. Game Mode: Long press Right (R) for 2s, prompt "Beep Game mode" to enter game mode; Long press for 2s, prompt "Music mode" to enter music mode.
8. Factory Reset: Earbuds on and unconnected, quickly click MFB for 5 times to clear pairing data, both earbuds LED lights are on, automatically off after 3s. Put earbuds back to charging case, close lid, open lid and connect again.

### Bluetooth Pairing Instructions

1. After using for a period of time, the contacts are oxidized, earbuds cannot be charged or turned on. First, use a alcohol and cloth to clean the contacts and the two thimbles in the charging compartment to solve the problem.
2. Connect to device: both earbuds light go off when connected to device. Search for bluetooth name "MD012", click and connected.
3. Can I replace the battery of earphone? No, this earphone uses a non-removable battery.
4. Automatically connect back: After the first connection is successful, earbuds will connect to the last paired phone by default.

#### Maintenance:

##### You can use this earphone while driving, but it is not recommended to use a

##### Bluetooth headset while driving a minivan.

##### 4. Double Click: Play/Pause; Answer Call/Hang up Call; Reject call when on

##### calling mode.

##### 5. Triple Click: Left earbuds (L) Skip Back, Right earbuds(R) Skip forward.

##### 6. Voice Assistance: Long press Left(L) for 2s to wake up Siri with a beep, Long

##### press for 2s to exit Siri with a beep

##### 7. Game Mode: Long press Right (R) for 2s, prompt "Beep Game mode" to enter

##### game mode; Long press for 2s, prompt "Music mode" to enter music mode.

##### 8. Factory Reset: Earbuds on and unconnected, quickly click MFB for 5 times to

##### clear pairing data, both earbuds LED lights are on, automatically off after 3s. Put

##### earbuds back to charging case, close lid, open lid and connect again.

### Indicator Light Display

1. Power on: Indicator lights flash 3 times.
2. Power off: Indicator lights flash 1 time.
3. After a long period of non-use, please charge before use.
4. Please use a dry soft cloth to clean the earbuds.
5. After the earbuds are connected to a computer or mobile phone, near different sounds?
6. Because Bluetooth is a wireless technology, it is very sensitive to objects between the earphone and the connected device. Please check whether there is metal or other objects in the connection range that affect the connection.
7. After the Bluetooth earphone is connected to the mobile phone, can the earphone be used to control the applications on the mobile phone?
8. The software settings of device applications may be different, so that the functions of individual applications do not support the earphone controlling.

### Accessory List

Bluetooth earphones	X2
Charging compartment	X1
Charging Cable	X1
Spare ear caps	X2
User Manual	X1

### Notes on Charging

1. L&R earbuds Pairing: Left and Right earbuds auto pair, Master earbud quickly flash when pairing succeed, slave earbud light goes off.
2. The earbuds cannot be turned on?
3. Can I replace the battery of earphone?
4. Can I use the earphone while driving?
5. The earphone is disconnected from the phone?
6. Voice Assistance: Long press Left(L) for 2s to wake up Siri with a beep, Long press for 2s to exit Siri with a beep
7. Game Mode: Long press Right (R) for 2s, prompt "Beep Game mode" to enter game mode; Long press for 2s, prompt "Music mode" to enter music mode.
8. Factory Reset: Earbuds on and unconnected, quickly click MFB for 5 times to clear pairing data, both earbuds LED lights are on, automatically off after 3s. Put earbuds back to charging case, close lid, open lid and connect again.

### Common Problem

1. The earphone cannot be paired with the mobile phone?
2. The earbuds cannot be turned on?
3. Can I replace the battery of earphone?
4. Can I use the earphone while driving?
5. The earphone is disconnected from the phone?
6. Voice Assistance: Long press Left(L) for 2s to wake up Siri with a beep, Long press for 2s to exit Siri with a beep
7. Game Mode: Long press Right (R) for 2s, prompt "Beep Game mode" to enter game mode; Long press for 2s, prompt "Music mode" to enter music mode.
8. Factory Reset: Earbuds on and unconnected, quickly click MFB for 5 times to clear pairing data, both earbuds LED lights are on, automatically off after 3s. Put earbuds back to charging case, close lid, open lid and connect again.

### FCC Warning

1. The device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
2. When you put the earbuds back into the charging compartment, they will turn off and start charging; if you take it out again, they will automatically turn on and pair with each other automatically.
3. Automatically connect back: After the first connection is successful, earbuds will connect to the last paired phone by default.

#### Maintenance:

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

① Reorient or relocate the receiving antenna.

② Increase the separation between the equipment and receiver.

③ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

**Safety Problem:**

① As there is a battery in the headset, please try to keep this product away from high temperature areas.

② Please try to use qualified chargers and charging cables, and try to avoid using high current and voltage fast charging devices to charge this product.

③ The waterproof grade of this product is IPX5, please choose the appropriate scene to use this product.

**The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition with no restriction.**

## FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.