



JX11L
Bean TypeTWS



Instruction manual

Product Description



- 1: Multi-function touch button
- 2: Earbud indicator/microphone
- 3: Earbud cap
- 4: charging compartment indicator
- 5: charging thimble
- 6: Type-C USB charging port

1

Power on/off

Auto power on: Turn on the charging box and the headset will automatically turn on.

Manual power on: When the headset is off, press and hold the touch key for 3s to manually power on.


Auto power off: Put the earphone into the charging compartment and close the lid, the earphone will automatically shut down.

Manual power off: Long press the headset touch key for 5s to manually shut down.


Note: If it is not connected to any device within 2 minutes, it will automatically shut down.

Bluetooth pairing

- ❶ Open the charging compartment and take out the earbud to turn it on automatically.



- ❷ After turning on, put the left and right earphones close to each other. After the team is successful, the indicator light: the main earphone flashes red and blue lights alternately, and the other earphone flashes blue light once in 5s.




Blue light flashes once in 5s

Red and blue lights Alternate flashing

2

- ❸ Open the phone's Bluetooth connection interface, search for "JX11L", click pair, then the connection is successful and accompanied by a tone.

Music



- ▶ **Music pause/play:** During playback, click the multi-function touch key.
- ▶ **Previous song:** Double-click the left ear multi-function touch button.
- ▶ **Next song:** Double-click the right ear multi-function touch button.

Wake up voice assistant function

(requires mobile phone support)


- ▶ After successfully connecting with the mobile phone, except during a call, long press the left ear touch key for 3S to activate the voice assistant function (SIRI).

Game mode

- ▶ Long press the right ear for 3s to enter or exit the game mode.

3

Call



- ▶ **Answer:** When a call comes in, click the multi-function touch key.
- ▶ **Reject:** During a call, double-click the multi-function touch key.
- ▶ **Hang up:** During a call, double-click the multi-function touch key.

Headset restore factory settings

Double earphones simultaneously press and hold the 5S multi-function touch key, the red and blue lights flash 5 times at the same time, and the factory settings are restored successfully.

Charging

- ❶ The charging compartment is charged by the charging line, and after the full charging, the 4 indicator lights of the battery compartment should be on.
- ❷ The earbud is placed in the charging compartment, automatically charged, and the earbud indicator is off after being fully charged.

Earbuds charging	Red light is on
Earbuds is fully charged	Red light is off
Charging compartment is charging	Red light is light up in sequence
Charging compartment is fully charged	The light is always on

4

Specifications

- Model: JX11L
- Bluetooth version: 5.2
- Single earbud weight: 4.2g
- Earbud size: 20.8*18*24MM
- Earbud battery capacity: 3.7V/2*50mAh
- Earbud charging time: about 0.5 hour
- Play music time: about 6 hours(Medium volume)
- Support Agreement: SPP / HFP / A2DP / AVCTP / HID
- Frequency: 2.4GHz-2.48GHz
- Bluetooth distance: 10M
- Power input: DC 5V/500mA
- Charging case battery capacity: 3.7V/300mAh
- Charging bin to charge the earbud: 2 times
- Charging bin size: 54*36*28mm
- Charging bin weight: 33g

5

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Label

Bean Type TWS
Model: JX11L
FCC ID: 2A30A-BEAN