





Welcome to your Pana Pen

For more customizable settings, please download our driver




jupiter.com/support



Pairing




Wireless Charging



Pull

Nib Replacement

Refer to Pen & Windows Ink for single and double click settings



FCC Warning Statement:  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Reorient or relocate the receiving antenna.  
- Increase the separation between the equipment and receiver.  
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement.

Pana Pen and Pana Pen Charger Instructions for wireless charging  
1. Insert one end of the USB Type-C cable into the USB port of the computer and the other end into the Type-C mother seat of the Pana Pen Charger. Place the Pen magnet in the Pana Pen Charger and the Pana Pen enters the shutdown state. At this moment, Pana Pen Charger is charging the Pana Pen wirelessly, and the LED indicator of Pana Pen is red, indicating that Pana Pen has successfully received the wireless charging of Pana Pen Charger, and the overall wireless charging mode is completed. Pana Pen's LED indicator is green when fully charged;  
2. When the Pana Pen is taken out of the Pana Pen Charger, the Pana Pen automatically enters the power-on state, and the Pana Pen connects with the computer through the Pana Pen Charger through Bluetooth.  
Wireless communication interface: BLE 5.0  
Input current: 5V/450mA  
Wireless charging frequency: 160KHz  
Conversion efficiency: > 25%  
Induction distance: 2-2.2mm  
Maximum charging temperature: < 53°C (ambient temperature: 25°C)  
Charging time: 2.5-3.5 hours

Product Name:Pana Pen  
Model:Pana Pen IC  
Product Name:Pana Pen Charger  
Model:Pana Pen IC Charger