











SZIG:71x52mm

正面

<h3>Know about the sensor</h3>  <p>(1)</p>	<h3>1 Button</h3> <p>① Long Press: Press and hold the button for 5 seconds until the screen blinks, the device will enter pairing mode</p> <p>② Single-click: Wake device up (synchronize data on cloud server), if it is triggering sound alarm, click to make it to be mute</p> <p>③ Double-click: Cycle switching between °C and °F temperature unit.</p>  <p>(2)</p>	<h3>2 Screen</h3>  <p>(3)</p>	<h3>Quick Installation Guide</h3> <p>1. (If you have installed the smart life APP on your mobile phone, please go to step2) Scan below QR code or search Smart Life in APP Store or Google Play to install APP new user must register account first.</p>  <p>(4)</p>
<h3>2.Connect mobile phone to your 2.4GHz Wi-Fi router (with internet)</h3> <h3>3.Power on the sensor</h3> <ol style="list-style-type: none"> open the battery cover insert the battery into the battery compartment (please note battery positive and negative). close the battery cover <p>(5)</p>	 <p>(6)</p>	<h3>4.Device pairing</h3> <ol style="list-style-type: none"> Pressing the button for 5 seconds until the screen blinks. Run Smart Life APP, Click "+" at the top right corner and select "Add Device". It will be discovered automatically (The phone's Bluetooth should be enabled for discovering) as below, Click "Add" then follow the in-app instructions to connect the sensor to your network.  <p>(7)</p>	<p>③Waiting for a few seconds, This device is added successfully and you may rename it. Click "Done" to finish the setting.</p>  <p>(8)</p>

反面

<h3>5.Setting with Smart Life</h3> <h4>①Create scene</h4> <p>Click "Smart" to enter scene page and click "+" to add a new scene.</p>  <p>(9)</p>	 <p>(10)</p>	 <p>(11)</p>	<h3>②Other settings</h3> <p>Click "Set" to enter the device setting page. There are more options for adjusting the device, such as Unit Convert, Reporting period, Temp update sensitivity, Humidity sensitivity, Temp MAX and MIN setting, Humidity MAX and MIN setting, Enable/Disable alarm (include High humidity/Low humidity/High temperature alarm/Low temperature alarm/Low battery), Mute setting.</p> <p>Note: If you have changed the setting, please single-click the button to make it take effect (get the setting from cloud server).</p> <p>(12)</p>
<h3>6.Alarm description</h3> <p>It will sound and continue for one minute in interval of a minute when the temperature or humidity is over your setting.at the same time,it will push notification to app.</p> <p>Note: if the mute setting on app is enabled, there will be no any alarm information (include sound and notification)</p> <p>(13)</p>	<p>(14)</p>	<p>FCC Caution: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help. To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.</p>	