反面

# iSwift

# Snapods

Manual

Please read this manual carefully before using this product and keep it properly

---

- Anti-slide silicone
- Anti-drop Magnet
- Indicator light
- Charging probe type-c charging port
- Magsafe magnet contact
- Wireless charging coil
- Magsafe magnet contact

- Front vent
- Acoustic outlet
- Charging contact points
- Fixing magnet
- Rear vent
- Noise canceling Mic
- Indicator light
- Touch area
- Answering Mic

---

## Power On/Off

1. The earbuds will automatically turn on when taken out from the charging case and turn off when put in.

2.In the power-off mode, long press the touch area to power on. In the disconnected mode, long press the touch area to power off.

## Pairing

1.When first use, the earbuds will automatically turn on and go into pairing mode when taken out from the charging case.

2.Turn on Bluetooth on your mobile device, select "Snapods" from the list of available devices. The pairing will be complete when hear the voice reminder "Connected".

## Accessory description

Charging Case　Earbuds　Charging line　Iron sheet　Manual

---

---

## Instructions

1.Power on: the earbuds will be automatically turned on after taken out from the case. Long press the touch area if in off state.
2. Power off: put the earbuds into the case to charge and turn off. Long press the touch area to disconnect.It will shut down after 3 mins if not connected.
3. Pairing status: when there's no pairing record, the earbuds go directly into pairing state / when there's a pairing record, the earbud will automatically connect to the device and it will go back to pairing mode if failed to connect.
4. Turn on/Off Siri speech recognition: hit the left and right earbud 3 times
5. Previous/ next: long press left earbud/long press right earbud
6. Answer/ hang up the phone: touch once/ touch twice (works for either side)
7. Refuse an incoming call: long press the earbud (works for either side)
8. Play and pause: touch the earbuds twice quickly within 0.5s(works for either side)
9. Reset: click for 5 consecutive times when there's no connection. Restart the earbuds after shutting down. (take them from the charging case or long press the touch area). Reset complete when two earbuds are connected.
10. Volume+/Volume−: touch the right earbud once/touch the left earbud once.
It doesn't work if use in single earbud.
11. Android devices need to turn on the synchronization switch to make the earbuds volume can be synchronized with the phone volume.

---

## When charging the earbuds

When the battery is 100%, the LED1 LED2 LED3 will turn on about 4s and then turn off.
When the battery is 66%, the LED1 LED2 turn on about 4s and then turn off
When the battery is 33%, the LED1 will turn on about 4S and then turn off.
When the voltage is lower than 3.3V, the LED1 flashes continuously and rapidly, indicating that the charging case should be recharged in time as the electricity is too low.

## LED indicator

Power on: the red and blue lights are on for 1 second at the same time.
Turn off: the red light is on for 1 second.
Standby(no device connection): both earbuds flash blue light quickly
Standby(connected to a device): no flashing lights on two earbuds.
During the call: When the incoming call is alerted, the main earbud flashes twice in 3seconds; no lights are on during the call.
Charging: the red light is always on.
Charging completed: the blue light turns off for 10 seconds, and the light is no longer on.
Low voltage alarm: a light flashes in the charging case
Power-on reconnection status (connected): no light
Earbuds unpaired: red and blue light will flash
Reset completed: touch 5 times continuously, the red and blue lights will be on together, and then it will be automatically shut down

## When charging the charging case

LED1 flashes at 33% battery,
When the battery is 66%, the LED1 is always on and the LED2 flashes.
When the battery is more than 66%, the LED1 LED2 are alway on, the LED3 flashes until fully charged, then it stops flashing and always on .
At 100% battery, the LED1 LED2 LED3 are always on until you unplug the power cord or leave the wireless charger.

---

## Cue tone

| | |
|---|---|
| Power on | Voice reminder: Power on |
| Power off | Voice reminder :Power off |
| Connected | Voice reminder:Connected |
| Disconnected | Voice reminder: Disconnected |
| Enter pairing state | Voice reminder: Pairing |
| Answer calls | \ |
| Volume Max/Min | DUDU |
| Battery low | Voice reminder :Battery low |
| Reject a call | \ |
| Connected | DUDU |

## Guarantee card

Name: _____
Telephone: _____
Mailbox: _____
Postal code: _____
Address: _____
Equipment model: _____
Date of purchase: _____

---

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

· Reorient or relocate the receiving antenna.
· Increase the separation between the equipment and receiver.
· Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
· Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.