






# **COMPONENTS AND STRUCTURE** Machine Screv - Line 2.9m / 114.2in 1. The main light 2. Secondary light x 4 4. Rotary Union 5. Cover6. LED Light Source 7. Lamp Bracket





















**PREPARATION** 




PLEASE MAKE SURE YOUR WALL SWITCH AND POWER AT MAIN CIRCUIT BREAKER BOTH ARE OFF. IF IN DOUBT ABOUT ELECTRICAL INSTALLATION. CONSULT A LICENSED

ELECTRICIAN.

WARNING: INSTALLING THIS LIGHT IN AN UNGROUNDED ELECTRICAL SYSTEM MAY CAUSE THE METAL PARTS OF THE LIGHT TO CARRY CURRENT IF ANY WIRES OR WIRE CONNECTIONS ARE DAMAGED OR LOOSE. IN THIS CASE, ANYONE WHO TOUCHES THE LIGHT WILL RECEIVE AN ELECTRIC SHOCK, RESULTING IN INJURY OR DEATH.


BE CAREFUL NOT TO DAMAGE OR CUT THE WIRE INSULATION (COVERING) DURING INSTALLATION. DO NOT LET THE WIRES TOUCH ANY SHARP EDGES.





- 1. Connect the ground stake to each light.
- 2. Install the lights on the ground and adjust them to your desired angle. 3. Plug the adapter into the power supply.

## **B. Bracket Installation**



## STEP 1:

According to the spacing (see the "A" part of the picture) of two screw bits on the LED Light bracket, drill two mounting holes. STEP 2:

Put the bracket onto the prepared mounting holes and then screw it on.

Adjust the beam direction as you like, and then plug the adapter into the power supply.

### FCC ID: 2A3W8H05HCW

#### **FCC Warning:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses

and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

-Reorient or relocate the receiving antenna.

following measures:

-Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is

-Consult the dealer or an experienced radio/TV technician for help. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled

environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Manufacturer / Hersteller: Shen Zhen Shi Meng Zhi Tuo Ke Ji You Xian Gong Si Address: qian wan yi lu 1 hao A dong 201 shi qian hai shen gang he zuo qu Shen Zhen, Guang support@onforuled.com www.onforuleds.com

EU REP MDH LIGHTING LTD Suite 302, 292 Strovolos Avenue, 2048 Strovolos Nicosia, Cyprus | support@onforuled.com UK REP MDH LIGHTING LTD

69 Aberdeen Avenue, Cambridge CB2 8DL, United Kingdom | support@onforuled.com

Made in China