

LS说明书


尺寸: 80mm\*110mm




tranya.com/pages/register-product






















FAQ















nsure the following matters during monitoring:



In the Message interface, click the main screen to view the


the upper right to exit.

message, slide the screen to turn the pages. Press the button o

Note: Message reminder is just a function to remind you to receive

characters for IOS and Android per message).

a message. Its display interface will have character restrictions (80



solvent, propanol, alcohol or insect repellent.

SPECIFICATIONS application Once Fit Touchscreen 2.5D tempered glass anti-fingerprint coating

6. Please do not use this product in high pressure and high

nay cause skin allergy itching.

If you have sensitive skin or tighten the wristband, you may feel

B. Please dry the sweat drips on the wrist in time. The strap has lon

contact with soap, sweat, allergies or pollution ingredients, which

If it is often used it is recommended to clean the wristhand ev

t appropriate to wear a hot bath with a wristband. After

week. Wipe with wet cloth and remove oil or dust with mild soap. It

mming, please wipe the wristband in time so as to keep dry.

A: Please follow the instructions: (1) Install the "OnceFit" App in Google Play or App store and allow all authorizations required by OnceFit. 2) Make sure both of your watch and mobile phone Bluetooth are turned on. And it would be better that the distance between the mobile phone and the watch is less than 1m. (3) If the watch is not connected to the mobile phone through the OnceFit App, but directly through the Bluetooth search, please delete the watch "LS" from the Bluetooth list of your mobile phone. (4) If you want to connect to another new phone, please unbind the watch on the original phone through the OnceFit App first. (If the original phone is an iOS system you also need to delete the watch LS from the Bluetooth list of the phone). 2: Why can't the watch receive SMS / App information notification? Please follow the instructions: 1) Make sure that you have authorized the SMS/App

notification for the OnceFit App.

phone through the OnceFit App.

(2) Ensure that the watch is connected to the mobile


the phone normally?

Q: What should I do when my watch can't be connected

A. Please follow the instructions: (1) Make sure that you have authorized the SMS/App notification for the OnceFit App. 2) Ensure that the watch is connected to the mobile phone through the OnceFit App. Note: Some Android phones automatically close Apps runnin stopped by the system, the watch will not receive any nformation notification. through "Setting" in your phone. f you don't know how to set it, you can search "your mobile phone brand + how to keep the App running in the background?" on Google. O: Why is the time and weather on the watch incorrect? A: The time and weather of the watch are synchronized with your smart phone. Please make sure that your watch has been connected to your phone through the OnceFit App, and keep the

(2) At the same time, the "Location" of your mobile phone is

turned on.



can wash your hands with the smart watch.

Note: But be sure not to enter the steam room with your

watch. Such as sauna, hot spring, hot bath, etc.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.