

三合一无线充台灯英文说明书

100 mm

Product Introduction

Packaging Content

1*3 in 1 Wireless charger with desk lamp
1*C to C cable
1*Instructions

Installation Instructions

Installation instructions
*Please cut off the power supply before installation to prevent electric shock.

As the illustration, please make sure the accessories are inserted to the base properly before use.

Table Lamp Instructions

Brightness and color temperature adjustment.

- Touch the key points to control the light.
- Touch the dimming key with your fingers.

Brightness switch
Long press to adjust brightness.

Light delay-off button
Delay to turn off the light for approximately 60s.

Power Switch
Short press turn /off the lamp.

The lamp has a brightness memory function. In the powered state, the brightness will be recorded and will come back on the next time the lamp is turned on. However, if the power has been cut off, the previous brightness will not be recorded and the light will turn on with the default brightness.

When the light is on, each touch of the brightness switch will change the brightness of the lamp. The touch-sensitive buttons respond to your touch, EXCEPT FOR the following operations:

1. Touch with other objects than fingers, such as gloves, ballpoints, etc.
2. Touch is too slight and quick to be perceived.
3. Using the product in an unstable temperature environment.
4. When used in areas with complex external interference, proximity to the button may cause the button to react.

wireless charger Instructions

Using the wireless charger

- Connect mobile devices to the wireless charger
- Put mobile phone on the wireless charging area (a) to charge it, put AirPods on the wireless charging area (b) to charge it. You can also put iwatch on the wireless charging area (c) to charge it.

Indicator Light Identification

The indicator light display the wireless charger's status.

Indicator light	Status
After 3s of light on, it goes out	Power on
Blue light	Normal operation
Flashing blue	Foreign object detection

If the indicator light does not work as described, disconnect the adapter with the wireless charger and reconnect it.

The indicator light may work differently depending on the mobile device, wireless charging cover, or the Watch.

Product Parameters

Input	12V=3A
Light power	4W
Model.NO	TYH-60111
Wireless output(for Phone)	5W/7.5W/10W/15W
Wireless output (for AirPods)	3W
Wireless output(for iWatch)	2.5W

Note

1. Do not put this product into fire or heat it, and do not store it at high temperatures (recommended ≤ 95°F).
2. Do not drop or use hard objects to impact or damage this product.
3. Do not disassemble this product or internal components arbitrarily, do not change the internal structure of this product.
4. Do not immerse this product in water or other solvents, and do not use it after immersion.
5. Do not use unqualified equipment during charging and discharging, and follow the correct usage instructions.

700.00 mm

折叠尺寸：100mmX100mm
 展开尺寸：100mmX700mm
 材质：80g书写纸风琴折



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna