GETTING STARTED

Included in the box:

- Defigo answering device
- USB-C cable and adaptor
- Screwkit for for on-wall installation



Remove the answering device and adaptor from the box.
Plug the adaptor into a power socket, and the USB-C end of
the cable into the back of the answering device. This will
power the device. The device will automatically switch on.

2.



The first screen on the device will allow you to select your language from the dropdown options. Choose the language you would like to use, and press next.

3.



Select your WiFi from the options on the screen, enteryour WiFi password and then press next.

4.



Choose who will manage your answering device - you or the building administrator. If you are managing your answering device, skip to step 6.

5.



If your building administrator is managing your device, send them the number that appears on the screen. Once activated, skip to step 7.

6.



Select your region, then log in with your Defigo username and password. Your login credentials were emailed to you when you were added as a Defigo user.

7



You will now have an overview of the doors you can open. On the main screen you can open the door or hide your doorbell. 8.



You can now receive calls from the Defigo intercom. For more information, visit:

www.getdefigo.com/en/answering-device

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.