




MagBoost Portable Charger 5K Slide  
Model Number: TSB4260

## User Manual



### USER MANUAL MagBoost Portable Charger 5K Slide



1. Silicone hand strap
2. Power button
3. LED indicator for wireless charging
4. Power LED indicator
5. Type-C input & output

#### Product Specifications

Battery type : li-polymer Capacity : 5000mAh/18.5Wh  
Type-C input & output : PD18W (5V/3A,9V/2A,12V/1.5A)  
Wireless output : 15W Total output : 5V/3A (Max)

#### Wireless Charging

Snap the iPhone 12 on the MagBoost Portable Charger and then press the power button to activate wireless charging.



### USER MANUAL MagBoost Portable Charger 5K Slide

#### Charging by cable

Using the charging cable to connect your device with the Type-C output, the power bank will start to charge your device automatically, the white LED indicator show the remaining power.

#### Recharge the power bank

To recharge your power bank, it is recommended to use at least an 18W USB-C PD wall charger. Use the USB-C cable included to connect one end to the 18W USB-C PD wall charger and the other end to USB-C input port on the MagBoost portable charger. The portable charger will automatically start recharging and the LED indicators will start blinking.



- High Voltage Protection
- Input & Output Current Regulation
- Input & Output Short-Circuit Protection
- Device Overcharge Protection
- Battery Discharge Protection
- Output Temperature Control

### USER MANUAL MagBoost Portable Charger 5K Slide

#### One Year Warranty

Please email [Support@techsmarterusa.com](mailto:Support@techsmarterusa.com) to start the warranty process.

#### Warnings

1. Do not expose the power bank to excess humidity or liquids. It should be stored in a cool, dry place when not in use.
2. Do not damage or puncture the casing of the power bank. This may cause over-heating, fire or an explosion.
3. Do not expose the power bank to sources of heat, including radiators, stoves, or fires. Do not expose to ambient temperatures above 40°C, such as in a car on hot day, or in direct sunlight. Failure to do so may cause over-heating, fire, or explosion.
4. Do not use in a strong electrostatic or electromagnetic environment, including near microwaves as this may shorten the device's life.
5. If the power bank emits an odour, excessive heat or becomes discolored or distorted, please discontinue use immediately.

#### FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help
- This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.