




wireless power bank  
Model No.: TSB7300


### USER INSTRUCTION

- ① 4 LED Power Indicator Lights
- ② Micro USB input
- ③ Type-C Input/Output
- ④ USB output
- ⑤ Wireless output
- ⑥ Power ON/OFF
- ⑦ Suction Cups
- ⑧ Kick Stand




#### PRODUCT SPECIFICATION

PRODUCT SPECIFICATION	
Structure	
Model Number	TSB7300
Battery Capacity	10000mAh
Input	Micro USB Input: 5V/2A, 9V/2A USB-C Input: 5V/2A, 9V/2A
Output	USB Output 1&2: 5V/3A, 5V/4.5A, 9V/2A, 12V/1.5A (22.5W) USB-C Output: 5V/3A, 9V/2.3A, 12V/1.67A (20W) Wireless Output: 15W
Product Dimension	156x71.5x17.2mm
Weight	261g



Use micro cable or Type-C cable to charge power bank



Computer usb port



Charge the Android phone and iPhone



Charge mobile phone with wireless output

#### Minimum instruction for Use for Portable Power Banks

to be provided with portable power banks to the customer

1. The power bank will generate heat when charging. Always charge in a well ventilated area. Do not charge under pillows, blankets or on flammable surfaces.
2. Keep the power bank away from heat sources, direct sunlight, combustible gas, humidity, water or other liquids.
3. Do not disassemble, open, microwave, incinerate, paint or insert foreign objects into the power bank.
4. Do not subject the power bank to mechanical shock such as crushing, bending, puncturing or shredding. Avoid dropping or placing heavy object on the power bank.
5. Do not short-circuit the power bank or store it in a receptacle where it may be short-circuited by other metallic or conductive objects.
6. Do not operate the power bank if it has been wet or otherwise damaged, to prevent against electric shock, explosion and/or injury. Contact the dealer of authorized agent.
7. Power bank usage by children should be supervised.
8. Please read the operating instructions (including charging instructions and information on the minimum and maximum operating temperatures), supplied with this power bank.

#### Dispose Advice for Waste Power Bank

Battery cell in this power bank may cause certain damage to the environment. In order to protect our environment, please dispose of waste power bank properly.

#### FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

120.00

73.00