


尺寸: 90*90MM

材质: 120克书纸 单色印刷 骑马钉

HOUSBAY TS5 User Manual



(1 Year Warranty)

If a faulty product is found when setting up please Email us at
Support@keviec.com

Tips:

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

2. The clock works and lasts a few hours if it is powered by battery ONLY, please keep it plugged in always!

Thank you for purchasing from **HOUSBAY**! Please read these instructions carefully and keep the user manual in safe place for future reference.

1

Instructional Video

Please scan the QR code here to access the instructional video of this product.



2

Features

- 5 Alarm Sounds & 9 Minutes Snooze
- Bluetooth for Streaming Music and Synchronizing Time from phone
- 12 Colorful Night Light
- 0-100% Brightness Control For Display
- 0-30 Level Adjustable Volume
- True Battery Backup
- 12/24H Mode

Package Include


- 1*1.5m DC Adapter
- 1*User Manual

3

Power Specifications


AC 100-240V, 50/60Hz.
DC 5V/2A

Front View




4

Top View



6

Back View



7


Getting Started

Plug the adapter into a standard household outlet, you will see 7:00 on the display and the clock is ready to be set.

Notice:
If the display is "blank" after plugging in, please check whether the DISPLAY DIMMER on the back is at the HIGH position.


Time Setting

1.Press the button to enter HOUR setting. The HOUR digits flash on the display. Press the or button to advance to the correct hour.



8

2.Press the button to confirm and enter MINUTE setting. When the MINUTE digits flash, press the or button to advance to the correct minute.




3.Press the button to confirm and enter TIME FORMAT setting. Press the or button to select time format. When using the 12-hour time format, AM/PM icon appears on the display to suggest morning/afternoon time.

4.Press the button to confirm and exit the time setting mode.
Notice:
The clock will exit automatically from the TIME setup mode if no action is taken within 5 seconds. (Action refers to pressing the desired button for setup)


9

Alarm Setting

1.Press the button to enter ALARM HOUR setting. The HOUR digits flash on the display. Press the or button to advance to the desired hour.




2.Press the button to confirm and enter ALARM MINUTE setting. The MINUTE digits flash on the display. Press the or button to advance to the desired minute.



10

3.Press the button to confirm and enter WAKE UP SOUND setting. The icon of alarm flashes on the display. Press the or button to choose from 01) Bird chirping, 02)Ocean waves, 03)Brook sound, 04)Forest, 05) Beep sound.
When you set the WAKE UP SOUND, press the or button to select the ALARM VOLUME LEVEL. (0-30 adjustable)



4.Press the button to confirm and exit the alarm setting mode.

Notice:
The clock will exit automatically from the ALARM setup mode if no action is taken within 5 seconds. (Action refers to pressing the desired button for setup)

11

Wake-Up Light

When the preset alarm time comes, the wake-up light will light up with the alarm sound. Please note the following:

- 1.The wake-up light is preset and cannot be adjusted.
- 2.The wake-up light will turn on/off when the alarm is turned on/off.

Alarm Pause & Snooze

When the alarm and wake up light are on, you have two options:

- 1.Press the button to stop the alarm when it's ringing. Alarm will go off on the next day.
- 2.Press the button to snooze, the indicator flashes on the display. The alarm will go off again 9 minutes later.

12

Notice:

The alarm will automatically turn off after 60 minutes if no action is taken.

Alarm On/Off

- 1.When the alarm time is set, press and hold the button for 2 seconds to turn on the alarm and the indicator appears on the display. The alarm will go off on the next day.
- 2.Press and hold the button for 2 seconds to completely turn off alarm and the indicator disappears on the display. The alarm will NOT go off on the next day.


Display Brightness Setting

Scroll the DISPLAY DIMMER dial at the back of the machine to adjust the display brightness. (It can be adjusted from 0 to100%)

13

Night Light Setting

1.Press the button to turn on the night light.
Then press the button to change the color of night light.



2.When the night light is on, press the button to switch among all the 12 colors and modes in sequence.

14

Here is the list of light colors and modes

C01	Warm White Light	C05	Green
C02	Red	C06	Cyan
C03	Orange	C07	Blue
C04	Yellow	C08	Purple
C09	RGB Flowing Light Mode: In this mode,the RGB light colors flow sequentially from left to right.		
C10	Gradient Light Mode: In this mode, the RGB light colors gradually transition from one to the next in sequence.		
C11	Breathing Light Mode: In this mode, the red-orange light gently dims and fades in color, then gradually brightens while deepening in color.		
C12	Rhythmic Light Mode: In this mode, the light's colors and brightness change in sync with the high and low of the music melody.		


15

3.Scroll the LIGHT DIMMER dial at the back of the machine to adjust the night light brightness. (It can be adjusted from 0 to 100%)

4.Press and hold the button for 2 seconds, the night light will be turned off.

Bluetooth Connection Setting

1.Press the button to turn on/off Bluetooth. When Bluetooth is ON, the icon flashes on the display.



16

2.Turn on Bluetooth on your phone and connect with the device "HOUSBAY-TS5". The icon stops flashing on the display upon connecting successfully.

- 3.When music is playing, press the or button to change the music. Press the button to pause the music and press again to play.
- 4.Press the or button to select the volume level. (0-30 level adjustable)
5. Press and hold the button for 2 seconds to disconnect from the current device.

Notice:

1.The Bluetooth will automatically turn off if fails to connect to the phone within 5 minutes.

17

2.When the clock is connected to the phone via Bluetooth, it will auto-sync the phone time to the alarm clock. It may fail to auto-sync the time due to incompatible situations on different phone version.

3.When the Bluetooth is on, the volume adjustment is only used for the Bluetooth speaker, the volume of the alarm will not be affected.

4. Please turn up the paired device for the desired volume, then adjust the volume of the Bluetooth speaker as they cannot sync the same volume level automatically.

Battery Operated Setting

- 1.The device has a built-in 2400 mAh lithium battery.
- 2.Under the battery power, all functions can be used normally.
- 3.The clock works and lasts a few hours if it is powered by battery only, please keep it plugged in always!

18

Power ON/OFF

Press and hold the button on the back for 2 seconds to turn ON/OFF the machine.

Reset

Press and hold the and buttons for 2 seconds at the same time, and all settings of the machine will be reset.

Support

The Bluetooth Alarm Clock with Night Light comes with one year warranty. If you have any issue with this machine, please contact us at Support@keviec.com. We will address your issue within 24 hours.

19

FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.