

SMART CURTAIN ROBOT

Warm reminder:

1. The dual-open smart curtain robot is controlled by linkage, you only need to add a curtain robot after booting.
2. Do not untie the double-open smart curtain robot. After unbinding, one curtain machine will not move and the machine will not be linked. Manipulation
3. If you accidentally unbind, click on the settings to restore the initial state and return to the learning interface. After clicking on the binding, a set of codes will appear (do not change), just click on the binding to automatically jump to the learning interface, and you can learn again


Parts List



Curtain Robot




USB Cable



Note: Double-click to enter the pairing mode after booting

APP Connection Method



Download the "SmartLife" app, register and log in


- ①Click "add device"
- ②Click "automatic discovery", then click "start searching"
- ③Found smart curtain robot, click "next"
- ④Waiting for connection.
- ⑤Click done

Learning Method



- ①Click above smart curtain robot
- ②The initial installation position of the curtain robot is the curtain's close state, click "start learning".
- ③Click "stop learning" after the curtain is fully opened.
- ④Click "OK" after completing the learning.

Multi-function Settings



- ①Control interface: you can control the full open/half open/close of the curtain, click o in the upper right corner to enter the setting interface
- ②Setting interface: set the temperature/light intensity to close, set the timing switch, the curtain robot needs to learn again if clicked to restore the initial state
- ③Light intensity setting interface: Set the light intensity to close as needed
- ④Temperature setting interface: set the temperature to close as needed
- ⑤ Timing setting interface: set the timing switch as needed

Product Name:Smart curtain robot

Model Name:LY-1668

Connection: Bluetooth

Operating temperature: -10°C -50°C

Working humidity: 0-95% RH, no condensation

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirements, the device can be used in portable exposure condition without restriction